Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Chicco 00006825120000

Chicco Thermal Cup Blue User Manual

Model: 00006825120000

Product Overview

The Chicco Thermal Cup is designed to help children transition to drinking independently while keeping beverages at a consistent temperature for longer periods. Its ergonomic design and silicone straw make it suitable for use both at home and on the go.



Image: Front view of the Chicco Thermal Cup in blue, featuring a friendly hippo character design. The cup has an insulated body and a soft silicone straw.

This insulated cup is recommended for children aged 18 months and older. It has a capacity of 266 milliliters (9 ounces) and is made from durable silicone material, ensuring safety and comfort for your child.



Image: The Chicco Thermal Cup in blue, displayed within its retail packaging. The packaging highlights key features such as "18m+" age suitability and "266 ml / 9 oz" capacity.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts, including the cup body, lid, and silicone straw, are present.

2. **Initial Cleaning:** Before first use, wash all parts of the cup thoroughly with warm soapy water. Rinse well and allow to air dry completely. Refer to the "Maintenance and Cleaning" section for detailed instructions.
3. **Assemble the Straw:** Insert the silicone straw firmly into the designated opening in the lid. Ensure it is securely seated to prevent leaks.
4. **Attach the Lid:** Screw the lid onto the cup body until it is hand-tight. Do not overtighten.

Operating Instructions

Filling the Cup

1. Unscrew the lid from the cup body.
2. Pour the desired beverage into the cup. Do not fill beyond the maximum fill line (if indicated) or to the very top to prevent spills when the lid is attached.
3. Re-attach the lid securely, ensuring the straw is properly aligned.

Using the Thermal Feature

The double-wall insulation of the Chicco Thermal Cup helps maintain the temperature of both warm and cold beverages for an extended period. For best results:

- For warm drinks: Pre-warm the cup with warm water before adding the beverage.
- For cold drinks: Pre-chill the cup with cold water before adding the beverage.
- Ensure the lid is always securely closed when not in use to maximize thermal retention.

Drinking from the Straw

The soft silicone straw is designed for easy sipping. Children can simply tilt the cup and sip through the straw. The integrated valve helps prevent spills.

Maintenance and Cleaning

Regular cleaning is essential to ensure hygiene and prolong the life of your Chicco Thermal Cup.

Daily Cleaning

1. **Disassemble:** Separate the cup body, lid, and silicone straw.
2. **Wash:** Wash all parts immediately after each use with warm water and a mild dish soap. Use a straw brush (not included) to thoroughly clean the inside of the silicone straw.
3. **Rinse:** Rinse all components thoroughly under running water to remove any soap residue.
4. **Dry:** Allow all parts to air dry completely before reassembling or storing to prevent mold and mildew growth.

Dishwasher Use

The Chicco Thermal Cup is generally dishwasher-safe (top rack only). However, hand washing is recommended for optimal longevity of the product's thermal properties and printed designs.

Storage

Store the cup in a clean, dry place away from direct sunlight and extreme temperatures. Ensure all parts are dry before storage.

Important Notes

- Do not use abrasive cleaners, scourers, or solvents as these can damage the product.
- Do not sterilize in a microwave.
- Regularly inspect the straw and other components for signs of wear or damage. Replace immediately if any damage is observed.

Troubleshooting

Problem	Possible Cause	Solution
Leaking from the lid	Lid not securely tightened. Straw not properly inserted. Gasket/seal damaged or missing.	Ensure lid is screwed on tightly. Check that the straw is fully seated. Inspect the lid's seal for damage and replace if necessary.
Difficulty sipping through straw	Straw clogged. Air vent blocked.	Clean the straw thoroughly with a straw brush. Check the air vent on the lid for any blockages and clear if needed.
Beverage not staying warm/cold	Lid not sealed properly. Cup not pre-warmed/chilled.	Ensure the lid is tightly closed. Pre-warm or pre-chill the cup before adding the beverage.
Unpleasant odor or taste	Inadequate cleaning. Residue buildup.	Disassemble all parts and clean thoroughly, paying special attention to the straw and lid crevices. Consider a deep clean with baking soda and water solution.

Specifications

Model Number: 00006825120000

Brand: Chicco

Material: Silicone (straw), Insulated plastic (cup body)

Capacity: 266 ml (9 oz)

Dimensions (L x W x H): Approximately 9 x 10.5 x 16 cm

Weight: Approximately 159 grams

Recommended Age: 18 months +

Special Features: Insulated, Silicone Straw, Ergonomic Shape

Color: Assorted (Blue with hippo design, Pink with giraffe design) *-This manual focuses on the blue version.*

Components Included: 1x Thermal Cup, 1x Silicone Straw

Warranty and Support

Chicco products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Chicco website for your region.

If you encounter any issues not covered in this manual or require further assistance, please contact Chicco Customer Service. Contact details can typically be found on the product packaging or the official Chicco website.

Online Resources: For additional product information, FAQs, and support, please visit the official Chicco website.

© 2023 Chicco. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00SN4FX02

More documents and user manuals: **https://manuals.plus/**