Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell 201540

Bushnell Tour X Jolt Golf Laser GPS/Rangefinder User Manual

Model: 201540

Product Overview

The Bushnell Tour X JOLT laser rangefinder is designed for golf enthusiasts, offering advanced features for accurate distance measurement. It incorporates Exchange Technology, allowing users to switch between Slope Technology for compensated distances and a USGA conforming mode for tournament play. The integrated Dual Display Technology provides flexibility to choose between a bright red vivid display or a crisp black display based on lighting conditions. This device offers precise measurements accurate to 1/2 yard, ranging from 5 to 1,300 yards, and includes the PinSeeker with JOLT feature for flag locking confirmation. It features 6x magnification with HD optics and operates with a 3-volt battery.



Figure 1: Bushnell Tour X Jolt Golf Laser Rangefinder. This image shows the overall design of the rangefinder, highlighting its white, black, and red color scheme.

Key Features

- **Exchange Technology:** Allows for use of patented Slope Technology for compensated distances (red faceplate) and USGA conforming device functionality (black faceplate).
- **Dual Display Technology:** Seamlessly switch between bright red vivid display and crisp black display.
- **PinSeeker with JOLT Technology:** Provides tactile feedback when the device locks onto the flag.
- **Accuracy:** Accurate to 1/2 yard, with a ranging capability from 5 to 1,300 yards.
- **Magnification:** 6x magnification with HD optics.
- **Power:** Operates on a 3-volt battery.

Setup

1. Battery Installation

The Bushnell Tour X JOLT requires one 3-volt CR2 battery.

1. Locate the battery compartment on the side of the device.
2. Twist the battery cap counter-clockwise to open.
3. Insert the 3-volt CR2 battery with the positive (+) terminal facing inward.

4. Replace the battery cap and twist clockwise to secure.



Figure 2: Battery compartment. This image shows the rangefinder with its battery compartment open, revealing where the 3-volt CR2 battery is inserted.

2. Faceplate Selection (Exchange Technology)

The Tour X JOLT comes with two interchangeable faceplates: a red faceplate for Slope Technology and a black faceplate for USGA conforming play.

1. To change the faceplate, gently slide the current faceplate off the front of the unit.
2. Align the desired faceplate (red for Slope, black for non-Slope) with the unit and slide it into place until it clicks securely.



Figure 3: Interchangeable Faceplates. This image displays both the red (Slope) and black (non-Slope) faceplates, which can be swapped to enable or disable the slope compensation feature.



Figure 4: Rangefinder with Black Faceplate. This image shows the rangefinder with the black faceplate attached, indicating it is set for USGA conforming play without slope compensation.

Operating Instructions

1. Powering On and Focusing

- Press the Power/Fire button (usually on top) once to activate the display.
- Rotate the eyepiece (diopter adjustment) until the display and target appear sharp and clear.

2. Ranging a Target

- Aim the reticle (crosshairs) at the desired target.
- Press and hold the Power/Fire button. The distance will be displayed in the viewfinder.

3. PinSeeker with JOLT Technology

This feature allows for easy acquisition of the flag without inadvertently getting distances to background targets.

1. While looking through the rangefinder, align the reticle over the flag.

2. Press and hold the Power/Fire button.
3. Slowly pan the rangefinder across the flag. The PinSeeker will identify the flag and provide a short vibration (JOLT) to confirm acquisition.
4. The distance to the flag will be displayed.

4. Dual Display Technology

To switch between the bright red Vivid Display Technology (VDT) and the crisp black display:

- With the unit powered on, press and hold the MODE button (usually on the side or bottom) for approximately 3 seconds.
- The display will toggle between red and black. Release the button when the desired display color is active.

5. Slope Technology (with Red Faceplate)

When the red faceplate is installed, the unit will provide compensated distances based on elevation changes.

- Perform a normal ranging operation.
- The display will show both the actual distance and the compensated "Play As" distance.

Maintenance and Care

- **Cleaning:** Gently wipe the lenses with a soft, clean cloth. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store the rangefinder in its protective case when not in use. Avoid extreme temperatures and high humidity.
- **Battery:** Remove the battery if the unit will not be used for an extended period to prevent leakage.
- **Water Resistance:** The unit is designed to be water-resistant, but it is not submersible. Avoid prolonged exposure to heavy rain or submersion in water.

Troubleshooting

Problem	Possible Cause / Solution
No display or dim display	Check battery installation. Replace battery if low. Adjust diopter for focus. Ensure Dual Display is set to appropriate brightness for lighting conditions.
Cannot obtain a reading	Ensure target is within ranging limits (5-1300 yards). Ensure Power/Fire button is pressed firmly. Target may be too small or non-reflective. Try ranging a larger object nearby.
JOLT feature not activating	Ensure PinSeeker mode is active and you are panning across the flag. The flag may be too far or obscured.

Specifications

- **Model:** 201540
- **Magnification:** 6x
- **Measuring Range:** 5 to 1300 yards
- **Accuracy:** +/- 0.5 yards
- **Battery Type:** 3-volt CR2 (Alkaline)
- **Item Weight:** 0.16 Kilograms

- **Dimensions (LxWxH):** 4.72 x 3.15 x 1.57 inches
- **Laser Type:** Class 1 laser with <0.5mW average power output

Warranty and Support

Warranty Information

The Bushnell Tour X JOLT Golf Laser GPS/Rangefinder typically comes with a 2-year limited warranty from the manufacturer. Please refer to the original product packaging or the official Bushnell website for the most current and detailed warranty terms and conditions.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Bushnell customer support.

- **Website:** www.bushnellgolf.com
- **Phone:** Refer to the Bushnell website for regional contact numbers.

© 2024 Bushnell. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00SW2G0U2

More documents and user manuals: **https://manuals.plus/**