Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic SR-932DPLW

Panasonic SR-932DPLW 2-Litre Electric Cooker Instruction Manual

Model: SR-932DPLW

Introduction

Thank you for purchasing the Panasonic SR-932DPLW 2-Litre Electric Cooker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.

Product Overview

Included Components

- Electric Cooker Unit
- Cooking Pan (Anodised Aluminium)
- Lid
- Spatula
- Measuring Cup
- User Manual
- Warranty Card

Key Features

- **Total Volume:** 8.2 Litre
- **Raw Capacity:** 2 Litre
- Wide large pan for efficient cooking
- Anodised aluminium pan for durability and even heating
- 3.2 litres cooking capacity
- Power: 1025 watts for quick cooking
- Micro switch and thermal fuse for protection against power fluctuations
- Uniform cooking with double heating coil

- Automatic keep warm function for up to 5 hours
- Auto cut-off reliability for safety

Product Visuals



Image: The Panasonic SR-932DPLW Electric Cooker shown with its lid, inner cooking pan, steamer basket, measuring cup, and rice spatula.



Image: Front view of the Panasonic SR-932DPLW Electric Cooker, highlighting the 'Cook' and 'Warm' indicator lights and the control switch.



Image: Close-up of the anodised aluminum inner cooking pan, designed for durability and even heat distribution.

Product Video

▶ Watch video online

Video: A short overview showcasing the key features and design of the Panasonic SR-932DPLW Electric Cooker, including its anodized aluminum pan, safety features, and keep-warm function.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or transport.
2. **Clean:** Before first use, wash the inner cooking pan, lid, steamer plate, spatula, and measuring cup with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the cooker unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the electric cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Insert Pan:** Place the clean, dry inner cooking pan into the main cooker unit. Ensure it sits properly on the heating plate.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet (230 Volts).

Operating Instructions

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly under cold water until the water runs clear.
2. **Add Water:** Place the rinsed rice into the inner cooking pan. Add the appropriate amount of water. A general guideline is 1.5 to 2 cups of water for every 1 cup of rice, but refer to specific rice package instructions for best results.
3. **Place Pan and Lid:** Ensure the outer surface of the inner pan is dry, then place it into the main cooker unit. Cover with the lid.
4. **Start Cooking:** Plug the power cord into the wall socket. Press the 'Cook' switch down. The 'Cook' indicator light will illuminate.
5. **Automatic Keep Warm:** Once the rice is cooked, the switch will automatically flip up, and the 'Warm' indicator light will illuminate. The cooker will then switch to keep-warm mode, maintaining the rice at an optimal serving temperature for up to 5 hours.
6. **Serve:** After cooking, allow the rice to rest for 10-15 minutes in keep-warm mode for best texture. Use the provided spatula to fluff and serve the rice.

Steaming (if using steamer plate)

1. **Prepare Water:** Add water to the inner cooking pan, ensuring it does not touch the bottom of the steamer plate.
2. **Place Steamer Plate:** Insert the steamer plate into the inner cooking pan.
3. **Add Food:** Place vegetables, fish, or other food items on the steamer plate.
4. **Cook:** Cover with the lid and press the 'Cook' switch down. The cooker will switch to 'Warm' mode once the water has evaporated or the cooking cycle is complete. Monitor steaming time as needed for your specific food.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your electric cooker.

1. **Unplug:** Always unplug the cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pan and Lid:** Wash the inner cooking pan, lid, steamer plate, spatula, and measuring cup with warm, soapy water. Use a soft sponge or cloth to avoid scratching the non-stick surface of the pan. Rinse thoroughly and dry completely.
3. **Exterior:** Wipe the exterior of the cooker unit with a damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main cooker unit in water or any other liquid.
4. **Heating Plate:** If food particles are stuck to the heating plate, gently wipe them off with a damp cloth. Do not use metal objects to scrape the heating plate.
5. **Storage:** Store the clean and dry electric cooker in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; Power outage; Faulty outlet.	Ensure power cord is securely plugged in. Check power supply. Try a different outlet.
Rice is undercooked or too hard.	Insufficient water; Rice not soaked (for some types); Lid not properly sealed.	Add more water next time. Ensure lid is closed tightly. Consider soaking rice if recommended.
Rice is overcooked or mushy.	Too much water; Rice cooked for too long.	Reduce water amount next time. Do not leave rice in 'Cook' mode longer than necessary.
Rice sticks to the bottom of the pan.	Not enough water; Pan not properly cleaned; Pan is worn.	Ensure correct water-to-rice ratio. Clean pan thoroughly. If pan is old, consider replacement.
Steam escapes from around the lid.	Lid not seated correctly; Lid or pan deformed.	Adjust the lid to ensure a tight seal. Check for any damage to the lid or pan.

Specifications

- **Brand:** Panasonic
- **Model Number:** SR-932DPLW
- **Item Type Name:** Electric Cooker
- **Colour:** White
- **Capacity:** 8.2 litres (Total Volume), 2 Litre (Raw Rice Capacity), 3.2 litres (Cooking Capacity)
- **Power Source:** Electric
- **Power Source Type:** Electric
- **Wattage:** 1025 Watts
- **Voltage:** 230 Volts
- **Material Type:** Metal (Body), Anodised Aluminium (Inner Pan), Aluminum (Lid)
- **Product Care Instructions:** Hand Wash (for removable parts), Wipe Clean (for main unit)
- **Item Weight:** 6.02 Kilograms

- **Manufacturer:** Panasonic App India Co Ltd

Warranty and Support

Warranty Information

This Panasonic Electric Cooker comes with a comprehensive warranty:

- **Heater:** 5 years warranty
- **Product:** 2 years warranty

Please refer to the included Warranty Card for detailed terms and conditions, including coverage and claim procedures.

Customer Support

For any product-related queries, service requests, or technical assistance, please contact Panasonic customer support:

- **Manufacturer Contact:** Panasonic App India Co Ltd, Ponneri Taluk, Chennai, Tamilnadu. Contact - 9867664664.
- **Packer Contact:** Panasonic Applinaces India Co Ltd., NH-No-5 Sholavaram Villege, Ponneri Taluk, Chennai-600067. Contact Person for Customer Complaints: 9835302102.
- **Website:** www.panasonic.com

When contacting support, please have your product model number (SR-932DPLW) and purchase details ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00T642RXE

More documents and user manuals: **https://manuals.plus/**