Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BLOSSOMZ BLZ-0753

BLOSSOMZ Mainstays Slimline Digital Scale User Manual

Model: BLZ-0753

Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Introduction

Thank you for purchasing the BLOSSOMZ Mainstays Slimline Digital Scale, model BLZ-0753. This digital scale is designed for accurate measurement of food and other items in your kitchen, providing measurements in pounds, ounces, and grams. Please read this manual thoroughly before use to ensure proper operation and care.

Setup

1. Unpacking

Carefully remove all components from the packaging. Ensure all parts are present and undamaged. Retain packaging for future storage or transport.

2. Battery Installation

The scale requires batteries for operation. Locate the battery compartment on the underside of the scale. Open the compartment cover, insert the required batteries (typically AAA, refer to compartment markings for correct polarity), and close the cover securely.

3. Placement

Place the digital scale on a hard, flat, and stable surface. Uneven or soft surfaces can affect measurement accuracy. Avoid placing the scale near strong electromagnetic fields or extreme temperature fluctuations.



Image: The BLOSSOMZ Mainstays Slimline Digital Scale, model BLZ-0753, shown in its packaging with a bowl of fresh berries on its surface, illustrating its intended use for kitchen measurements.

Operation

1. Turning On/Off

- To turn on: Press the **ON/OFF** button (or the **MODE** button if no dedicated ON/OFF). The display will show "0" or "0.0".
- To turn off: Press and hold the **ON/OFF** button for a few seconds, or the scale will automatically shut off after a period of inactivity to conserve battery life.

2. Unit Conversion

Press the **MODE** button to cycle through available measurement units: pounds (lb), ounces (oz), and grams (g). Select the desired unit before weighing.

3. Tare Function

The Tare function allows you to weigh items in a container by subtracting the container's weight.

1. Place an empty container on the scale.
2. Press the **TARE** button (or the **Z/T** button). The display will reset to "0".
3. Add the items you wish to weigh into the container. The display will show only the weight of the added items.

4. Weighing Items

Ensure the scale is on and set to the desired unit. Place the item(s) directly onto the weighing platform or into a tared container. Read the weight displayed on the LCD screen.

Maintenance

1. Cleaning

Wipe the scale surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water. Ensure the scale is completely dry before storage or next use.

2. Storage

Store the scale in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

3. Battery Replacement

When the battery indicator appears on the display, or if the scale fails to turn on, replace the batteries. Always replace all batteries at the same time with new ones of the same type.

Troubleshooting

Problem	Possible Cause	Solution
Scale does not turn on	Dead or incorrectly installed batteries	Replace batteries, ensuring correct polarity.
Inaccurate readings	Uneven surface, scale overloaded, or calibration issue	Place on a flat, stable surface. Do not exceed maximum weight capacity. Turn off and on again to re-calibrate.
"Err" or "O-Ld" displayed	Overload indication	Remove item immediately. The scale's capacity has been exceeded.
Display shows "Lo"	Low battery indication	Replace batteries.

Specifications

Model: BLZ-0753

Brand: BLOSSOMZ

Product Dimensions: 7.64 x 5.51 x 0.55 inches

Item Weight: 1.45 pounds

Weight Limit: 400 Pounds (Note: This capacity is unusually high for a typical kitchen scale. Please use within reasonable kitchen measurement limits.)

Units: Pounds (lb), Ounces (oz), Grams (g)

Color: Black

Power Source: Batteries (type not specified, typically AAA or AA)

Warranty & Support

Warranty Information

This product is covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase or contact customer support for details regarding warranty terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or to inquire about replacement parts, please contact BLOSSOMZ customer

support. Contact information can typically be found on the product packaging or the manufacturer's official website. Please have your model number (BLZ-0753) ready when contacting support.

© 2023 BLOSSOMZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00U9OMS6Q

More documents and user manuals: **https://manuals.plus/**