Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome IH-K301

iHome IH-K301 Classic Corded USB Desktop Keyboard User Manual

Model: IH-K301

1. Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your iHome IH-K301 Classic Corded USB Desktop Keyboard. Please read this manual thoroughly before using the product.



Image 1.1: iHome IH-K301 Classic Corded USB Desktop Keyboard. This image displays the full-size black keyboard with its attached USB cable.

2. Package Contents

- iHome IH-K301 Classic Corded USB Desktop Keyboard
- User Manual (this document)

3. Setup Instructions

The iHome IH-K301 keyboard is designed for simple plug-and-play installation.

1. **Connect the USB Cable:** Locate an available USB port on your computer. Insert the USB connector from the

keyboard into the USB port.

2. **System Recognition:** Your operating system (Windows or macOS) should automatically detect and install the necessary drivers for the keyboard. This process typically takes a few seconds.
3. **Adjust Keyboard Feet (Optional):** For ergonomic comfort, you may extend the fold-out feet located on the underside of the keyboard to adjust its tilt.
4. **Test Functionality:** Open a text editor or any application that accepts text input and type to confirm the keyboard is functioning correctly.

Note: No additional software or drivers are required for basic functionality.

4. Operating the Keyboard

The IH-K301 is a full-size QWERTY keyboard with standard layout and additional features.

4.1 Key Features

- **Full-Size Layout:** Includes a numeric keypad and function keys (F1-F12).
- **Quiet Touch Keys:** Designed for reduced typing noise.
- **LED Indicators:** Lights for Num Lock, Caps Lock, and Scroll Lock are located above the numeric keypad.
- **Adjustable Tilt:** Fold-out feet on the underside allow for angle adjustment.

4.2 Special Keys

- **Function Keys (F1-F12):** Perform various system or application-specific functions.
- **Print Screen (PrtSc):** Captures the current screen.
- **Scroll Lock (ScrLk):** Toggles scroll lock functionality in some applications.
- **Pause/Break:** Used for pausing system processes or debugging.
- **Numeric Keypad:** Provides dedicated number and arithmetic keys. Ensure Num Lock is active for number input.

5. Maintenance and Care

Proper care will extend the life of your keyboard.

- **Cleaning:** Disconnect the keyboard from your computer before cleaning. Use a soft, damp cloth to wipe the surface. For dust and debris between keys, use compressed air. Avoid harsh chemicals or abrasive cleaners.
- **Spill Resistance:** The keyboard features drainage holes on the underside to help mitigate damage from minor liquid spills. In case of a spill, immediately disconnect the keyboard, invert it to drain liquid, and allow it to dry completely before reconnecting. This feature is not a guarantee against all liquid damage.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter issues with your keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
  - Ensure the USB cable is securely connected to both the keyboard and the computer.
  - Try plugging the keyboard into a different USB port on your computer.
  - Restart your computer.
  - Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's USB

port/drivers.

- **Keys Not Registering or Registering Inconsistently:**
  - Check for any debris or obstructions under the affected keys. Use compressed air to clear them.
  - Ensure you are pressing the keys firmly.
  - If the issue persists, the key switch may be faulty.
- **Numeric Keypad Not Working:**
  - Press the "Num Lock" key. The Num Lock LED indicator should illuminate when active.
- **LED Indicators Not Lighting Up:**
  - Ensure the keyboard is properly connected and receiving power.
  - Toggle the respective lock keys (Num Lock, Caps Lock, Scroll Lock) to see if the LEDs respond.

7. Specifications

Feature	Detail
Brand	iHome
Model Number	IH-K301
Connectivity	Wired USB (USB-A)
Keyboard Layout	QWERTY, Full-Size with Numeric Keypad
Operating System Compatibility	Windows 2000, Windows XP, Windows Vista, Windows 7, Windows 8, OSX 10.0 or later
Hardware Platform	PC
Dimensions (LxWxH)	17.7 x 5.6 x 1.3 inches (approx.)
Item Weight	1.25 pounds (approx.)
Special Features	Foldable feet for tilt adjustment, Quiet Touch keys, LED indicators

8. Warranty and Support

For warranty information and technical support, please refer to the official iHome website or contact their customer service department. Keep your purchase receipt as proof of purchase.
iHome Official Website: www.ihome.com
Customer Service: Refer to the iHome website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00X8FQ7CO

More documents and user manuals: **https://manuals.plus/**