Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

1byone O0000-0750

1byone Wireless Turntable HiFi System User Manual

Model: O0000-0750
Brand: 1byone

Introduction | Safety Information | What's in the Box | Features | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your 1byone Wireless Turntable HiFi System. Please read this manual thoroughly before using the product to ensure proper function and longevity. This briefcase-styled turntable combines modern elements with a retro aesthetic, offering a unique way to enjoy your vinyl records.

2. Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- This appliance must be used only for the purpose for which it has been developed, and in the manner described in the instructions for use. Any improper use can be dangerous.

3. What's in the Box

Upon opening the package, please verify that all components are present and undamaged:

- 1. Turntable Unit
- 2. Power Cable
- 3. User Manual (this document)

4. Key Features

- Front-facing built-in stereo speakers for great sound.
- Dynamic, balanced tone arm with soft damping control.
- Selectable 33 / 45 / 78 RPM speeds settings with included 45-RPM adapter.
- RCA output and headphone jack line-in and line-out make it easy to operate and listen to your music your way.
- Briefcase-style turntable for lightweight, easy storage and portability.

5. Setup Guide

5.1 Unpacking and Placement

Carefully remove the turntable from its packaging. Place the unit on a stable, flat surface away from direct sunlight, heat sources, and excessive dust or vibrations. Ensure adequate ventilation around the unit.



Figure 1: The 1byone Wireless Turntable HiFi System in its open, ready-to-play configuration. The turntable is housed within a black briefcase-style casing, featuring a record platter, tone arm, and built-in speakers on the front.



Figure 2: The 1byone Wireless Turntable HiFi System in its closed, portable briefcase form. The black casing features a sturdy handle and chrome latches, highlighting its portability and compact storage design.

5.2 Power Connection

Connect the provided power cable to the DC input port on the turntable and then plug it into a standard wall outlet. Ensure the power switch is in the "OFF" position before connecting.

5.3 External Connections (Optional)

Your turntable offers various connectivity options:

- **RCA Output:** Use RCA cables (not included) to connect the turntable to external speakers or an amplifier for enhanced audio output.
- **Headphone Jack:** Plug in standard 3.5mm headphones for private listening.
- **3.5mm Line-in Port:** Connect external audio devices like iPods, MP3 players, or mobile phones to play their audio through the turntable's speakers.



Figure 3: A visual guide illustrating the various audio input and output options available on the 1byone turntable, including the headphone jack for personal listening, RCA outputs for connecting to external speakers, and a 3.5mm line-in port for connecting portable audio devices.



Figure 4: The 1byone turntable demonstrating its versatility by playing music from a smartphone connected through the 3.5mm line-in port, effectively using the turntable as a standalone music player for digital audio.

6. Operating Instructions

6.1 Playing a Vinyl Record

1. Open the turntable lid.
2. Place a vinyl record on the platter.
3. Select the appropriate speed (33, 45, or 78 RPM) using the speed selector switch. For 45 RPM records, place the included 45 RPM adapter on the spindle.
4. Remove the protective cap from the stylus (needle) and open the tone arm clip to release the tone arm.
5. Gently lift the tone arm using the cueing lever and position the stylus over the desired track on the record.
6. Lower the tone arm slowly using the cueing lever. The record will begin to play.
7. Adjust the volume using the volume knob.
8. When the record finishes, the tone arm will automatically return to its rest position if the AUTO STOP switch is ON. If AUTO STOP is OFF, the record will continue to spin.
9. To stop playback manually, lift the tone arm using the cueing lever and return it to its rest. Secure the tone arm with the clip.



Figure 5: A detailed view of the control panel located on the side of the 1byone turntable. This image highlights the power ON/OFF switch, volume control knob, headphone output, RCA (L/R) output jacks, and the Line-In port, providing a clear reference for users to identify and operate these functions.

6.2 Auto Stop Function

The AUTO STOP ON/OFF switch controls whether the record stops automatically when it reaches the end. For some records, the auto-stop function may activate before the end or not at all. If this occurs, you can switch AUTO STOP to OFF for continuous playback.

6.3 Using the Line-in Function

To play audio from an external device:

1. Connect your external audio device (e.g., smartphone, MP3 player) to the 3.5mm Line-in port using an audio cable (not included).
2. Turn on the turntable. The audio from your external device will now play through the turntable's speakers.
3. Adjust the volume using the turntable's volume knob and/or the volume control on your external device.

7. Maintenance and Care

7.1 Cleaning the Unit

Wipe the exterior of the turntable with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish. Keep the lid closed when not in use to protect the platter and tone arm from dust.

7.2 Stylus Care

The stylus is a delicate component. Avoid touching it with your fingers. Clean the stylus periodically with a soft brush designed for stylus cleaning, brushing gently from back to front. A worn or dirty stylus can damage your records and degrade sound quality. Replace the stylus when necessary.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Ensure power cable is securely plugged into the unit and a working outlet. Check if the power switch is ON.
No sound or low sound	Volume too low; External speakers not connected properly; Stylus dirty or damaged.	Increase volume. Check RCA or headphone connections. Clean or replace stylus.
Record not spinning	Tone arm not positioned correctly; Belt drive issue.	Ensure the tone arm is lifted and positioned over the record. If the issue persists, the drive belt may need inspection or adjustment (refer to professional service if unsure).
Sound distorted or skipping	Record dirty or scratched; Stylus dirty or worn; Turntable not level; Excessive vibration.	Clean the record. Clean or replace stylus. Place the turntable on a stable, level surface. Avoid placing near vibrating objects.
Auto stop not working correctly	Record type incompatibility.	Switch the AUTO STOP function to OFF if it's stopping prematurely or not at all for certain records.

9. Product Specifications

Product Dimensions: 5.12 x 10.04 x 13.78 inches

Item Weight: 5.7 pounds

Model Number: O0000-0750 (LP-02)

Brand: 1byone

Connectivity Technology: Wired

Maximum Rotational Speed: 78 RPM

Material: Plastic

Color: Sky Blue

On-mode power consumption: 36 watts

10. Warranty and Support

This 1byone product comes with a 24-month guarantee. For warranty claims, technical support, or any inquiries regarding your product, please contact 1byone customer service. Please retain your proof of purchase for warranty

validation.
For further assistance, visit the official 1byone store:1byone Store on Amazon

© 2024 1byone. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00XVJF2JG

More documents and user manuals: **https://manuals.plus/**