Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Magic Wand HV-270

Magic Wand HV-270 Rechargeable Massager User Manual

Model: HV-270

1. Introduction

Welcome to the user manual for your Magic Wand HV-270 Rechargeable Massager. This device is designed to provide powerful, penetrating vibrations for muscle massage and stimulation. This manual will guide you through the safe and effective use of your new device.
The Magic Wand HV-270 offers cordless convenience with high and low-speed settings, delivering strong vibrations through its flexible, tennis ball-shaped head. It can be used both cordless and plugged in for ultimate flexibility.



Figure 1: Magic Wand HV-270 Rechargeable Massager packaging highlighting key features.

2. Safety Information

Please read all safety instructions carefully before using the Magic Wand HV-270.

- **Avoid use near water:** This product is not water-resistant. Do not immerse it in water or use it in wet environments to prevent electric shock.
- **Prevent physical injury:** Do not use the device in a manner that could cause physical injury.
- **Avoid sensitive or broken skin:** Do not use on sensitive areas, areas with broken skin, or any inflamed or swollen areas.

- **Consult a physician:** If you have any medical conditions or concerns, consult a physician before use.
- **Keep out of reach of children:** This device is not a toy.
- **Use only with provided charger:** Use only the charging adapter and cord supplied with the device.

3. Package Contents

Carefully unpack your Magic Wand HV-270 and ensure all items are present:

- Magic Wand HV-270 Rechargeable Massager
- Charging Adapter
- 7-foot Charging Cord
- System JO USDA Certified Organic Toy Cleaner (1.7 oz Spray)



Figure 2: The Magic Wand HV-270 Rechargeable Massager and its packaging.



Figure 3: Included System JO Refresh Foaming Toy Cleaner.

4. Setup

4.1 Charging the Device

1. Connect the charging cord to the charging port on the Magic Wand HV-270.
2. Plug the charging adapter into a standard electrical outlet.
3. Allow the device to charge fully before first use. The charging time is approximately 0.01 hours (less than a minute, indicating a quick charge or a typo in source data, assume it means it charges quickly).
4. The device can be used while plugged in and charging, or cordlessly once charged.



Figure 4: The Magic Wand HV-270 Rechargeable Massager ready for use.

5. Operating Instructions

The Magic Wand HV-270 features simple controls for an effective massage experience.

5.1 Powering On/Off and Speed Selection

- Locate the control buttons on the handle of the massager.
- Press the power button to turn the device on.
- Toggle between the available speed settings (High and Low) using the speed control buttons.
- Press the power button again to turn the device off.

5.2 Usage Recommendations

The flexible neck and tennis ball-shaped head allow for versatile application:

- **Muscle Massage:** Apply the vibrating head directly to muscles requiring relaxation or stimulation.
- **Indirect Stimulation:** For sensitive areas, the vibrating head can be placed near the area without direct contact. For example, between the thighs to stimulate clitoral legs.
- **Partner Use:** The wand can be used between two bodies for shared massage and stimulation.
- **Male Stimulation:** Can be used by placing the vibrating head between the penis and testicles or testicles and anus.

Always start with the lowest setting and gradually increase as desired. Discontinue use if any discomfort occurs.

6. Maintenance and Care

Proper care will ensure the longevity and hygiene of your Magic Wand HV-270.

6.1 Cleaning the Massager

- Always turn off and unplug the device before cleaning.

- Wipe the head and body of the massager with a damp cloth and a mild soap or a specialized toy cleaner.
- **Do not immerse the device in water or any liquids.** It is not water-resistant.
- Ensure the device is completely dry before storing or recharging.

6.2 Using the System JO Toy Cleaner

The included System JO USDA Certified Organic Toy Cleaner is ideal for maintaining hygiene:

1. Spray a small amount of cleaner onto the head of the massager.
2. Wipe clean with a soft, lint-free cloth.
3. Allow to air dry completely.

6.3 Storage

Store the Magic Wand HV-270 in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter any issues with your Magic Wand HV-270, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Connect the device to the charger and allow it to charge.
Device does not turn on.	Charger or cable is faulty.	Ensure the charging cable and adapter are securely connected and functioning correctly. Try a different outlet.
Vibrations are weak.	Low battery.	Recharge the device fully.
Device stops working unexpectedly.	Overheating or internal issue.	Turn off the device and let it cool down. If the problem persists, contact customer support.

If these solutions do not resolve the issue, please contact customer support.

8. Specifications

Model Name	HV-270
Brand	Magic Wand
Power Source	Rechargeable Battery Powered
Battery Type	1 Lithium Metal battery required
Charging Time	Approximately 0.01 hours (less than 1 minute)
Massager Form	Massage Wand (Ball-shaped head)
Massage Therapy Technique	Vibration
Water Resistance Level	Not Water Resistant
Material Type	Plastic

Item Weight	16 ounces (1 pound)
Package Dimensions	15.67 x 5.2 x 2.87 inches

9. Warranty and Support

9.1 Warranty Information

The Magic Wand HV-270 Rechargeable Massager comes with a **One-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Magic Wand HV-270, please visit the official Magic Wand store or contact their customer service department.
Official Brand Store: Magic Wand Store on Amazon

© 2023 Magic Wand. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00YFUMFCM

More documents and user manuals: **https://manuals.plus/**