Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 316456528

Frigidaire Range/Stove/Oven Backsplash Panel

MODEL: 316456528

1. Introduction

This manual provides essential information for the installation, maintenance, and care of your genuine Frigidaire 316456528 Range/Stove/Oven Backsplash Panel. This component is designed as a direct replacement part to ensure proper fit and function with compatible Frigidaire appliances. Please read all instructions carefully before proceeding with installation or maintenance.

2. Safety Information

- Always disconnect power to the appliance at the circuit breaker or fuse box before attempting any installation or repair. Failure to do so can result in electrical shock or injury.
- Wear appropriate personal protective equipment, such as gloves, to prevent cuts or scrapes from sharp edges.
- If you are unsure about any part of the installation process, it is recommended to consult a qualified appliance technician.
- Keep children and pets away from the work area during installation.
- Handle the backsplash panel carefully to avoid bending or damaging it.

3. Package Contents

Verify that your package contains the following item:

- One (1) Frigidaire 316456528 Range/Stove/Oven Backsplash Panel



Figure 1: The Frigidaire 316456528 Backsplash Panel, a rectangular metal component designed to fit behind a range, stove, or oven.

4. Setup and Installation

The following steps provide a general guide for installing the backsplash panel. Specific procedures may vary depending on your appliance model. Refer to your appliance's main instruction manual for detailed removal and installation steps if available.

1. **Prepare the Area:** Ensure the range/stove/oven is pulled away from the wall, providing adequate access to the rear of the appliance.
2. **Disconnect Power:** Turn off the electrical power to the appliance at the main circuit breaker or fuse box.
3. **Remove Old Backsplash (if applicable):** If replacing an existing backsplash, carefully remove any screws, clips, or fasteners holding it in place. Store fasteners if they are to be reused.
4. **Position New Backsplash:** Align the new Frigidaire 316456528 Backsplash Panel with the mounting points on the rear of your range/stove/oven.
5. **Secure the Panel:** Use the appropriate screws or fasteners (often reused from the old panel, or new ones provided with the appliance) to securely attach the backsplash panel. Ensure it is flush and stable. Do not overtighten screws.
6. **Verify Installation:** Gently test the panel to ensure it is firmly attached and does not wobble.
7. **Restore Power:** Once the backsplash is securely installed, push the appliance back into its position and restore power at the circuit breaker.

5. Operating Instructions

This backsplash panel is a stationary component and does not require operational instructions. Its function is to provide a protective and aesthetic barrier at the rear of your cooking appliance.

6. Maintenance and Care

To keep your Frigidaire backsplash panel in good condition:

- **Cleaning:** Clean the backsplash regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining or residue buildup.
- **Inspection:** Periodically check the mounting screws to ensure they remain tight. Do not overtighten.

7. Troubleshooting

As a non-operational component, troubleshooting for the backsplash panel is limited to physical issues:

- **Panel is Loose:** Ensure all mounting screws are properly tightened. If the mounting points on the appliance are damaged, professional repair may be required.
- **Panel is Damaged:** If the panel is bent, scratched, or otherwise damaged, it may need to be replaced. Cosmetic damage does not typically affect function but can impact appearance.

8. Specifications

Attribute	Value
Brand	Frigidaire
Model Number	316456528
Item Weight	4.52 pounds
Product Dimensions	31 x 7.5 x 1.75 inches
Part Type	Backsplash Panel

9. Warranty Information

This product is a genuine Frigidaire replacement part. For specific warranty details regarding this component, please refer to the warranty documentation that came with your original appliance or visit the official Frigidaire website. Warranty terms typically cover manufacturing defects.

10. Customer Support

If you have further questions or require assistance with your Frigidaire 316456528 Backsplash Panel, please contact Frigidaire customer support or visit their official website for service and support resources.

Official Frigidaire Website: www.frigidaire.com

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00YH35PV0

More documents and user manuals: **https://manuals.plus/**