Garmin 010-01284-00

Garmin Panoptix PS30 Down Transducer User Manual

Model: 010-01284-00

Introduction

The Garmin Panoptix PS30 Down Transducer provides advanced sonar imaging capabilities, allowing users to visualize fish and bait in real-time beneath their vessel. This transducer offers three distinct views: LiveVu Down, RealVu 3-D Down, and RealVu 3-D Historical, enhancing situational awareness for fishing and navigation. This manual provides essential information for the setup, operation, and maintenance of your Panoptix PS30 transducer.

Setup and Installation

Proper installation is crucial for optimal performance of your Panoptix PS30 transducer. The transducer is designed for transom mounting and includes the necessary mounting kit.

Included Components:

- PS30 down looking transducer (integrated 30' network cable, 15' power cable)
- Transom mount
- Split ring RJ-45 connector
- Documentation

Mounting Considerations:

The transom mount supports deadrise/transom angles from 0° to 70°. Ensure the mounting location provides a clear view of the water beneath the boat and is free from obstructions that could interfere with the sonar signal.




Image: The Garmin Panoptix PS30 Down Transducer, shown with its black main body, attached to a silver-colored metal transom mounting bracket. Two black cables extend from the transducer, indicating power and network connections. The bracket features multiple elongated holes for secure attachment to a boat's transom.

Wiring:

The transducer connects via Ethernet for data transmission and includes a 15 ft. power cable for electrical supply. Connect the Ethernet cable to a compatible Garmin chartplotter or sonar module and the power cable to a suitable 12V DC power source on your vessel, ensuring proper fusing.

Operating the Transducer

The Panoptix PS30 transducer provides dynamic real-time sonar views. Access these views through your connected Garmin display unit.

Available Views:

- **LiveVu Down:** Provides real-time moving sonar images directly below your boat. This view allows you to observe fish and bait swimming, and even track your lure's movement as you reel it in.
- **RealVu 3-D Down:** Displays a 3-D representation of the area directly beneath your boat while stationary. It shows a history of a single sonar sweep, providing a detailed snapshot of the underwater environment.
- **RealVu 3-D Historical:** Designed for use while your boat is moving, this view creates a 3-D historical record of the entire water column you have passed over. It shows the bottom, surface, and all fish targets in between.

Sonar Characteristics:

- **Frequency:** 417 kHz
- **Power Output:** 144 W

- **Beam Width:** 120°x90° Max
- **Maximum Depth:** 300 ft.

Adjust sonar settings such as gain, range, and color palette on your connected display unit to optimize the sonar image for current water conditions and fishing preferences.

Maintenance

Regular maintenance ensures the longevity and performance of your Panoptix PS30 transducer.

Cleaning:

After each use in saltwater, rinse the transducer and mounting bracket with fresh water to prevent salt buildup and corrosion. Periodically clean the transducer face with mild soap and water to remove marine growth, dirt, or oil that could impede sonar performance. Avoid abrasive cleaners or solvents.

Inspection:

Regularly inspect the transducer cable for any signs of wear, cuts, or kinks. Check the mounting hardware for tightness and corrosion. Ensure the transducer is securely fastened and properly aligned.

Troubleshooting

If you experience issues with your Panoptix PS30 transducer, consider the following common troubleshooting steps:

- **No Sonar Image:**
    - Verify all cable connections (power and Ethernet) are secure and free from damage.
    - Check the power supply to the display unit and transducer.
    - Ensure the transducer is properly selected as the active sonar source on your display unit.
- **Poor or Intermittent Image:**
    - Clean the transducer face to remove any fouling or air bubbles.
    - Check for obstructions near the transducer that might be blocking the sonar signal.
    - Adjust sonar settings (gain, range) on your display unit.
    - Ensure the transducer is correctly mounted and submerged in water.
- **Incorrect Depth Readings:**
    - Verify the transducer is fully submerged and not experiencing aeration.
    - Check for any debris or marine growth on the transducer face.

For persistent issues, consult the full Garmin support documentation or contact Garmin customer service.

Specifications

Feature	Specification
Model Number	010-01284-00
Frequency	417 kHz

Feature	Specification
Power Output	144 W
Beam Width	120°x90° Max
Maximum Depth	300 ft.
Number of Pins	Ethernet
Power Cable Length	15 ft.
Ethernet Cable Length	30 ft.
Supported Deadrise/Transom Angles	0°-70° transom
Item Weight	6.03 pounds (2.74 Kilograms)
Product Dimensions	11.02 x 11.02 x 11.02 inches
Connectivity Technology	Ethernet
Special Feature	Motion Sensor

Warranty and Support

For information regarding the product warranty, please refer to the documentation included with your Panoptix PS30 transducer or visit the official Garmin website. For technical support, troubleshooting assistance, or service inquiries, please contact Garmin customer support directly.
Garmin Support: www.garmin.com/support

© 2025 Garmin International, Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question