Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 492932

Briggs & Stratton Genuine OEM 492932 Oil Filter Instruction Manual

Model: 492932 | Part Numbers: 492932, 492932S

Introduction

This manual provides essential information for the proper installation and maintenance of your Briggs & Stratton Genuine OEM 492932 Oil Filter. This high-capacity oil filter is designed to meet the rigorous demands of modern engines, ensuring optimal performance and protection under various operating conditions and temperatures. Regular replacement of the oil filter is crucial for maintaining engine health and longevity.

Safety Information

- Always wear appropriate personal protective equipment, such as gloves and eye protection, when handling engine oil and filters.
- Ensure the engine is cool and turned off before beginning any maintenance. Disconnect the spark plug wire to prevent accidental starting.
- Dispose of used oil and filters responsibly according to local environmental regulations. Do not pour used oil down drains or onto the ground.
- Avoid skin contact with used engine oil, as it may contain harmful contaminants. Wash hands thoroughly after handling.
- Keep children and pets away from the work area.

Installation

Follow these steps to replace your Briggs & Stratton oil filter. This process is generally straightforward and can be performed with basic tools or by hand.

1. **Prepare the Engine:** Ensure the engine is cool and turned off. Place a drain pan beneath the oil filter to catch any oil spills.
2. **Remove Old Filter:** Unscrew the old oil filter counter-clockwise. A filter wrench may be needed if it is too tight. Be prepared for some oil to drain out.

3. **Clean Mounting Surface:** Wipe the engine's oil filter mounting surface clean with a rag to remove any old gasket material or debris.
4. **Prepare New Filter:** Apply a thin film of clean engine oil to the rubber gasket of the new Briggs & Stratton 492932 oil filter. This pre-lubrication helps ensure a proper seal and easier removal next time.
5. **Install New Filter:** Screw the new filter onto the engine by hand until the gasket makes contact with the mounting surface. Then, tighten it an additional 1/2 to 3/4 turn. Do not overtighten. The process involves hand-tightening the filter until snug.
6. **Check for Leaks:** Add the recommended amount of fresh engine oil to the engine. Start the engine and let it run for a few minutes. Check for any oil leaks around the new filter. If leaks are present, turn off the engine and tighten the filter slightly more.



Image: The Briggs & Stratton Genuine OEM 492932 Oil Filter, showing the part number 492932S on the packaging and the filter itself with its gasket.

Maintenance

Regular oil filter replacement is a critical part of engine maintenance. Refer to your engine's owner's manual for specific service intervals. Generally, it is recommended to replace the oil filter at least once per mowing season or every 50 hours of operation, whichever comes first. Always replace the oil filter when changing the engine oil.

Troubleshooting

While oil filters themselves rarely malfunction, issues related to oil filtration can indicate other engine problems. If you experience any of the following, consult your engine's service manual or a qualified technician:

- **Low Oil Pressure:** Can be caused by a severely clogged filter, incorrect oil type, or other engine issues.
- **Excessive Engine Wear:** A compromised filter can lead to contaminants circulating in the oil, causing premature wear.
- **Oil Leaks:** Ensure the filter is properly tightened and the gasket is seated correctly.

Specifications

Feature	Detail
Brand	Briggs & Stratton
Model Number	492932
Part Numbers	492932, 492932S
Material	Plastic (housing), Filter Media (internal)
Thread Size	7/8-14 inch
Item Weight	Approximately 7 ounces (single filter)
Product Dimensions (L x W x H)	Approximately 1 x 1 x 1 inches (per filter)
Vehicle Service Type	Lawn Mower
UPC	706433455768, 714602343006

Compatibility

The Briggs & Stratton Genuine OEM 492932 Oil Filter is compatible with a wide range of Briggs & Stratton engines. Please verify your engine's specific requirements against the part numbers listed below or consult your engine's owner's manual for exact compatibility.
Compatible with engine models including, but not limited to:

- 104772-0101-01, 104772-0110-01, 104772-0111-01, 104772-0113-01, 104772-0114-01, 104772-0115-01, 104772-0116-01, 104772-0117-01, 104772-0118-01, 104772-0119-01, 104772-0120-01, 104772-0120-02, 104772-0121-01, 104772-0122-99, 104772-0123-01, 104772-0124-01, 104772-0125-01, 104772-0125-02, 104772-0127-01, 104772-3101-01, 104772-3112-01, 104772-3112-02, 104772-4003-01, 104772-4004-01, 104772-4004-03, 104772-4005-01, 104772-4024-01, 104772-4025-01, 104772-4044-01, 104772-4045-01, 104772-4045-02
- 104777-0102-01, 104777-0112-01, 104777-3102-01, 104777-4006-01, 104777-4006-02, 104777-4007-01
- 261777-0126-01, 261777-0126-02, 261777-0130-01, 261777-0144-01, 261777-0145-01
- 290442-0023-01, 290442-0023-02, 290442-0031-01, 290442-0031-02, 290442-0031-99, 290442-0034-01,

290442-0034-99, 290442-0040-01, 290442-0040-02, 290442-0043-01, 290442-0043-02, 290442-0044-01, 290442-0047-01, 290442-0047-02, 290442-0053-01, 290442-0053-02, 290442-0057-01, 290442-0057-02, 290442-0059-01, 290442-0060-01, 290442-0061-01, 290442-0061-03, 290442-0062-01, 290442-0062-02, 290442-0063-99, 290442-0070-01, 290442-0070-02, 290442-0084-99, 290442-0085-99, 290442-0102-01, 290442-0122-01, 290442-0123-01, 290442-0307-01, 290442-0311-99, 290442-0318-01, 290442-0320-01, 290442-0320-03, 290442-0329-99, 290442-0330-99, 290442-0340-01, 290442-0340-02, 290442-0343-99, 290442-0344-99, 290442-0347-01, 290442-0347-02, 290442-0347-03, 290442-0347-05, 290442-0350-01, 290442-0353-01, 290442-0357-01, 290442-0357-02, 290442-0359-01, 290442-0360-01, 290442-0360-03, 290442-0361-01, 290442-0361-03, 290442-0362-99, 290442-0363-01

Warranty and Support

As a genuine OEM part, this Briggs & Stratton oil filter is manufactured to high standards. For specific warranty information, please refer to the documentation provided with your engine or contact Briggs & Stratton customer support directly. Genuine parts ensure compatibility and maintain the validity of your engine's warranty.
For further assistance or to locate authorized service centers, visit the officialBriggs & Stratton website or contact their customer service department.

© 2026 Briggs & Stratton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B011VS0K5Y

More documents and user manuals: **https://manuals.plus/**