Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Secura B01261VEOG

Secura Electric Wine Opener User Manual

Model: B01261VEOG

Introduction

Thank you for choosing the Secura Electric Wine Opener. This automatic electric wine bottle corkscrew is designed for effortless and quick cork removal, making it an ideal tool for any wine enthusiast. Please read this manual carefully before using the product to ensure proper operation and maintenance.

This opener is compatible with most wine bottle sizes and can open up to 30 bottles on a single charge.

Package Contents

Please ensure all items are present in the package:

- Secura Electric Wine Opener (Stainless Steel)
- Foil Cutter
- Charging Stand
- Power Charging Socket (100-240V)



Image: An overview of the package contents, including the electric wine opener with its 'Up' and 'Down' switches, the foil cutter, the charging stand, and the power charging socket (100-240V).

Setup and Charging

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place Charging Stand:** Position the charging stand on a stable, flat surface. It is recommended to keep the charging base near your wine storage area for convenience.
3. **Connect Power:** Plug the power charging socket into a standard electrical outlet (100-240V). Connect the charging cable to the charging stand.
4. **Charge Opener:** Place the electric wine opener onto the charging stand. The indicator light on the opener will illuminate, indicating that it is charging. Allow the unit to fully charge before first use. A full charge allows for opening up to 30 bottles.
5. **Maintenance Charging:** If the wine opener is not in regular use, charge it every three months to maintain battery health.



Image: The Secura Electric Wine Opener, shown with its charging base, foil cutter, and several removed corks, highlighting its sleek stainless steel design.

Operating Instructions

Follow these simple steps to open a wine bottle:

1. **Remove Foil:** Use the included foil cutter to remove the foil seal from the top of the wine bottle. Place the cutter on top of the bottle, squeeze, and twist to cut the foil cleanly.
2. **Position Opener:** Place the electric wine opener vertically on top of the wine bottle, ensuring the corkscrew is centered over the cork. Hold the bottle firmly with one hand and the opener with the other.
3. **Extract Cork:** Press and hold the "Down" button (lower button) on the opener. The corkscrew will automatically rotate and penetrate the cork, then pull it out of the bottle. Release the button once the cork is fully extracted.

4. **Release Cork:** To release the cork from the opener, press and hold the "Up" button (upper button). The corkscrew will rotate in the opposite direction, releasing the cork.



Image: A visual guide demonstrating the four simple steps to operate the Secura Electric Wine Opener: cutting the foil, placing the opener vertically, pressing the 'Down' button to extract the cork, and pressing the 'Up' button to release it.



Image: This image illustrates the ease of use of the Secura Electric Wine Opener compared to traditional, often difficult or dangerous, uncorking methods. It highlights that uncorking is easy, takes 6 seconds, and has a long-lasting battery.

Care and Maintenance

- **Cleaning:** To clean the exterior of the wine opener and charging stand, wipe them with a soft, damp cloth. Do not immerse the unit in water or any other liquid.
- **Corkscrew Cleaning:** If cork particles accumulate around the corkscrew, use a small brush or cloth to gently remove them. Ensure the unit is turned off and unplugged before cleaning.
- **Storage:** Store the wine opener and charging stand in a cool, dry place when not in use. Keep the unit charged as per the setup instructions to prolong battery life.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh detergents, as these may damage the finish or internal components.

Troubleshooting

Problem	Possible Cause	Solution
Opener does not turn on or operate.	Battery is low or depleted.	Place the opener on the charging stand and ensure it is properly connected to power. Allow it to charge fully.
Cork is not extracted or only partially extracted.	Opener not positioned vertically; corkscrew not centered; cork is synthetic or unusually dense.	Ensure the opener is held perfectly vertical and centered over the cork. Apply gentle, steady pressure. For synthetic corks, the process might take slightly longer. Ensure battery is fully charged.
Cork does not release from the opener.	"Up" button not pressed or held long enough; cork is stuck.	Press and hold the "Up" button firmly until the cork is fully released. If it's still stuck, gently twist the cork while pressing the button.
Foil cutter does not remove foil cleanly.	Foil cutter not positioned correctly or not enough pressure applied.	Ensure the foil cutter is placed firmly on the bottle neck and rotated completely around the bottle with sufficient pressure.

Specifications

Brand: Secura

Model: B01261VEOG

Material: Stainless Steel

Color: Silver

Finish Type: Brushed

Item Weight: 1.2 Pounds

Product Dimensions: 11"L x 4.92"W

Input Voltage: 100-240V (Wide range)

Battery Life: Opens up to 30 bottles on a single charge

EU Spare Part Availability Duration: 12 Months

UPC: 638339650261, 791507556502, 638339651282



Image: This image shows the dimensions of the Secura Electric Wine Opener (11 inches tall, 4.92 inches wide) and indicates its ability to open up to 30 wine bottles on a single charge.

Warranty and Customer Support

Secura offers a **12-month warranty** for this product, covering manufacturing defects and malfunctions under normal use. For any questions, concerns, or technical assistance, please contact our friendly customer service team. You can find more information and contact details on the official Secura store page:Secura Store on Amazon.

© 2023 Secura. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01261VEOG

More documents and user manuals: **https://manuals.plus/**