Manuals+

Q & A | Deep Search | Upload

Lenovo GX30J39644

Lenovo 500 Wireless Mouse (GX30J39644) User Manual

Model: GX30J39644

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Lenovo 500 Wireless Mouse, model GX30J39644. This wireless mouse offers a sleek design and reliable 2.4GHz wireless connectivity for seamless use with your computer.

Image: The Lenovo 500 Wireless Mouse in silver, showcasing its ergonomic design.

Key Features:

- Ergonomic design for comfort and portability.
- 1000 DPI optical sensor for precise tracking.
- 2.4GHz wireless technology with a micro USB receiver.
- Three buttons: Left click, Right click, and a standard scroll wheel with click function.
- Durable buttons with a life expectancy of 3 million clicks.

Package Contents

Please check the package contents to ensure all items are present:

- Lenovo 500 Wireless Mouse (GX30J39644)
- USB Receiver (typically stored inside the mouse)
- AA Batteries (2 included)
- Quick Start Guide (this document)

Setup

1. Battery Installation

1. Locate the battery compartment cover on the underside of the mouse.
2. Slide or lift the cover to open the compartment.
3. Insert the two AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

2. Connecting the USB Receiver

1. The USB receiver is typically stored inside the battery compartment or a dedicated slot on the mouse for safekeeping during transport. Remove the receiver.
2. Plug the USB receiver into an available USB port on your computer.
3. Your operating system should automatically detect and install the necessary drivers. This may take a few moments.

3. Powering On

Locate the power switch on the underside of the mouse. Slide the switch to the "ON" position. The mouse should now be ready for use.

Operating the Mouse

The Lenovo 500 Wireless Mouse features standard controls for intuitive navigation.

- **Left Click:** Use the left button for selecting items, opening files, and executing commands.
- **Right Click:** Use the right button to access context menus and additional options.
- **Scroll Wheel:** Roll the scroll wheel up or down to navigate through documents and web pages. Press the scroll wheel to activate middle-click functions, which can vary by application.

The mouse operates at 1000 DPI (dots per inch), providing a balance of speed and precision for general computing tasks.

Maintenance

Cleaning

To maintain optimal performance and appearance, clean your mouse regularly.

- Ensure the mouse is powered off before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Wipe the surface of the mouse gently. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.

Battery Replacement

When the mouse performance degrades or it stops responding, the batteries may need replacement.

1. Turn off the mouse using the power switch.
2. Open the battery compartment cover.
3. Remove the old AA batteries.
4. Insert new AA batteries, observing the correct polarity.
5. Close the battery compartment cover and turn the mouse back on.
6. Dispose of used batteries according to local regulations.

Troubleshooting

If you encounter issues with your Lenovo 500 Wireless Mouse, try the following solutions:

Problem	Solution
Mouse not responding or cursor not moving.	1. Ensure the mouse is powered on. 2. Check battery levels and replace if necessary. 3. Ensure the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port. 4. Move the mouse closer to the USB receiver to rule out interference. 5. Restart your computer.
Intermittent connection or lag.	1. Ensure there are no large metal objects or other wireless devices (e.g., Wi-Fi routers, cordless phones) between the mouse and the receiver that could cause interference. 2. Try plugging the USB receiver into a different USB port, preferably one on the front of your computer or via a USB extension cable to bring it closer to the mouse. 3. Replace batteries.
Buttons or scroll wheel not working correctly.	1. Check for physical obstructions or debris around the buttons or scroll wheel. 2. Restart your computer. 3. Reinstall mouse drivers (if applicable, usually automatic for plug-and-play devices).

Specifications

Feature	Detail
Model Number	GX30J39644
Brand	Lenovo
Connectivity	2.4 GHz Wireless (USB Receiver)
Movement Detection	Laser
DPI	1000 dpi
Number of Buttons	3 (Left, Right, Scroll Wheel Click)
Button Life	3 million clicks
Power Source	2 x AA Batteries
Dimensions (LxWxH)	2.5 x 1.5 x 4 inches (6.35 x 3.81 x 10.16 cm)
Weight	8 ounces (approx. 227 grams)
Color	Silver
Operating System Compatibility	Linux (and generally Windows/macOS for standard USB mice)

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Lenovo support website.
Lenovo Support Website: support.lenovo.com
Keep your proof of purchase for warranty claims.

© 2023 Lenovo. All rights reserved.