Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXIBOOK LBOXA500

LEXIBOOK Playdroid TV Motion Wireless Remote (LBOXA500) Instruction Manual

Model: LBOXA500

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your LEXIBOOK Playdroid TV Motion Wireless Remote (Model LBOXA500). Please read this manual thoroughly before using the product to ensure safe and optimal performance. This remote is designed to enhance your gaming experience with the Playdroid TV (LBOX500) system, offering motion detection capabilities for interactive games.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- **Battery Safety:** Use only the specified battery type (2 x AAA Alkaline). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity (+/-). Remove batteries if the remote will not be used for an extended period. Dispose of used batteries responsibly.
- **Choking Hazard:** This product contains small parts (batteries). Keep out of reach of small children to prevent accidental ingestion.
- **Water and Moisture:** Do not expose the remote to water, moisture, or extreme temperatures. This can cause damage or malfunction.
- **Impact:** Avoid dropping or subjecting the remote to strong impacts, as this may damage internal components.
- **Cleaning:** Clean the remote with a soft, dry cloth only. Do not use liquid cleaners or abrasive materials.

3. Package Contents

Ensure all items are present in your package:

- 1 x LEXIBOOK Playdroid TV Motion Wireless Remote (LBOXA500)
- Instruction Manual (this document)

Note: 2 x AAA batteries are required and not included in the package.



Figure 3.1: Product packaging for the LEXIBOOK Playdroid TV Motion Wireless Remote. The image displays the remote control and various game screenshots on the box, indicating its use with a gaming system.

4. Setup

4.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or unclip the cover to open the compartment.
3. Insert two (2) AAA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

4.2. Connecting to Playdroid TV (LBOX500)

The Playdroid TV Motion Wireless Remote is designed to connect wirelessly to your Playdroid TV console (LBOX500). Refer to your Playdroid TV console's manual for specific pairing instructions. Generally, the process involves:

- Ensure your Playdroid TV console is powered on.
- Press the power button on the remote to activate it.
- Follow the on-screen prompts on your TV, or consult the Playdroid TV manual for pairing mode activation on the console and remote.
- Once successfully paired, the remote's indicator light (if present) will confirm connection.

5. Operating Instructions

5.1. Remote Control Layout and Functions





Figure 5.1: Front view of the LEXIBOOK Playdroid TV Motion Wireless Remote. This image highlights the various buttons and their layout, including directional controls, action buttons, and system functions.

The remote features several buttons for navigation and gameplay:

- **Power Button ( ):** Turns the remote and potentially the Playdroid TV console on/off.
- **Directional Pad (Up, Down, Left, Right arrows):** Used for menu navigation and in-game movement.
- **OK Button:** Confirms selections or performs actions.
- **Back/Return Button (↩):** Returns to the previous screen or menu.
- **Volume Buttons (/):** Adjusts the volume of the Playdroid TV.
- **Home Button ( ):** Returns to the main menu of the Playdroid TV.
- **A, B, X, Y Buttons:** Action buttons used for various in-game functions, similar to standard game controllers.
- **Cursor Button (↖):** Activates or deactivates the on-screen cursor for point-and-click interactions.

5.2. Motion Detection Gameplay

The remote's primary feature is its motion detection capability, allowing for immersive gameplay in compatible titles. Games such as tennis, dart, bowling, and archery utilize physical movements of the remote to control in-game actions.

- **Tennis:** Swing the remote like a racket to hit the ball.
- **Dart:** Mimic a throwing motion to aim and release darts.
- **Bowling:** Perform a bowling swing to roll the ball down the lane.
- **Archery:** Simulate drawing and releasing a bowstring to shoot arrows.

Always ensure you have adequate space around you when playing motion-controlled games to avoid injury or damage to surroundings.



Figure 5.2: The LEXIBOOK Playdroid TV Motion Wireless Remote surrounded by various game screenshots, illustrating the types of interactive games that can be played using its motion detection features.

5.3. Connecting Multiple Remotes

The Playdroid TV system supports connecting up to two (2) remotes simultaneously. This allows for multiplayer gaming experiences. To connect a second remote, repeat the pairing process described in Section 4.2 for the additional remote.

6. Maintenance

6.1. Cleaning

To clean your remote, gently wipe the surface with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish or internal components.

6.2. Battery Replacement

When the remote's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in Section 4.1. Always replace both AAA batteries at the same time.

6.3. Storage

If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store the remote in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

- **Remote not responding:**
  - Check if batteries are correctly inserted and not depleted. Replace if necessary.
  - Ensure the remote is within range of the Playdroid TV console.
  - Attempt to re-pair the remote with the Playdroid TV console (refer to Section 4.2).
- **Motion detection issues:**
  - Ensure the remote has a clear line of sight to the Playdroid TV console or any required sensor.
  - Recalibrate the remote if the game offers this option.
  - Check for any obstructions or interference in the play area.
- **Buttons not working:**
  - Clean the remote surface, especially around the buttons, to remove any debris.
  - Replace batteries.

8. Specifications

Model Number	LBOXA500
Product Dimensions (LxWxH)	15.49 x 5.99 x 1.6 cm
Batteries Required	2 x AAA Alkaline (not included)
Controller Type	Button Control, Motion Control
Manufacturer	Lexibook America, Inc.

9. Warranty and Support

9.1. Warranty Information

This product comes with a**90-day warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9.2. Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Lexibook customer support. Refer to the official Lexibook website or product packaging for the most current contact information.

© 2023 LEXIBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B014W6ZGLU

More documents and user manuals: **https://manuals.plus/**