Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lionsgate 35219353

Burnt DVD Instruction Manual

Model: 35219353

1. Product Overview

The **Burnt DVD**, Model 35219353, is a cinematic drama from Lionsgate, directed by John Wells and starring Bradley Cooper and Sienna Miller. This DVD provides a standard definition viewing experience of the film.



Image: Front cover of the Burnt DVD. It displays the movie title "BURNT" prominently, with "BRADLEY COOPER" above it. Below the title, several cast members, including Bradley Cooper and Sienna Miller, are shown in chef attire within a kitchen setting.

2. Setup Instructions

1. **Connect your DVD Player:** Ensure your DVD player is properly connected to your television or display device. Refer to your DVD player's instruction manual for specific connection details (e.g., HDMI, RCA cables).
2. **Power On:** Turn on your television and DVD player. Select the correct input source on your television.
3. **Insert the DVD:** Gently open the DVD player tray or slot. Hold the**Burnt DVD** by its edges to avoid touching the playback surface. Insert the DVD with the label side facing up into the tray or slot.
4. **Close Tray:** Close the DVD player tray or allow the player to automatically draw the disc in.

3. Operating the DVD

3.1 Basic Playback

- **Start Playback:** After inserting the DVD, the movie should begin playing automatically or display a main menu. Use your DVD player's remote control to navigate the menu and select "Play Movie" if necessary.
- **Play/Pause:** Press the **PLAY** or **PAUSE** button on your remote to control playback.
- **Stop:** Press the **STOP** button to end playback and return to the main menu or stop the disc.
- **Fast Forward/Rewind:** Use the **FFWD** and **REW** buttons to quickly scan through the movie.
- **Chapter Selection:** Use the **NEXT/PREVIOUS CHAPTER** buttons to skip between chapters.

3.2 Language and Subtitle Selection

The **Burnt DVD** supports multiple audio languages and subtitles. Access these options through the DVD's main menu or by pressing the **AUDIO** and **SUBTITLE** buttons on your remote control during playback.

- **Audio Languages:** English, Spanish (Dubbed)
- **Subtitles:** Check the DVD packaging for available subtitle options.

▶ **Watch video online**
Burnt [Blu-ray]

Video: Official trailer for the movie Burnt. This video provides a preview of the film's content, showcasing key scenes and actors, and is intended to give viewers an idea of the movie's genre and style.

4. Maintenance and Care

- **Handling:** Always hold the DVD by its outer edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the DVD becomes dirty or smudged, gently wipe the playback surface with a soft, lint-free cloth. Wipe from the center outwards in a straight line, not in a circular motion. Do not use abrasive cleaners or solvents.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity. This helps prevent scratches and warping.

5. Troubleshooting

- **Disc Not Playing:**
  - Ensure the DVD is inserted correctly (label side up).
  - Check if the disc is clean and free of scratches.
  - Verify your DVD player is set to the correct region code for the disc.

- Try playing another DVD to confirm the player is functioning.

- **Skipping or Freezing:**
  - Clean the disc as described in the Maintenance section.
  - Ensure the DVD player is on a stable surface to prevent vibrations.

- **No Audio/Video:**
  - Check all cable connections between the DVD player and your TV.
  - Ensure your TV is on the correct input source.
  - Verify the audio settings on your DVD player and TV.

For persistent issues, consult your DVD player's instruction manual or contact the manufacturer of your DVD player for support.

6. Specifications

Title	Burnt
Model Number	35219353
Brand/Studio	Lionsgate
Media Format	DVD (Anamorphic, NTSC)
Run Time	1 hour and 41 minutes
Release Date	January 26, 2016
MPAA Rating	R (Restricted)
Main Language	English
Dubbed Language	Spanish
Number of Discs	1
Product Dimensions	0.7 x 7.5 x 5.4 inches; 0.01 ounces
Director	John Wells
Actors	Bradley Cooper, Daniel Brühl, Emma Thompson, Sienna Miller, Uma Thurman

7. Warranty and Support

For information regarding the warranty of your **Burnt DVD**, please refer to the packaging or contact the retailer from whom the product was purchased. Specific warranty terms and conditions are typically provided by the distributor or manufacturer at the point of sale.
For further assistance or technical support related to the DVD content, please contact Lionsgate customer service. For issues related to your DVD player, consult your player's manufacturer.

© 2016 Lionsgate. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B017DYS7ZK

More documents and user manuals: **https://manuals.plus/**