Swifty Sharp B017K5JW9W

Swifty Sharp Cordless Motorized Knife Blade Sharpener User Manual

Model: B017K5JW9W | Brand: Swifty Sharp

1. Product Overview

The Swifty Sharp Cordless Motorized Knife Blade Sharpener is designed to provide precision sharpening for various blades and tools. It features a professional-grade sapphire stone to hone blades to a razor-sharp edge. This cordless device is ideal for maintaining the sharpness of knives, precision tools, scissors, and other household tools.



Figure 1: Swifty Sharp Cordless Motorized Knife Blade Sharpener.

2. What's Included

Your Swifty Sharp package includes:

- 1x Swifty Sharp Cordless Motorized Knife Blade Sharpener (Green)
- Built-in guide for optimal blade angle
- Professional-grade high-speed rotating sharpening stone
- Integrated catch tray for metal shavings
- User Manual (this document)



Figure 2: Swifty Sharp product packaging and contents.

3. Setup

3.1 Initial Setup and Battery Installation

The Swifty Sharp requires 2 AA batteries (not included) for operation.

1. Locate the battery compartment on the underside of the unit.
2. Open the battery compartment cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3.2 Attaching/Removing Angle Guides

The sharpener comes with a built-in guide to assist in maintaining the correct sharpening angle.

- **To Remove:** Gently push the guide backward from the front of the sharpening slot. It will detach from the unit.
- **To Attach:** Align the screw on the guide with the slot on the sharpener. Tip the guide sideways to insert the screw into the slot, then slide it forward until it clicks into place.



Figure 3: Proper knife placement using the angle guide.

4. Operating Instructions

4.1 How to Use Your Swifty Sharp

The Swifty Sharp is designed for ease of use, providing a consistent sharpening angle.

1. **Power On:** Press the power button to activate the sharpener.
2. **Blade Placement:** Place the heel of the blade into the appropriate sharpening slot (knife, scissors, or screwdriver). Ensure the blade rests against the guide for the correct angle.

3. **Sharpening Motion:** Apply light, consistent pressure and pull the blade slowly through the slot. For optimal results, aim for approximately 8 seconds per pass.
4. **Repeat:** Repeat the process 3-5 times for each side of the blade, or until desired sharpness is achieved.
5. **Clean:** After sharpening, wipe the blade clean with a damp cloth to remove any metal shavings.

4.2 Sharpening Different Tools

- **Knives:** Use the designated knife sharpening slot. Ensure the entire blade, from heel to tip, passes through the sharpening stone.
- **Scissors:** Use the dedicated scissor sharpening slot. Open the scissors and slide one blade through at a time.
- **Screwdrivers:** Use the screwdriver sharpening slot. Insert the screwdriver tip and pull through gently.



Figure 4: Sharpening scissors with the Swifty Sharp.



Figure 5: Sharpening a screwdriver with the Swifty Sharp.

5. Maintenance

5.1 Care and Cleaning

Regular maintenance ensures the longevity and optimal performance of your Swifty Sharp.

- **Cleaning:** The integrated catch tray collects metal shavings. Periodically remove and empty the tray. Wipe the exterior of the unit with a dry or slightly damp cloth. Do not immerse the unit in water.
- **Belt Replacement:** The sharpening belts are designed for durability but will wear over time. Replacement belts are available. To replace:
  - Open the front lid of the sharpener.
  - Push down on the tensioner to release tension on the pulleys.
  - Carefully remove the old belt.
  - Place the new belt over the pulleys, ensuring it is properly seated.

    - Release the tensioner.
    - Close the front lid.
- **Storage:** Store the sharpener in a dry, safe place away from children.

Note: *Avoid using the sharpener in food preparation areas due to potential dust from the belt and steel particles.*

6. Troubleshooting

If you encounter issues with your Swifty Sharp, please refer to the following common solutions:

- **Unit Not Turning On:** Check if batteries are correctly installed and have sufficient charge. Replace batteries if necessary.
- **Poor Sharpening Results:** Ensure the blade is properly seated against the angle guide. Apply light, consistent pressure and pull the blade slowly. Check if the sharpening belt is worn and needs replacement.
- **Excessive Noise:** Ensure the sharpening belt is correctly installed and not loose.

For further assistance, please contact Swifty Sharp customer support.

7. Specifications

Material	Stone
Brand	Swifty Sharp
Color	Green
Product Dimensions	7.5"L x 5.5"W x 4.5"H
Item Weight	0.09 Kilograms (3.13 ounces)
Grit Type	Ultra Fine
Number of Items	1
Manufacturer	Swifty Sharp
Batteries	2 AA batteries required (not included)
Model Number	B017K5JW9W



Figure 6: Product dimensions of the Swifty Sharp.

8. Warranty and Support

The Swifty Sharp Cordless Motorized Knife Blade Sharpener comes with a**3-year warranty**. Please register your product on the official Swifty Sharp website to activate your warranty.

For customer support, warranty claims, or to purchase replacement parts and accessories, please visit the official Swifty Sharp website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question