Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz 2000025701

Campingaz Party Grill 600 Portable Camping Stove User Manual

Model: 2000025701

Introduction

The Campingaz Party Grill 600 is a versatile and portable all-in-one cooking solution designed for outdoor use. It offers multiple cooking surfaces, including a stove, grill, griddle, and plancha, making it ideal for camping, picnics, and other outdoor activities. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Party Grill 600.

Safety Information

WARNING: Read all instructions before operating this appliance. Failure to follow these instructions may result in fire, explosion, or serious injury.

- Use outdoors only in a well-ventilated area.
- Keep away from flammable materials.
- Ensure gas cylinders are connected correctly and securely.
- Do not leave the appliance unattended during operation.
- Keep children and pets away from the hot appliance.
- Always allow the appliance to cool completely before cleaning or storing.

Product Components

The Campingaz Party Grill 600 comes with several components for versatile cooking:

- Main unit with integrated burner
- Detachable legs
- Lockable lid with temperature gauge (can be used as an oven)

- Pan support
- Grill grate
- Reversible griddle/plancha with non-stick coating
- Water reservoir (drip tray)
- Carrying bag (polyester)



Image: The Campingaz Party Grill 600 fully assembled, showing the main unit, legs, and lid. This image illustrates the complete product setup.

Setup and Assembly

1. **Unpack Components:** Carefully remove all parts from the carrying bag.
2. **Attach Legs:** Securely attach the three detachable legs to the main unit. Ensure they click into place for stability.
3. **Install Water Reservoir:** Place the water reservoir (drip tray) into the base of the grill. Fill it with a small amount of water to collect fats and cooking juices, which aids in cleaning.
4. **Choose Cooking Surface:** Select the desired cooking surface (pan support, grill grate, or reversible griddle/plancha) and place it on the main unit.
5. **Connect Gas Cylinder:** The Party Grill 600 operates with Campingaz R904 or R907 gas cylinders. Connect the appropriate regulator and hose (sold separately) to the appliance and then to the gas cylinder. Ensure all connections are tight and leak-free.



Image: A detailed view of the gas connection point and the control knob on the Campingaz Party Grill 600. This shows where the gas cylinder connects and how to adjust the flame.

Operating Instructions

Ignition:

1. Ensure the gas cylinder is connected and the control knob is in the OFF position.
2. Turn the control knob to the maximum setting while simultaneously pressing the piezo ignition button. You should hear a click and see the burner ignite.
3. If the burner does not ignite after a few attempts, turn the knob to OFF, wait a few minutes, and try again.

Cooking Surfaces:

- **Stove:** Use the pan support for boiling water or cooking with pots and pans.
- **Grill:** Place the grill grate directly over the burner for grilling meats and vegetables.
- **Griddle/Plancha:** Use the reversible non-stick surface for frying, searing, or cooking delicate foods.
- **Oven:** Place the lid on the unit while using the grill or griddle to create an oven effect. Monitor temperature using the integrated gauge.

Adjusting Heat:

The Party Grill 600 features fully adjustable power. Rotate the control knob to increase or decrease the flame intensity as needed for your cooking requirements.



Image: A close-up view of the lid of the Campingaz Party Grill 600, highlighting the integrated temperature gauge. This gauge helps monitor the internal temperature when using the grill as an oven.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Party Grill 600.

1. **Cool Down:** Always allow the appliance to cool completely before attempting any cleaning.
2. **Empty Water Reservoir:** Dispose of the dirty water from the drip tray. Rinse the tray with soap and water.
3. **Clean Cooking Surfaces:** The pan support, grill grates, and griddle/plancha are dishwasher safe. Alternatively, clean them easily with a sponge and soapy water due to their non-stick surfaces.
4. **Wipe Down Unit:** Wipe the exterior of the main unit and legs with a damp cloth. Avoid abrasive cleaners.
5. **Storage:** Once clean and dry, all components can be stored inside the main unit. Detach the legs and secure the lid with its locking mechanism. Store in the provided carrying bag in a dry, cool place.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not ignite.	No gas flow, empty cylinder, faulty igniter, clogged burner.	Check gas cylinder level and connection. Ensure control knob is fully open. Clean burner ports if clogged. Contact customer support if igniter is faulty.
Low flame or inconsistent heat.	Low gas pressure, partially clogged burner, regulator issue.	Check gas cylinder level. Clean burner. Ensure regulator and hose are not kinked or damaged.
Gas smell.	Gas leak from connections or hose.	**IMMEDIATELY turn off gas supply.** Check all connections for leaks using soapy water (bubbles indicate a leak). Tighten connections or replace faulty parts. Do not operate if a leak is detected.

Specifications

Model: 2000025701

Power: 4000 W

Gas Consumption: 290 g/hour

Boiling Time (1L water): 3 minutes 50 seconds

Operating Time: Approximately 9 hours 30 minutes (on R907 cylinder); 6 hours 15 minutes (on R904 cylinder)

Weight: 10.72 kg

Dimensions (assembled, L x W x H): Ø 52 x 99 cm

Fuel Type: Gas (Campingaz R904/R907 cylinders)

Material: Stainless Steel (cooking surfaces with non-stick coating)

Color: Blue

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Campingaz website. Keep your proof of purchase for warranty claims.

Manufacturer: Campingaz

ASIN: B017K5OKXU

© 2024 Campingaz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B017K5OKXU

More documents and user manuals: **https://manuals.plus/**