**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Braun 81519196

# Braun PT5010 Precision Trimmer User Manual

Model: 81519196

## Introduction

The Braun precision trimmer provides you with the freedom to create a variety of looks, exactly how you want them. Two trimming combs create precise styles down to the very last millimetre while the extra small trimming attachment helps to define sharp lines and shapes.
Key features include:

- The ideal look is a matter of precision.
- Two trimming combs provide flexible, precise trimming.
- An extra small trimming element defines sharp lines.
- Washable head and combs can be easily cleaned under running water.




Figure 1: The Braun PT5010 Precision Trimmer, showcasing the device, its packaging, two trimming combs, and a stand.

## Safety Information

Please read all safety instructions carefully before using the Braun PT5010 Precision Trimmer.

- Use with caution around the eyes and ears.
- Avoid use on wet skin.
- Keep away from water sources.
- Always unplug the trimmer when not in use.
- Follow recommended cleaning and maintenance procedures.

## Setup

1. **Unpacking:** Carefully remove all components from the packaging. Ensure you have the trimmer unit, two trimming combs, and the stand.

2. **Battery Installation:** The trimmer requires 1 AAA battery (included). Open the battery compartment, insert the battery with the correct polarity (+/-), and close the compartment securely.
3. **Attaching a Trimming Comb:** Select the desired trimming comb. Align the comb with the trimmer head and gently push it until it clicks into place.




Figure 2: Components of the Braun PT5010 Precision Trimmer, including the trimmer, a AAA battery, the stand, and various trimming combs.

## Operating Instructions

1. **Turning On/Off:** Press the power button located on the trimmer body to turn the device on or off.
2. **Trimming with Combs:** For precise length trimming, attach one of the two provided combs. Gently glide the trimmer against the direction of hair growth, ensuring the comb maintains contact with the skin.
3. **Defining Sharp Lines:** For detailed styling and sharp lines, remove any attached comb. Use the extra small trimming element directly against the skin to create precise edges and shapes.



Figure 3: A user demonstrating the application of the Braun PT5010 Precision Trimmer for defining beard lines and achieving precise grooming results.



Figure 4: A detailed view of the Braun PT5010 Precision Trimmer head, showing a trimming comb securely attached, ready for use.

## Maintenance

1. **Cleaning the Head and Combs:** The trimmer head and combs are washable. After each use, remove the comb and rinse both the trimmer head and the comb under running water. Ensure the trimmer is turned off and disconnected from any power source before cleaning.
2. **Drying:** Allow all parts to air dry completely before reassembling or storing the trimmer.
3. **Storage:** Store the trimmer in its stand or a dry place away from direct sunlight and moisture.

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Trimmer does not turn on. | Battery is dead or incorrectly inserted. | Replace the AAA battery or check its polarity. |
| Poor trimming performance. | Trimmer head is clogged with hair or dull. | Clean the trimmer head and combs thoroughly. If performance does not improve, consider replacing the trimmer head if available. |
| Trimmer makes unusual noise. | Foreign object lodged in the trimming mechanism. | Turn off and inspect the trimmer head for any obstructions. Clean thoroughly. |

## Specifications

- **Model:** PT5010 (81519196)
- **Brand:** Braun
- **Power Source:** 1 AAA battery (included)
- **Product Dimensions:** 2.76 x 1.77 x 6.69 inches
- **Item Weight:** 3.17 ounces
- **Color:** Black
- **Recommended Uses:** Beard trimming, precise detailing
- **Washable:** Head and combs are washable under running water.

## Warranty and Support

For warranty information and customer support, please refer to the official Braun website or contact their customer service department. Keep your purchase receipt as proof of purchase.
**Online Support:** www.braun.com
**Manufacturer:** Procter & Gamble

© 2024 Braun. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B017LX1T58**

More documents and user manuals: **https://manuals.plus/**