Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FR376-RED

Frigidaire Retro Compact Fridge (Model FR376-RED) - Instruction Manual

1. Product Overview

This manual provides essential information for the safe and efficient operation of your Frigidaire Retro Compact Fridge, Model FR376-RED. Please read these instructions thoroughly before use and retain them for future reference.

Key Features:

- **Retro Design:** Stylish aesthetic suitable for various room settings.
- **Capacity:** 3.2 cubic feet (cu. ft.) storage.
- **Space-Saving:** Flush back design for seamless placement against walls.
- **Internal Storage:** Two glass shelves and a 2-liter door basket.
- **Beverage Dispenser:** Built-in can dispenser.
- **Chiller Compartment:** Includes a dedicated chiller section with an ice cube tray.
- **Convenience:** Integrated bottle opener.
- **Versatility:** Reversible door for flexible placement.





Front view of the Frigidaire Retro Compact Fridge in red, showcasing its classic design.



An image highlighting the 3.2 cubic feet storage capacity of the compact refrigerator.

2. Safety Information

Your safety and the safety of others are very important. Please read and follow all safety messages provided in this manual.

General Safety Precautions:

- **Electrical Safety:** Ensure the refrigerator is connected to a grounded 110-volt outlet. Do not use extension cords.
- **Ventilation:** Allow adequate space around the refrigerator for proper air circulation (at least 5 inches on sides and back).
- **Flammable Materials:** Do not store explosive substances or flammable materials inside or near the appliance.
- **Child Safety:** Supervise children near the appliance. Ensure children do not play with or climb inside the refrigerator.
- **Disposal:** Dispose of the appliance according to local regulations, especially regarding refrigerants and insulation materials.

3. Setup and Installation

Unpacking:

Carefully remove all packaging materials, including foam and adhesive tape. Inspect the refrigerator for any shipping damage. Remove any protective film from the exterior surfaces.

Placement:

Select a location that is strong enough to support the refrigerator when fully loaded. Avoid direct sunlight, heat sources (like stoves or heaters), and areas with excessive moisture. Ensure the refrigerator is placed on a level surface.

Leveling:

The refrigerator is equipped with adjustable leveling legs. Turn the legs clockwise to raise the refrigerator or counter-clockwise to lower it. Ensure the refrigerator is level to optimize performance and door sealing.

Initial Power-On:

After placement and leveling, allow the refrigerator to stand upright for at least 2-4 hours before plugging it into the power outlet. This allows the refrigerant to settle. Once plugged in, allow the unit to cool for several hours before storing food items.



This image illustrates key features of the refrigerator, including LED lighting, adjustable leveling legs for stability, quiet operation, and the option for a reversible door.



A diagram providing the precise dimensions of the Frigidaire Retro Compact Fridge for installation planning.

4. Operating Your Refrigerator

Temperature Control:

The refrigerator features an adjustable thermostat control located inside the unit. Turn the dial to your desired setting. Higher numbers typically indicate colder temperatures. Start with a medium setting and adjust as needed to achieve optimal cooling for your items.

Internal Storage:

- **Glass Shelves:** The two glass shelves are movable to accommodate items of various heights.
- **Door Basket:** The 2-liter door basket is designed for larger bottles and containers.
- **Can Dispenser:** Utilize the built-in can dispenser for convenient storage and access to canned beverages.
- **Chiller Compartment:** This section is designed for items requiring colder temperatures, such as ice cubes (using the provided tray) or small frozen goods.

Built-in Bottle Opener:

The integrated bottle opener on the side of the unit provides quick access for opening bottled beverages.

Reversible Door:

The door hinges can be reversed to allow the door to open from either the left or right side, offering flexibility in placement. Refer to the detailed instructions in the full owner's manual for the reversal procedure.



An open view of the refrigerator's interior, demonstrating its efficient organization with a freezer compartment, built-in can dispenser, movable shelving, and a 2L door basket.



Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.

The refrigerator's interior filled with various items, emphasizing its space-saving design and flush back for versatile placement.

5. Care and Maintenance

Cleaning the Interior and Exterior:

- **Interior:** Unplug the refrigerator before cleaning. Wash interior surfaces with a solution of mild soap and warm water. Rinse and dry thoroughly. Do not use abrasive cleaners or harsh chemicals.
- **Exterior:** Clean the exterior surfaces with a soft cloth dampened with mild soap and water. Dry with a soft cloth.
- **Door Gasket:** Regularly clean the door gasket to ensure a proper seal.

Defrosting the Chiller Compartment:

While the main refrigerator section features an automatic defrost system, the chiller compartment may accumulate frost. When frost buildup exceeds 1/4 inch (6 mm), manual defrosting is recommended. To defrost:

1. Unplug the refrigerator from the power outlet.
2. Remove all items from the chiller compartment and place them in another cooled area.
3. Leave the refrigerator door open to allow frost to melt naturally. Place towels at the bottom to absorb water. Do

not use sharp objects or heating devices to speed up defrosting.

4. Once defrosted, clean and dry the compartment thoroughly.
5. Plug the refrigerator back in and return items once the temperature has stabilized.

6. Troubleshooting Guide

Before contacting customer service, please review the following common issues and their solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Refrigerator is not cold enough.	Temperature control set too warm; door opened too frequently; warm food placed inside; poor ventilation.	Adjust thermostat to a colder setting; minimize door openings; allow hot food to cool before storing; ensure adequate space around unit.
Excessive noise.	Refrigerator not level; items vibrating inside; normal compressor operation.	Adjust leveling legs; rearrange items; some operational noise is normal.
Door does not close properly.	Refrigerator not level; door gasket dirty or damaged; items obstructing closure.	Level the unit; clean or inspect gasket; remove obstructions.

7. Product Specifications

- **Model Number:** FR376-RED
- **Brand:** Frigidaire
- **Capacity:** 3.2 Cubic Feet (3.0 cu. ft. Fresh Food, 0.2 cu. ft. Freezer)
- **Product Dimensions (D x W x H):** 18.5 x 21.5 x 32.5 inches
- **Item Weight:** 43.6 Pounds
- **Voltage:** 110 Volts
- **Installation Type:** Freestanding
- **Defrost System:** Automatic (main compartment)
- **Shelf Type:** Glass
- **Door Hinges:** Reversible
- **Included Components:** Owners manual, refrigerator unit

8. Warranty and Customer Support

For warranty information, please refer to the warranty card included with your product or contact Frigidaire customer support. Keep your purchase receipt as proof of purchase for any warranty claims.

If you require further assistance or have questions not covered in this manual, please contact Frigidaire customer service. Contact details can typically be found on the manufacturer's website or in the full owner's manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B019RF0FV2

More documents and user manuals: **https://manuals.plus/**