Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 2000024457

Coleman Divide+ 350 LED Flashlight User Manual

Model: 2000024457

1. Introduction

Thank you for choosing the Coleman Divide+ 350 LED Flashlight. This durable and versatile flashlight is designed for reliable performance in various conditions. It features Coleman's innovative BatteryLock™ system, which prevents battery drain and extends battery life. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your flashlight.



Figure 1: Coleman Divide+ 350 LED Flashlight overview.

2. Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Eye Safety:** Do not stare directly into the LED light. The intense light can cause temporary vision impairment or permanent eye damage.
- **Children:** Keep this flashlight out of reach of children. This is not a toy.
- **Battery Safety:**
  - Always insert batteries correctly, observing polarity (+/-) markings.
  - Do not mix old and new batteries, or different types of batteries.

- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.
- Never dispose of batteries in fire; they may explode.

- **Heat:** The flashlight head may become warm during prolonged use. This is normal.

3. Package Contents

Verify that all items are present in your package:

- Coleman Divide+ 350 LED Flashlight
- 4 x AAA DURACELL Batteries

4. Setup: Battery Installation

Your Coleman Divide+ 350 LED Flashlight requires 4 AAA batteries (included).

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the 4 AAA batteries into the battery compartment, ensuring correct polarity (+ and -) as indicated inside the flashlight body.
3. Replace the tail cap by screwing it clockwise until it is securely tightened. Do not overtighten.

5. Operating Instructions

5.1 Power On/Off and Mode Selection





Figure 2: Flashlight body showing the power button and BatteryLock indicator.

- **To Turn On:** Press the power button located on the side of the flashlight. The flashlight will turn on in High mode (350 lumens).
- **To Change Mode:** While the flashlight is on, press the power button again to switch to Low mode (35 lumens).
- **To Turn Off:** Press the power button a third time to turn the flashlight off.

5.2 BatteryLock™ System

The BatteryLock™ system prevents parasitic drain on your batteries when the flashlight is stored, ensuring power is available when you need it.

- **To Engage BatteryLock™ (Storage Mode):** Twist the flashlight head counter-clockwise until a red ring becomes visible between the head and the body. In this position, the battery circuit is completely disengaged, preventing any power drain.



Figure 3: Engaging the BatteryLock™ system. The red ring indicates the circuit is open.

- **To Disengage BatteryLock™ (Ready for Use):** Twist the flashlight head clockwise until the red ring is no longer visible. The flashlight is now ready for normal operation.



Figure 4: Disengaging the BatteryLock™ system. The red ring is hidden, and the flashlight is ready for use.

6. Maintenance

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the flashlight in a cool, dry place. For long-term storage (more than a few weeks), engage the BatteryLock™ system or remove the batteries to prevent potential leakage and damage.
- **Battery Replacement:** Replace all batteries simultaneously with new ones of the same type and brand.

7. Troubleshooting

Problem	Possible Cause	Solution
Flashlight does not turn on.	Batteries are dead or incorrectly inserted. BatteryLock™ system is engaged.	Check battery polarity and replace if necessary. Disengage BatteryLock™ by twisting the head clockwise until the red ring is hidden.
Light is dim or flickers.	Low battery power.	Replace all batteries with new ones.
Flashlight head feels loose.	Head is in BatteryLock™ position.	Twist the head clockwise until it is fully tightened and the red ring is no longer visible.

8. Specifications

Feature	Specification
Model Number	2000024457

Feature	Specification
Light Source	LED
Brightness (High/Low)	350 lumens / 35 lumens
Beam Distance (High/Low)	300 meters / 100 meters
Run Time (High/Low)	2 hours / 50 hours
Power Source	4 x AAA Batteries (included)
Material	Anodized Aluminum, Plastic
Color	Black-Silver-Red
Dimensions (L x W x H)	20.1 x 4.8 x 4.8 cm
Special Features	BatteryLock™ System, IPX4 Water Resistant

9. Warranty and Support

Coleman products are manufactured to high-quality standards and are backed by a limited warranty. For specific warranty details, please refer to the warranty information provided at the time of purchase or visit the official Coleman website. If you have any questions or require technical assistance, please contact Coleman customer support through their official website or the contact information provided with your product.

© 2023 Coleman. All rights reserved.

Coleman® and BatteryLock™ are registered trademarks of The Coleman Company, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01ABJHDRC

More documents and user manuals: **https://manuals.plus/**