Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briggs & Stratton 846483

Briggs & Stratton 846483 Hose Clamp Instruction Manual

Genuine Original Equipment Manufacturer (OEM) Part

1. Introduction

This manual provides essential information for the proper installation and maintenance of your Briggs & Stratton 846483 Hose Clamp. This is a genuine Original Equipment Manufacturer (OEM) part designed for specific applications within Briggs & Stratton equipment. Please read these instructions carefully before proceeding with installation.

2. Safety Information

WARNING: Always wear appropriate personal protective equipment (PPE) such as gloves and eye protection when working with machinery and parts. Ensure the equipment is turned off and cooled down before attempting any installation or maintenance.

California Proposition 65 Warning: This product can expose you to chemicals which are known to the State of California to cause cancer and reproductive harm. For more information, go to www.P65Warnings.ca.gov.

3. Package Contents

- 1x Briggs & Stratton 846483 Hose Clamp

4. Installation (Setup)

The Briggs & Stratton 846483 Hose Clamp is designed to secure hoses onto fittings, preventing leaks in fluid or air systems. Follow these general steps for proper installation:

1. **Preparation:** Ensure the hose and fitting surfaces are clean and free from debris or damage.
2. **Positioning the Clamp:** Slide the hose clamp over the end of the hose before attaching the hose to the fitting.
3. **Attaching the Hose:** Push the hose firmly onto the fitting, ensuring it is fully seated.
4. **Securing the Clamp:** Position the hose clamp over the area where the hose covers the fitting. Use an appropriate tool (e.g., screwdriver or nut driver, depending on clamp type) to tighten the clamp screw. Tighten until the hose is securely gripped by the fitting, but avoid over-tightening, which can damage the hose or clamp.

5. **Verification:** After tightening, gently pull on the hose to confirm it is securely attached and does not slip.



Image 1: The Briggs & Stratton 846483 Hose Clamp. This image shows the typical design of the clamp, used for securing hoses to fittings.

5. Operation

Once properly installed, the hose clamp operates by maintaining a tight seal between the hose and the fitting. This prevents fluid or air leakage from the connection point during equipment operation. No further user interaction is required for its operation beyond initial installation.

6. Maintenance

Regular inspection of the hose clamp and hose connection is recommended to ensure continued performance and prevent potential issues:

- **Visual Inspection:** Periodically check the clamp for signs of corrosion, damage, or deformation. Ensure the hose itself is not cracked, hardened, or swollen near the clamp.
- **Tightness Check:** Gently attempt to rotate the hose on the fitting. If it moves easily, the clamp may need to be re-tightened. Do not over-tighten.
- **Leak Detection:** During equipment operation, check for any signs of fluid or air leaks around the hose connection.
- **Replacement:** If the clamp shows significant wear, damage, or if leaks persist after re-tightening, replace the clamp with a new Briggs & Stratton 846483 OEM part.

7. Troubleshooting

Most issues related to a hose clamp involve leakage. Here are common troubleshooting steps:

- **Leakage at Connection:**
  - Ensure the hose is fully seated on the fitting.
  - Check if the clamp is positioned correctly over the fitting's barb or ridge.
  - Tighten the clamp screw slightly. Avoid excessive force.
  - Inspect the hose for cracks or damage under the clamp.
  - Inspect the clamp for damage or deformation.

- If issues persist, replace the hose and/or the clamp.

- **Hose Slipping Off:**
  - The clamp may not be tight enough. Re-tighten carefully.
  - The hose or fitting may be incompatible or damaged.
  - Ensure the clamp is the correct size for the hose and fitting.

8. Specifications

Attribute	Detail
Brand	Briggs & Stratton
Model Number / Part Number	846483
Item Package Quantity	1
Batteries Required	No
UPC	047282061053
ASIN	B01AFATRQ2

9. Warranty and Support

As a genuine Briggs & Stratton OEM part, this product is covered by the standard Briggs & Stratton warranty policy for replacement parts. For specific warranty details, claims, or technical support, please refer to the official Briggs & Stratton website or contact their customer service directly. Always use genuine OEM parts to ensure compatibility and maintain equipment warranty.
For further assistance, visit the official Briggs & Stratton website:www.briggsandstratton.com

© 2023 Briggs & Stratton. All rights reserved.
This manual is for informational purposes only. Briggs & Stratton reserves the right to make changes without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01AFATRQ2

More documents and user manuals: **https://manuals.plus/**