Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OLYMPIA 3128

Olympia A 330 Plus A3 Laminator User Manual

Model: 3128

Brand: OLYMPIA

Introduction

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your Olympia A 330 Plus A3 Laminator. Please read this manual thoroughly before using the device and retain it for future reference.

Safety Instructions

To ensure safe operation and prevent damage to the device or injury, please observe the following safety guidelines:

- Read all instructions before use.
- Keep the laminator away from children and pets.
- Use the device only in a dry environment. Avoid exposure to water or excessive humidity.
- Do not attempt to open or repair the laminator casing. Refer all servicing to qualified personnel.
- Unplug the laminator from the power outlet when not in use, before cleaning, or during maintenance.
- Ensure the power supply matches the specifications (230 V, 50 Hz).
- Place the laminator on a stable, flat surface with adequate ventilation around it.
- Do not laminate objects thicker than the specified film thickness or metallic items.
- In case of a jam, immediately switch off the device and use the jam release lever.

Product Overview

The Olympia A 330 Plus is an A3 laminator designed for protecting documents with a professional finish. Familiarize yourself with its main components:

- **Power Indicator Light:** Illuminates when the device is powered on.
- **Ready Indicator Light:** Illuminates when the laminator has reached the optimal operating temperature for hot

lamination.

- **Mode Switch (COLD/OFF/HOT):** Selects the desired lamination mode or turns the device off.
- **Film Entry Slot:** Where the laminating pouch with the document is inserted.
- **Film Exit Slot:** Where the laminated document emerges.
- **Jam Release Lever:** Used to manually release a jammed laminating pouch.



Figure 1: Front view of the Olympia A 330 Plus A3 Laminator, highlighting the control panel with 'READY' and 'POWER' indicator lights, and the 'COLD', 'OFF', 'HOT' mode switch. The film entry slot is also visible.



Figure 2: The Olympia A 330 Plus A3 Laminator in operation, demonstrating a document being fed through the machine for lamination. This image illustrates the device's capacity to handle A3-sized materials and its sleek design.

Setup

1. **Unpack:** Carefully remove the laminator from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Position the laminator on a flat, stable, and heat-resistant surface. Ensure there is sufficient space around the machine for proper ventilation and for documents to pass through freely.
3. **Power Connection:** Plug the power cord into a suitable electrical outlet (230 V, 50 Hz).

Operating Instructions

Hot Lamination

1. **Power On:** Switch the mode selector to the 'HOT' position. The 'POWER' indicator light will illuminate.
2. **Warm-up:** Allow approximately 2.5 minutes for the laminator to reach its operating temperature. The 'READY' indicator light will illuminate when the machine is ready for use.
3. **Prepare Document:** Place your document centrally inside a laminating pouch. Ensure the pouch is clean and free of dust. The laminator supports film thicknesses from 75 to 125 microns.
4. **Insert Pouch:** Feed the sealed edge of the laminating pouch straight into the film entry slot. The machine will automatically draw the pouch through.
5. **Collect Document:** Once the laminated document exits the machine, place it on a flat surface to cool and harden.

Cold Lamination

1. **Power On:** Switch the mode selector to the 'COLD' position. The 'POWER' indicator light will illuminate. No warm-up time is required for cold lamination.
2. **Prepare Document:** Use self-adhesive cold laminating pouches. Place your document centrally inside the pouch.
3. **Insert Pouch:** Feed the sealed edge of the cold laminating pouch straight into the film entry slot.
4. **Collect Document:** Retrieve the laminated document from the exit slot.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your laminator.

- **Cleaning:** Always unplug the laminator before cleaning. Use a soft, dry cloth to wipe the exterior of the machine. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the surface.
- **Roller Cleaning (Optional):** If you notice residue on the rollers, you can run a cleaning sheet (available separately) through the machine to remove adhesive buildup.
- **Storage:** When not in use, store the laminator in a dry, dust-free environment, away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your laminator, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Laminator does not power on.	No power supply; power cord not properly connected.	Check if the power cord is securely plugged into the laminator and the wall outlet. Test the outlet with another device.
Laminating pouch jams in the machine.	Pouch inserted incorrectly (open end first); pouch too thick; foreign object in rollers.	Immediately switch the laminator to 'OFF'. Pull the jam release lever and carefully pull the pouch out. Ensure pouches are inserted sealed edge first.
Laminated document has bubbles or is uneven.	Machine not fully warmed up; incorrect film thickness for temperature; pouch not fed straight.	Ensure the 'READY' light is illuminated before laminating. Use appropriate film thickness (75-125 microns). Feed the pouch straight and centered.
Laminator overheats and shuts down.	Continuous heavy use; poor ventilation.	Allow the machine to cool down. Ensure adequate ventilation around the laminator. The device has an automatic overheat shutdown for safety.

Specifications

- **Brand:** OLYMPIA
- **Model Number:** 3128
- **Product Dimensions (L x W x H):** 46.6 x 14.6 x 6.6 cm
- **Item Weight:** 1.3 Kilograms
- **Laminating Width:** 330 mm (A3 format)
- **Supported Film Thickness:** 75 to 125 microns

- **Warm-up Time:** Approximately 2.5 minutes
- **Laminating Speed:** 400 mm/minute
- **Power Supply:** 230 V, 50 Hz
- **Power Consumption:** 435 W, 1.9 A
- **Number of Rollers:** 2
- **Lamination Modes:** Hot and Cold
- **Safety Features:** Automatic overheat shutdown, jam release lever
- **Country of Origin:** China

Warranty and Support

The Olympia A 330 Plus A3 Laminator is designed for reliability and performance.

- **Warranty:** Spare parts availability is guaranteed for 1 year from the date of purchase. Please retain your proof of purchase for warranty claims.
- **Technical Support:** For further assistance, technical support, or inquiries regarding spare parts, please contact your retailer or the official Olympia service center. Refer to the product packaging or the Olympia website for contact details.

© 2024 OLYMPIA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I inserted a small laminating pouch into my Olympia A 330 Plus (3128) laminator and it got stuck inside. How can I fix this problem?

If a laminating pouch is stuck inside your Olympia A 330 Plus (Model 3128), follow these steps to resolve the jam: Power Off: Immediately switch the mode selector to the 'OFF' position to stop...

Read full answer

Open the live page

https://manuals.plus/asin/B01BDKZCWG

More documents and user manuals: **https://manuals.plus/**