Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LESHP LESHP071123

LESHP USB Wired Gaming Headset (Model LESHP071123) Instruction Manual

Model: LESHP071123

Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your LESHP USB Wired Gaming Headset, Model LESHP071123. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

Product Overview

The LESHP USB Wired Gaming Headset is designed for an immersive audio experience across various gaming platforms. It features a stereo microphone, noise-cancelling capabilities, and soft memory earmuffs for comfort during extended use.



Figure 1: LESHP USB Wired Gaming Headset with its inline control unit and USB connector.

Package Contents

Verify that all items are present in the package:

- LESHP USB Wired Gaming Headset (Model LESHP071123)
- Instruction Manual (this document)

Setup

Connecting to a Device

1. Locate an available USB port on your gaming console (PS3, PS4) or PC.
2. Insert the USB connector of the headset into the USB port.
3. The device should automatically detect and install the necessary drivers. This may take a few moments.
4. For optimal audio settings on PS3/PS4, navigate to your console's audio output settings and ensure the headset is selected as the primary audio output and input device. Refer to your console's user manual for specific steps.
5. For PC, verify the headset is selected as the default playback and recording device in your operating system's sound settings.



Figure 2: Connection diagram for PS4, PS3, and PC.

Operating Instructions

Adjusting the Headset

- **Headband Adjustment:** The headset features an adaptive headband with extendable arms. Gently pull the earcups downwards to extend the headband until it fits comfortably on your head.
- **Microphone Positioning:** The microphone is omnidirectional and retractable. Rotate the microphone arm downwards to position it near your mouth for clear communication. When not in use, rotate it upwards to retract it.



Figure 3: Headband adjustment using extendable arms.



Figure 4: Retractable omnidirectional microphone.

Inline Control Unit

The headset features an inline control unit for easy access to audio and microphone functions.



Figure 5: Inline control unit with indicators and buttons.

- **Microphone Indicator (Red):** Illuminates when the microphone is active.
- **Power Indicator Light (Green):** Illuminates when the headset is powered on and connected.
- **Microphone Mute Key:** Press to toggle the microphone on or off.
- **Volume Up (+):** Press to increase the headset volume.
- **Volume Down (-):** Press to decrease the headset volume.
- **Sound Mute Key:** Press to toggle the headset audio on or off.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.
- **Earmuffs:** The soft memory earmuffs are designed for comfort. Avoid puncturing or tearing the material.

Troubleshooting

Problem	Possible Cause	Solution
No sound from headset.	◦ Headset not properly connected. ◦ Volume too low or muted. ◦ Incorrect audio output settings on device.	◦ Ensure USB connector is fully inserted. ◦ Check inline control unit for mute and volume settings. ◦ Verify headset is selected as default audio output in device settings (PC) or console audio settings (PS3/PS4).
Microphone not working.	◦ Microphone muted. ◦ Incorrect audio input settings on device. ◦ Microphone arm not positioned correctly.	◦ Press the microphone mute key on the inline control unit. ◦ Verify headset is selected as default audio input in device settings (PC) or console audio settings (PS3/PS4). ◦ Ensure microphone arm is rotated down and positioned near your mouth.
Sound quality is poor.	◦ Loose connection. ◦ Interference.	◦ Reconnect the USB cable. ◦ Try a different USB port. ◦ Ensure no other devices are causing electrical interference.

Specifications

Model Name	LESHP071123
Connectivity Technology	Wired (USB)
Compatible Devices	Gaming Consoles (PS3, PS4), PC
Control Type	Volume Control, Microphone Mute, Sound Mute
Microphone Type	Omnidirectional, Retractable
Noise Control	Active Noise Cancellation
Material	Faux Leather (Earmuffs)
Item Weight	9.6 ounces (approx. 272 grams)
Package Dimensions	7.32 x 7.32 x 3.07 inches
UPC	601285034980

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official LESHP website. Keep your proof of purchase for warranty claims.

Manufacturer: LESHP
Brand Store: LESHP Official Store

© 2023 LESHP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01CS54GSG

More documents and user manuals: **https://manuals.plus/**