Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Outsunny 841-167

Outsunny Patio Recliner Chair with Flip-Up Side Table (Model 841-167) Instruction Manual

1. Safety Information

Please read and understand all safety instructions before assembling or using this product. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 400 lbs (181 kg). Exceeding this limit may cause damage to the chair or personal injury.
- **Stability:** Ensure the chair is placed on a stable, hard, and level floor surface before use. Uneven surfaces can lead to instability and tipping.
- **Assembly:** Follow all assembly instructions carefully. Improper assembly can compromise the structural integrity of the chair.
- **Operation:** Use the adjustable backrest and flip-up side table safely. Avoid sudden movements or excessive force that could lead to tipping or injury.
- **Children and Pets:** Keep children and pets away from the chair during assembly. Supervise children when they are near the chair during use.
- **Outdoor Use:** This chair is designed for outdoor use. While weather-resistant, prolonged exposure to extreme weather conditions may reduce its lifespan. Consider using a protective cover when not in use.

2. Product Overview

The Outsunny Patio Recliner Chair (Model 841-167) is an outdoor seating solution designed for comfort and convenience. It features a durable PE rattan wicker construction over a robust metal frame, complete with thick cushions and an integrated flip-up side table.



Image: Outsunny Patio Recliner Chair in an outdoor setting, showcasing its design and features.

Key Features:

- **Reclining Function:** Adjustable backrest and pop-up footrest for personalized comfort.
- **Comfortable Cushions:** Plush, 3.9-inch thick cushions for the seat, backrest, and footrest.
- **Flip-Up Side Table:** Integrated table for holding drinks, phones, or other small items.
- **Durable Construction:** Hand-woven PE rattan wicker with an all-weather build, reinforced by a powder-coated steel frame.

Dimensions:

- **Upright Dimensions:** 33.5" L x 28.25" W x 40.25" H
- **Seat Dimensions:** 22.75" W x 23.5" D
- **Seat to Floor Height:** 14.5" H
- **Net Weight:** 53 lbs
- **Weight Capacity:** 400 lbs



Image: Diagram illustrating the key dimensions of the recliner chair.

3. Setup and Assembly

Assembly of the Outsunny Patio Recliner Chair is required. Please ensure all components are present before beginning assembly. Refer to the separate assembly guide included in your packaging for detailed, step-by-step instructions and a list of all parts and hardware.

General Assembly Tips:

- Lay out all parts on a soft, clean surface to prevent scratches.
- Do not fully tighten screws until all parts are loosely assembled.
- Ensure all connections are secure before using the chair.

4. Operating Instructions

4.1 Reclining Function

The chair features an adjustable backrest and a pop-up footrest for multiple reclining positions. To recline, gently push back on the backrest while applying slight pressure with your feet to extend the footrest. To return to an upright position, lean forward and push the footrest down with your legs.



Image: Visual guide demonstrating the reclining function and footrest extension.



Image: The recliner chair with its footrest fully extended, ready for relaxation.

4.2 Flip-Up Side Table

A compact flip-up side table is integrated into the armrest. To use, gently pull the table upwards until it locks into a horizontal position. To store, press the release mechanism (if present, refer to assembly guide) and fold the table back down flush with the armrest.



Image: Detail of the convenient flip-up side table, ideal for holding small items.

5. Maintenance

5.1 Cleaning

- **Frame and Wicker:** Wipe clean with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent water spots or mildew. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushion covers are washable. Remove covers and follow the care instructions on the label. Air dry thoroughly before reattaching to prevent mildew.

5.2 Storage

- During prolonged periods of non-use or inclement weather, store cushions indoors to protect them from fading and moisture.
- Consider using a weather-resistant furniture cover for the entire chair to protect it from dust, dirt, and harsh elements.

6. Troubleshooting

6.1 Chair Feels Unstable

- Ensure all bolts and screws are securely tightened.
- Verify the chair is placed on a flat, level surface.

6.2 Reclining Mechanism Sticking

- Check for any obstructions around the mechanism.
- Ensure the mechanism is clean and free of debris. A light application of silicone-based lubricant may help if movement is stiff.

6.3 Side Table Not Operating Smoothly

- Inspect the hinges for any debris or damage.
- Ensure no objects are blocking its path when opening or closing.

7. Specifications

Feature	Detail
Brand	Outsunny
Model Name	841-167
Product Dimensions (Upright)	33.5" D x 28.25" W x 40.25" H
Seat Dimensions	22.75" W x 23.5" D
Seat Height	14.5" H

Item Weight	53 lbs
Weight Capacity	400 lbs
Material	Steel, PE Rattan Wicker, Polyester (Cushions)
Color	Beige, Cream White
Special Features	Adjustable Backrest, Detachable Tray, Weather-resistant
Indoor/Outdoor Usage	Outdoor
Assembly Required	Yes

8. Warranty and Support

For warranty information, missing parts, or technical support, please contact Outsunny customer service. Refer to your purchase documentation or the Outsunny official website for contact details.

You can visit the Outsunny Store on Amazon for more information and product offerings.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01CYL1NU8

More documents and user manuals: **https://manuals.plus/**