Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Parlux 330 I

Parlux Advance Light Ionic & Ceramic Hair Dryer Model 330 I User Manual

Model: 330 I

1. Introduction

Thank you for choosing the Parlux Advance Light Ionic & Ceramic Hair Dryer, Model 330 I. This professional-grade hair dryer is designed to provide efficient and effective hair drying with advanced ionic and ceramic technology, ensuring healthy, static-free hair. Its lightweight design and powerful motor make it a reliable tool for daily use. Please read this manual carefully before operating the appliance to ensure safe and proper use.

2. Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed. To reduce the risk of electric shock, burns, fire, or injury to persons, please observe the following:

- Keep out of reach of children.
- Do not rinse or submerge the hair dryer in water or any other liquid.
- Always unplug the hair dryer immediately after use and when not in use.
- Do not use while bathing or near water, including sinks, bathtubs, or showers.
- Keep the power plug and cord away from heated surfaces.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Do not block the air openings or place the hair dryer on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

3. Product Overview

The Parlux Advance Light Hair Dryer is engineered for professional performance and user comfort. It features a powerful 2200-watt motor, advanced ionic and ceramic technology for frizz-free results, and a built-in silencer for reduced noise during operation.



Figure 1: Parlux Advance Light Hair Dryer with included concentrator nozzles.

Key Features:

- **Ionic & Ceramic Technology:** Ensures healthy, static-free hair by breaking down water molecules for faster drying and sealing the cuticle for a smooth finish.
- **Powerful 2200 Watt Motor:** Provides strong airflow for quick drying.
- **Built-in Silencer:** Significantly reduces operational noise for a more comfortable experience.
- **Lightweight Design:** Ergonomically designed for comfortable handling during extended use.
- **Multiple Heat and Speed Settings:** Offers versatility for various hair types and styling needs.
- **Innovative Cleaning System:** Designed for easy maintenance and prolonged product life.



Figure 2: The hair dryer features a 2200 Watt motor and Ionic & Ceramic technology.

Components:

- Hair Dryer Unit
- Two Concentrator Nozzles (different sizes for varied styling)
- Power Cord (3 meters in length)



Figure 3: The two included concentrator nozzles for precise styling.



Figure 4: The dryer promotes shiny, soft hair and features an innovative cleaning system.

4. Setup

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if the appliance or power cord is damaged.
3. **Attach Concentrator (Optional):** Select the desired concentrator nozzle. Align the nozzle with the front barrel of the hair dryer and push it firmly into place until it clicks. Ensure it is securely attached before use.
4. **Power Connection:** Plug the power cord into a suitable 240-volt electrical outlet. Ensure your outlet voltage matches the appliance's requirements.

5. Operating Instructions

The Parlux Advance Light Hair Dryer offers various settings to customize your drying and styling experience.

1. **Power On/Off:** Locate the main power switch on the handle. Slide it to the 'ON' position to start the dryer and to 'OFF' to turn it off.
2. **Adjust Speed:** The hair dryer features 2 speed settings. Use the speed switch to select your preferred airflow intensity (e.g., low for gentle drying, high for fast drying).
3. **Adjust Heat:** There are 7 heat settings available. Use the heat switch to select the desired temperature. Start with a lower heat setting for delicate hair or higher settings for thicker hair or faster drying.
4. **Cold Shot Button:** Press and hold the cold shot button (usually marked with a snowflake icon) to deliver a burst of cool air. This helps to set your style and add shine. Release the button to return to the selected heat setting.
5. **Styling with Concentrators:** Use the concentrator nozzles to direct airflow precisely for specific styling needs, such as straightening or smoothing sections of hair.

For best results, towel-dry hair before using the dryer. Hold the dryer approximately 6-8 inches away from your hair and move it continuously to prevent heat damage.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

1. **Cleaning the Air Filter:** The hair dryer is equipped with an innovative cleaning system, likely involving a removable rear filter. Regularly clean the rear air filter to prevent lint and dust buildup, which can reduce airflow and cause overheating. To clean, ensure the dryer is unplugged and cool. Twist or pull off the rear filter cover. Use a soft brush or cloth to remove any accumulated debris. Replace the filter cover securely.
2. **Cleaning the Exterior:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. **Storage:** When not in use, unplug the appliance and allow it to cool completely. Store it in a dry place, away from moisture and direct sunlight. Do not wrap the power cord tightly around the dryer, as this can damage the cord. Use the hanging loop for convenient storage.

7. Troubleshooting

If you encounter any issues with your Parlux Advance Light Hair Dryer, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Dryer does not turn on.	No power supply; damaged cord/plug; internal fault.	Check if the dryer is properly plugged into a working outlet. Inspect the power cord for damage. If damaged, discontinue use and contact support.
Low airflow or overheating.	Blocked air intake filter.	Unplug the dryer and allow it to cool. Clean the rear air filter as described in the Maintenance section.
Dryer suddenly stops during use.	Overheating protection activated.	Unplug the dryer and allow it to cool down for at least 10-15 minutes. Check and clean the air filter. Plug it back in and try again.
Unusual noise or smell.	Internal debris or motor issue.	Discontinue use immediately and unplug the dryer. Contact customer support for assistance.

If the problem persists after following these steps, please contact customer support.

8. Specifications

Technical specifications for the Parlux Advance Light Ionic & Ceramic Hair Dryer Model 330 I:

- **Model Number:** 330 I
- **Brand:** Parlux
- **Manufacturer:** PerfumeWorldWide, Inc.
- **Power Source:** Corded Electric
- **Voltage:** 240 Volts
- **Wattage:** 2200 watts
- **Number of Speeds:** 2
- **Number of Settings:** 7 (Heat/Speed combinations)
- **Cable Length:** 3 Meters
- **Hair Type Compatibility:** Dry, All
- **Material Type:** Ceramic
- **Product Dimensions:** 9.8 x 3.5 x 7.8 inches
- **Item Weight:** 0.5 Grams (Note: This weight is as provided in product data and may refer to a component or be an error in the source data.)
- **UPC:** 737003983329
- **Origin:** Made in Italy

9. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the retailer from whom you purchased the Parlux Advance Light Hair Dryer. Warranty terms and conditions may vary by region and retailer.

For technical support or service inquiries, please contact the official Parlux customer service or your authorized distributor. Contact details can typically be found on the manufacturer's official website or on your purchase receipt.

© 2024 Parlux. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01D8K29LG

More documents and user manuals: **https://manuals.plus/**