Manuals+
Q & A | Deep Search | Upload

Casio TQ-143S-1EF

Casio TQ-143S Classic Alarm Clock User Manual

Model: TQ-143S-1EF | Brand: Casio

1. Product Overview

The Casio TQ-143S is a compact, classic analog alarm clock designed for reliable timekeeping and gentle waking. Its simple, functional design makes it suitable for various settings, including bedrooms, offices, or travel. Key features include an easy-to-read dial, a quiet quartz movement, and a convenient light/snooze button.

Figure 1: Front view of the Casio TQ-143S alarm clock, showing the analog dial with luminous numbers and hands.

2. Package Contents

- Casio TQ-143S Alarm Clock
- 1 x CR2 Battery (pre-installed or included separately)
- User Manual (this document)

3. Setup

3.1 Battery Installation

The Casio TQ-143S alarm clock operates on one CR2 battery. Ensure the battery is correctly installed for proper function.

1. Locate the battery compartment cover on the back of the alarm clock.
2. Slide or gently pry open the battery compartment cover.
3. Insert the CR2 battery, ensuring the positive (+) and negative (-) terminals align with the indicators

inside the compartment.

4. Replace the battery compartment cover securely.

Figure 2: Rear view of the alarm clock, highlighting the battery compartment and control knobs for time and alarm settings.

3.2 Setting the Time

To set the current time on your alarm clock:

1. Locate the **Time Setting Knob** on the back of the clock (refer to Figure 2).
2. Rotate this knob clockwise or counter-clockwise until the hour and minute hands display the correct current time.

4. Operating Instructions

4.1 Setting the Alarm

To set the desired alarm time:

1. Locate the **Alarm Setting Knob** on the back of the clock (refer to Figure 2).
2. Rotate this knob until the small alarm hand points to your desired wake-up time.
3. To activate the alarm, slide the **Alarm ON/OFF Switch** (usually located on the side or back) to the "ON" position.
4. The alarm will sound at the set time, typically with a gradually increasing volume.

4.2 Using the Snooze/Light Function

The top button on the alarm clock serves a dual purpose:

- **Snooze:** When the alarm is sounding, press the large button on top of the clock to temporarily stop the alarm. The alarm will sound again after a few minutes (typically 5-10 minutes).
- **Light:** Press the same top button at any time to illuminate the clock face for easy viewing in low-light conditions. The light will remain on as long as the button is pressed.

4.3 Turning Off the Alarm

To permanently turn off the alarm until the next set time:

- Slide the **Alarm ON/OFF Switch** (refer to Figure 2) to the "OFF" position. This will stop the alarm from sounding and prevent it from sounding again at the set time until reactivated.

5. Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Battery Replacement:** Replace the battery when the clock hands slow down or the alarm sound weakens. Always use a fresh CR2 battery. Dispose of old batteries responsibly according to local regulations.
- **Storage:** If storing the clock for an extended period, remove the battery to prevent leakage and damage.

6. Troubleshooting

Problem	Possible Cause	Solution
Clock not running / Hands not moving.	Battery is dead or incorrectly installed.	Check battery polarity. Replace with a new CR2 battery.
Alarm does not sound.	Alarm switch is OFF. Alarm time is not set correctly. Battery is low.	Slide alarm switch to ON. Re-set alarm time. Replace battery.
Alarm is too quiet.	Battery is low.	Replace with a new CR2 battery.
Light function not working.	Battery is low or dead.	Replace with a new CR2 battery.

7. Specifications

Feature	Detail
Brand	Casio
Model Number	TQ-143S-1EF
Color	Black
Product Dimensions (L x W x H)	7 x 3 x 7 cm (2.76 x 1.18 x 2.76 inches)
Material	Plastic
Item Weight	80 grams (2.82 ounces)
Power Source	Battery Powered
Battery Type	1 x CR2 (included)
Display Type	Analog
Style	Classic
Special Feature	Illumination (Light), Snooze Function
Shape	Square

8. Warranty and Support

For information regarding warranty coverage, product support, or service inquiries, please refer to the official Casio website or contact Casio customer service directly. Specific warranty terms may vary by region and retailer.
Please note: This manual provides general instructions. For detailed support, always refer to the manufacturer's official resources.

© 2024 Casio. All rights reserved.