Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

vhbw Hoover Diva DV 70, DV 71, DV20, DVG 1100-2099 compatible

vhbw Microfiber Vacuum Cleaner Bags Instruction Manual

Compatible with Hoover Diva DV 70, DV 71, DV20, DVG 1100-2099 Series

Introduction

This manual provides essential information for the proper installation and use of your vhbw microfiber vacuum cleaner bags. These bags are designed to be compatible with specific Hoover Diva vacuum cleaner models, ensuring optimal performance and filtration. Regular replacement of vacuum bags is crucial for maintaining your vacuum cleaner's suction power and preventing the release of dust and allergens back into the air.



Image: Two vhbw microfiber vacuum cleaner bags, ready for use.

Setup and Installation

Follow these general steps to replace the vacuum cleaner bag. Always refer to your specific Hoover Diva vacuum cleaner's instruction manual for detailed, model-specific instructions.

1. **Power Off:** Ensure your vacuum cleaner is unplugged from the power outlet before attempting any installation or maintenance.
2. **Open Compartment:** Locate and open the dust bag compartment on your vacuum cleaner. This usually involves releasing a latch or pressing a button.
3. **Remove Old Bag:** Carefully remove the full dust bag. Most bags have a sealing mechanism on the collar to prevent dust from escaping during removal. Dispose of the old bag responsibly.
4. **Insert New Bag:** Take a new vhbw microfiber bag. Align the cardboard collar of the new bag with the bag holder inside the compartment. Push firmly until it is securely seated. Ensure the bag is fully unfolded inside the compartment without obstructing any air inlets.

5. **Close Compartment:** Close the dust bag compartment securely until you hear a click or feel it latch into place.
6. **Test:** Plug in your vacuum cleaner and perform a brief test to ensure proper operation and suction.



Image: Benefits of vhbw bags, highlighting easy change and high filtration.

Operating Guidelines

These vhbw microfiber vacuum cleaner bags are designed for single use. For optimal performance and hygiene, it is recommended to replace the bag when it is approximately two-thirds full, or when you notice a decrease in suction power. Do not attempt to empty and reuse the bags, as this can compromise filtration efficiency and damage your vacuum cleaner.

Maintenance

The vhbw microfiber vacuum cleaner bags themselves require no maintenance as they are disposable. However, regular replacement is the primary maintenance action to ensure your vacuum cleaner operates effectively. Periodically check your vacuum cleaner's filters (if applicable) and clean or replace them according to your vacuum cleaner's manual, as clogged filters can also affect performance.

Troubleshooting

- **Reduced Suction Power:** If your vacuum cleaner experiences reduced suction, first check if the dust bag is full and replace it if necessary. Also, inspect the vacuum cleaner's filters for clogs and clean or replace them. Ensure there are no blockages in the hose or attachments.
- **Unpleasant Odors:** Unpleasant odors during vacuuming often indicate a full or old dust bag. Replace the bag immediately to eliminate odors.
- **Dust Escaping:** If dust is escaping from your vacuum cleaner, ensure the dust bag is correctly installed and the

compartment lid is securely closed. Check for any tears or damage to the bag.

Specifications

Brand	vhbw
Material	Microfiber (Synthetic)
Color	White
Quantity	10 bags per pack
Bag Dimensions (approx.)	28 cm (Length) x 20 cm (Width)
Compatible Devices	Hoover Diva DV 70, DV 71, DV20, DVG 1100-2099 series vacuum cleaners
Replaces Original Part	Hoover H68



Image: Compatibility information for vhbw bags.

Warranty Information

vhbw products are manufactured to high-quality standards. For specific warranty details regarding this product, please refer to the packaging or contact your retailer. Keep your proof of purchase for any warranty claims.

Support

Should you have any questions or require further assistance with your vhbw vacuum cleaner bags, please contact the retailer from whom you purchased the product. They will be able to provide support or direct you to the appropriate customer service channels.

© 2023 vhbw. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01EL0ZN8I

More documents and user manuals: **https://manuals.plus/**