Manuals+
Q & A | Deep Search | Upload

HUO JI X7200

HUO JI E-Element X7200 Mechanical Gaming Keyboard User Manual

Model: X7200

Introduction

This manual provides comprehensive instructions for the HUO JI E-Element X7200 Mechanical Gaming Keyboard. This keyboard features 104 anti-ghosting keys, DIY replaceable blue mechanical switches, multicolor LED backlighting, and a durable design. It is designed for gamers and typists requiring responsive and tactile feedback. Please read this manual thoroughly to ensure proper setup, operation, and maintenance of your keyboard.

Image: Top-down view of the HUO JI E-Element X7200 Mechanical Gaming Keyboard, showcasing its full 104-key layout and multicolor LED backlighting.

Package Contents

- 1 x HUO JI E-Element X7200 Mechanical Gaming Keyboard
- 1 x User Manual

Setup

1. **Unpack the Keyboard:** Carefully remove the keyboard and any accessories from the packaging.
2. **Connect to Computer:** Plug the USB cable of the keyboard into an available USB port on your computer. The keyboard is plug-and-play, requiring no additional drivers for basic functionality.

3. **System Compatibility:** The keyboard is compatible with Windows 10, Windows 8, Windows 7, Mac OS X, Windows XP, Windows VISTA, and Linux operating systems.

Image: Angled view of the HUO JI E-Element X7200 Mechanical Gaming Keyboard, showing the USB cable connection point.

Operating Instructions

Key Features

- **Anti-Ghosting 104 Keys:** Features N-key rollover, allowing multiple keys to be pressed simultaneously with accurate registration, which is beneficial for gaming.
- **DIY Blue Mechanical Switches:** Equipped with Outemu blue switches, known for their tactile bump, audible click sound, and responsive feedback. These switches are designed for durability with a lifespan of up to 50 million clicks.
- **Ergonomic Design:** The stepped keycap design and integrated wrist rest are intended to provide comfort and reduce fatigue during extended use.

Function Shortcuts (FN Combinations)

Utilize the Function (FN) key in combination with the F1-F12 keys to access various multimedia and system shortcuts:

Combination	Function
FN + F1	My Computer
FN + F2	Search
FN + F3	Calculator
FN + F4	Media Player
FN + F5	Previous Track
FN + F6	Next Track

Combination	Function
FN + F7	Play/Pause
FN + F8	Stop
FN + F9	Mute
FN + F10	Volume Down
FN + F11	Volume Up
FN + F12	Email

Image: Close-up view of the F1-F12 keys, highlighting the secondary functions accessible via the FN key.

Backlight Control

- **Change Backlight Mode:** Press **FN + INS** to cycle through 9 different LED backlight modes.
- **Gaming Key Lighting Patterns:** The keyboard has 8 built-in gaming key lighting patterns. Press**FN + (1-8)** to activate these predefined patterns.
- **Customizable Key Lights:** For custom lighting, press **FN + (9 or 0)**. This allows you to select specific keys to light up while others remain off. Refer to the keyboard's on-screen display or specific software (if available) for detailed customization steps.

Maintenance

- **Cleaning:** To clean the keyboard, gently remove the keycaps. The keycaps are designed to be easily removable for cleaning. Use a soft brush or compressed air to remove dust and debris from underneath the keycaps and between the switches. Wipe the keycaps and keyboard surface with a slightly damp, lint-free cloth. Ensure the keyboard is disconnected from the computer before cleaning.

- **Switch Replacement:** The HUO JI E-Element X7200 features DIY replaceable switches. If a switch becomes faulty, it can be replaced. Use a keycap puller to remove the keycap, then use a switch puller to carefully extract the faulty switch. Insert a new compatible Outemu blue switch until it clicks into place, then reattach the keycap.

Image: Close-up view demonstrating the replaceable mechanical switches, with several keycaps and switches detached from the keyboard.

Troubleshooting

Common Issues and Solutions

- **Keyboard Not Responding:**
  - Ensure the USB cable is securely plugged into both the keyboard and the computer.
  - Try plugging the keyboard into a different USB port on your computer.
  - Restart your computer.
- **Keys Not Registering or Double-Typing:**
  - This can indicate a faulty mechanical switch. Refer to the "Maintenance" section for instructions on how to replace individual switches.
  - Clean the area around the affected key to ensure no debris is obstructing the switch mechanism.
- **Backlighting Not Working or Incorrect:**
  - Ensure the keyboard is properly connected.
  - Press **FN + INS** to cycle through backlight modes.
  - Check if a specific gaming pattern (**FN + 1-8**) or custom mode (**FN + 9-0**) is active.

Specifications

Feature	Detail
Model Number	X7200
Brand	HUO JI
Key Count	104 Keys
Switch Type	Outemu Blue Mechanical Switches (DIY replaceable)
Keystroke Durability	Up to 50 million clicks
Keystroke Force	60±15 grams
Keystroke Travel	4.0±0.2mm
Anti-Ghosting	N-key rollover
Backlighting	Multicolor LED, 9 modes, customizable
Connectivity	USB Wired
Cord Length	1.8 m (70.87 inches)
Material	Metal base, ABS material, double shot injection keycaps
Dimensions	430 x 120 mm (16.9" x 4.7") (Keyboard only, without wrist rest)
Product Dimensions (with wrist rest)	42.93 x 3.05 x 11.94 cm
Weight	Approx. 1240g (43.7oz) / 1.22 kg
Compatibility	Windows 10/8/7/XP/VISTA, Mac OS X, Linux

Warranty and Support

The HUO JI E-Element X7200 Mechanical Gaming Keyboard typically comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.
If you encounter any quality problems or require technical assistance, please contact the seller or manufacturer's customer support. Provide your purchase details and a clear description of the issue to facilitate prompt resolution.