Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Howard Miller 635191

Howard Miller Megan Mantle Clock Model 635191

Instruction Manual

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Howard Miller Megan Mantle Clock, Model 635191. Please read these instructions carefully before using your clock to ensure optimal performance and longevity.
The Megan Mantle Clock features a retro-style design with a piano walnut finish, a frosted-center glass dial, black Roman numerals, and a quartz movement. It is designed for tabletop placement.

2. Safety Information

- Keep the clock away from direct sunlight, extreme temperatures, and high humidity to prevent damage to the wood finish and internal components.
- Avoid placing the clock near strong magnetic fields, which can affect the accuracy of the quartz movement.
- Handle the clock with care to prevent accidental drops or impacts.
- Ensure the clock is placed on a stable, level surface to prevent tipping.

3. Package Contents

Upon unpacking, please verify that all components are present:

- Howard Miller Megan Mantle Clock (Model 635191)
- Instruction Manual (this document)

Note: One AA battery is required for operation and is not included in the package.

4. Setup

4.1. Battery Installation

The clock operates on one (1) AA battery. Follow these steps to install the battery:

1. Locate the battery compartment cover on the back of the clock.
2. Remove the cover by sliding or gently prying it open.
3. Insert one fresh AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Replace the battery compartment cover securely.

Important: Use only high-quality alkaline batteries. Do not mix old and new batteries or different types of batteries.

4.2. Clock Placement

Place the clock on a flat, stable surface such as a mantelpiece, shelf, or table. The felt covers on the bottom of the feet are designed to protect your furniture surfaces.



Image 1: The Howard Miller Megan Mantle Clock (Model 635191) in a typical tabletop setting. This image illustrates the clock's overall appearance, including its piano walnut finish, glass dial with Roman numerals, and polished aluminum accents.

5. Operating Instructions

5.1. Setting the Time

Once the battery is installed, the clock will begin to operate. To set the correct time:

1. Locate the time-setting knob or wheel on the back of the clock's movement mechanism.
2. Gently turn the knob in either direction until the hour and minute hands indicate the correct time.

3. Avoid forcing the hands directly, as this may damage the movement. Always use the setting knob.

6. Maintenance

6.1. Cleaning

- To clean the clock's wood finish, gently wipe with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or polishes that may damage the finish.
- For the glass dial, use a soft cloth lightly dampened with a glass cleaner, then wipe dry immediately. Avoid spraying cleaner directly onto the clock.
- Dust the aluminum components with a soft, dry cloth.

6.2. Battery Replacement

Replace the AA battery annually or when the clock begins to lose time or stops running. Follow the battery installation steps outlined in Section 4.1.

- Remove depleted batteries promptly to prevent leakage, which can damage the clock's movement.
- Dispose of used batteries according to local regulations.

7. Troubleshooting

Problem	Possible Cause	Solution
Clock not running	Battery is depleted or incorrectly installed. Battery compartment contacts are dirty.	Replace with a fresh AA battery, ensuring correct polarity. Clean battery contacts with a dry cloth or cotton swab.
Clock runs too slow or fast	Battery is low. Clock movement is exposed to extreme temperatures.	Replace with a fresh AA battery. Relocate the clock to a room with stable temperature.
Hands are stuck	Hands are bent and touching each other or the dial.	Carefully adjust the hands to ensure they do not touch. If unable to resolve, contact customer support.

8. Specifications

Feature	Detail
Model Number	635191
Brand	Howard Miller
Dimensions (H x W x D)	8" (20 cm) x 9" (23 cm) x 3.25" (8 cm)
Weight	4.2 Pounds (approx. 1.9 kg)
Movement Type	Quartz, Battery-Operated
Power Source	1 x AA Battery (not included)
Materials	Piano Walnut finish on select hardwoods and veneers, Glass dial, Polished Aluminum accents

Feature	Detail
Color	Brown
Style	Retro
Mounting Type	Tabletop

9. Warranty and Support

Howard Miller products are manufactured to high-quality standards. For specific warranty information regarding your Megan Mantle Clock, please refer to the warranty card included with your purchase or visit the official Howard Miller website. For technical support or service inquiries, please contact Howard Miller customer service directly.

Howard Miller Official Website: www.howardmiller.com

© 2023 Howard Miller. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01F1DJHG8

More documents and user manuals: **https://manuals.plus/**