Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lexibook JG7425

Lexibook JG7425 TV Game Console Instruction Manual

Model: JG7425

Introduction

This manual provides essential information for the safe and effective use of your Lexibook JG7425 TV Game Console. Please read it thoroughly before use and retain it for future reference.

Safety Information:

- Not suitable for children under 3 years of age.
- Requires 6 AAA batteries (not included) for the controllers.

Package Contents

Verify that all items are present in the package:

- Lexibook JG7425 TV Game Console Unit
- 2 Wireless Controllers
- RCA Connection Cable (Audio/Video)
- Power Adapter
- Instruction Manual (this document)



Image: Lexibook JG7425 console with included accessories: two wireless controllers, power adapter, and RCA cable.

Setup

1. Installing Batteries in Controllers

1. Locate the battery compartment on the back of each wireless controller.
2. Open the battery compartment cover.
3. Insert 3 AAA batteries into each controller, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Connecting to Your TV

The Lexibook JG7425 console uses an RCA connection for audio and video output.

1. Locate the RCA input ports (typically yellow for video, white for left audio, red for right audio) on your television.
2. Connect the yellow plug of the RCA cable to the yellow video input on your TV.
3. Connect the white plug to the white audio input on your TV.
4. Connect the red plug to the red audio input on your TV.
5. Connect the other end of the RCA cable to the corresponding output ports on the Lexibook JG7425 console.

3. Connecting Power

1. Connect the power adapter to the power input port on the Lexibook JG7425 console.
2. Plug the power adapter into a standard electrical outlet.

4. Powering On

1. Turn on your television and select the correct AV input source (e.g., AV1, Video, Input 1) that corresponds to where you connected the RCA cables.
2. Press the Power button on the Lexibook JG7425 console. The console's indicator light should illuminate.
3. The main menu of the console should appear on your TV screen.

Operating Instructions

Controller Functions

The wireless controllers allow for interactive gameplay. Familiarize yourself with the buttons:

- **Directional Pad (D-Pad):** Used for movement and menu navigation.
- **Action Buttons (A, B, X, Y):** Perform in-game actions such as jumping, attacking, or confirming selections.
- **START Button:** Typically used to pause games or confirm selections.
- **BACK/SELECT Button:** Used for various functions depending on the game, often for returning to previous menus or selecting options.



Image: The Lexibook JG7425 console with its two wireless controllers, showing button layout.

Game Selection and Play

1. From the main menu, use the D-Pad on your controller to navigate through the available game categories (e.g., Sports Games, Arcade Games, Mini-Games).
2. Press the A button to select a category.
3. Browse the list of games within the selected category. The console includes 221 games (40 sports games, 181 arcade and mini-games), with 132 games featuring 32-bit graphics.
4. Select a game and press the A button to start playing.
5. Many games support multiplayer. Refer to individual game instructions for specific multiplayer setup.



Image: Two children actively playing a tennis game using the Lexibook JG7425 console, with the game displayed on a television screen.

Maintenance

Cleaning

- Ensure the console is powered off and unplugged before cleaning.
- Use a soft, dry cloth to wipe the console and controllers.
- Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the device.

Battery Care

- Remove batteries from controllers if the console will not be used for an extended period to prevent leakage.
- Replace all batteries in a controller at the same time. Do not mix old and new batteries or different types of batteries.

Storage

- Store the console and accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
No image or sound on TV.	RCA cables not connected correctly. Incorrect TV input selected. Console not powered on.	Ensure RCA cables are securely connected to both the console and the TV. Select the correct AV input on your TV (e.g., AV1, Video). Press the Power button on the console.
Controllers not responding.	Batteries are low or incorrectly inserted. Controllers are too far from the console.	Replace batteries with new AAA batteries, ensuring correct polarity. Move closer to the console.
Console freezes or crashes.	Temporary software glitch.	Turn off the console, unplug the power adapter, wait 10 seconds, then plug it back in and restart.

Specifications

- **Model:** JG7425
- **Brand:** Lexibook
- **Controller Type:** Wireless Control
- **Power Source:** Electric with cable (via included power adapter)
- **Hardware Interface:** MiniSD (refers to internal storage, not user-accessible slot)
- **Number of Batteries (Controllers):** 6 AAA (3 per controller)
- **Battery Type (Controllers):** AAA (Alkaline recommended)
- **Display Type:** DIGITAL (internal processing, output is analog RCA)
- **Material:** Plastic
- **Memory Capacity:** 4 GB (internal)
- **Product Dimensions:** 38 x 6 x 25 cm
- **Item Weight:** 490 g
- **Recommended Age:** 5 years and up
- **Languages:** French, English, Italian, Portuguese, Spanish, German
- **Games Included:** 221 (40 sports, 181 arcade/mini-games), including 132 with 32-bit graphics.
- **Connectivity:** RCA Plug and Play

Warranty Information

Lexibook products are covered by a limited warranty. For specific details regarding warranty coverage, duration, and claims procedures, please refer to the warranty card included with your product or visit the official Lexibook website. Please retain your proof of purchase for warranty service.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Lexibook customer support.

- **Online Support:** Visit the official Lexibook website for FAQs, troubleshooting guides, and contact forms.
- **Contact Information:** Refer to the product packaging or the Lexibook website for regional customer service contact details (phone numbers, email addresses).

© 2023 Lexibook. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01F704GWA

More documents and user manuals: **https://manuals.plus/**