**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### GameSir GameSir G4 Pro

# GameSir G4 Pro Bluetooth Game Controller User Manual

Model: GameSir G4 Pro | Brand: GameSir

## Introduction

The GameSir G4 Pro is a versatile multi-platform gaming controller designed for an enhanced gaming experience across various devices. It supports iOS, Android, PC, and Nintendo Switch, offering multiple connection options including Type-C USB wired, Bluetooth, and 2.4GHz Wi-Fi. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you get the most out of your controller.
Key features include magnetic ABXY buttons for platform-specific layouts, a six-axis gyroscope for precise motion control, and dedicated Turbo and Screenshot buttons. It is also highly compatible with major cloud gaming platforms like Xbox Cloud Gaming and Google Stadia, as well as Apple Arcade and MFi certified games.

## Package Contents

- GameSir G4 Pro Controller
- USB Type-C Charging Cable
- 2.4GHz USB Dongle (located inside the controller)
- User Manual (this document)

## Setup

### Charging the Controller

Before first use, ensure the controller is fully charged. Connect the supplied USB Type-C cable to the controller's charging port and a power source (e.g., computer USB port or USB wall adapter). The battery indicator lights will show charging status.
The controller features an 800 mAh polymer lithium battery for extended playtime.




Image: The GameSir G4 Pro controller highlighting its 800 mAh polymer lithium battery for long-lasting use.

## Connecting to Devices

The GameSir G4 Pro supports multiple connection methods:

- **Bluetooth Connection:** Ideal for Android phones/tablets, iPhones/iPads, and Nintendo Switch.
- **2.4GHz Wireless Connection:** For Windows PC and other compatible devices using the included USB dongle. The dongle is typically stored within the controller itself.
- **Type-C USB Wired Connection:** For direct connection to PC or other devices.

### Connecting to Android Phones/Tablets

To connect via Bluetooth, press and hold the central button (GameSir logo) and the 'A' button simultaneously until the

indicator light flashes. Search for "GameSir G4 Pro" in your device's Bluetooth settings and pair. The controller also features a built-in phone holder for devices between 3.5-6 inches.




Image: The GameSir G4 Pro controller with a smartphone attached, demonstrating its compatibility with Apple Arcade and MFi games.

▶ **Watch video online**

GameSir G4 pro Game Controller is coming

Video: An official GameSir video demonstrating the features and usage of the G4 Pro controller, including connecting to mobile devices and playing games.

## Connecting to Windows PC

For PC connection, insert the 2.4GHz USB dongle into an available USB port on your computer. Press and hold the central button (GameSir logo) and the 'X' button simultaneously until the indicator light turns blue, indicating successful pairing. Alternatively, connect directly via a USB Type-C cable.

## Connecting to Nintendo Switch

To connect to Nintendo Switch, press and hold the central button (GameSir logo) and the 'Y' button simultaneously.

Follow the pairing instructions on your Nintendo Switch console. The controller's magnetic ABXY buttons can be rearranged to match the Switch layout.




Image: The GameSir G4 Pro controller displayed with various gaming peripherals, emphasizing its broad compatibility with iOS, Android, PC, and Nintendo Switch.

## Operating Instructions

### Button Layout and Functions

The GameSir G4 Pro features a standard gamepad layout with two analog sticks, a D-pad, ABXY buttons, shoulder buttons (L1/R1), and triggers (L2/R2). The ABXY buttons are magnetic, allowing you to swap their positions to match different gaming platform layouts (e.g., Nintendo Switch layout).




Image: A front view of the GameSir G4 Pro controller, showcasing its ergonomic design and the arrangement of its buttons and joysticks.

## Special Features

- **Six-Axis Gyroscope:** Provides precise and stable motion control, enhancing gameplay in compatible titles.




Image: The GameSir G4 Pro controller demonstrating its six-axis gyroscope for precise and stable control during gameplay.

- **Turbo Key:** Activate the Turbo function to rapidly repeat button presses, giving you an advantage in fast-paced games.
- **Screenshot Key:** Capture in-game moments instantly with a dedicated screenshot button.




Image: A detailed view of the GameSir G4 Pro controller highlighting the Turbo and Screenshot keys and their respective functionalities.

- **Asymmetric Motor:** Provides varied vibration feedback for a more immersive gaming experience, with right moment, right vibration, and right intensity.




Image: Hands holding the GameSir G4 Pro controller, illustrating the asymmetric motor's capability to provide precise and varied vibration feedback.

## Supported Gaming Platforms

The G4 Pro is compatible with a wide range of gaming platforms and services:

- Native controller supported games
- Apple Arcade games
- MFi certified games
- Cloud gaming platforms: Xbox Cloud Gaming, Google Stadia, Vortx
- G-Touch mode for Apple games
- G-Touch mode for Android games

## Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the controller. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in use for extended periods.
- **Grips and Buttons:** The controller features soft rubber grips and metal plating buttons for enhanced durability and resistance to sweat and corrosion.




Image: A close-up view of the GameSir G4 Pro controller's soft rubber grips and durable metal-plated buttons.

## Troubleshooting

- **Controller not connecting:**
  - Ensure the controller is charged.
  - Verify you are using the correct pairing mode for your device (Bluetooth, 2.4GHz, or wired).

- If experiencing issues with 2.4GHz connection, try re-inserting the USB dongle.
- If the controller gets stuck in a specific mode (e.g., Bluetooth), use the reset pinhole on the back of the controller to reset it.

- **Input lag or unresponsiveness:**
  - Ensure the controller is within range of your device (for wireless connections).
  - Check for interference from other wireless devices.
  - Try connecting via USB wired mode to rule out wireless issues.
- **Buttons not responding:**
  - Ensure the controller is powered on and connected.
  - Test the controller with another game or application to determine if the issue is game-specific.

## Specifications

| Feature | Detail |
|---|---|
| Brand | GameSir |
| Model Name | GameSir G4 Pro |
| Connectivity Technology | Bluetooth, USB, 2.4GHz Wi-Fi |
| Compatible Devices | Android, iOS, Nintendo Switch, PC (Windows) |
| Controller Type | Gamepad |
| Hardware Platform | Android/iOS |
| Operating System Support | Windows Vista, Windows XP, Mac, Linux |
| Item Weight | 8.7 ounces |
| Product Dimensions (LxWxH) | 6.3 x 23.23 x 4.09 inches |
| Color | G4p (Black) |
| Power Source | Corded Electric (Rechargeable Battery) |
| Batteries | 1 A battery required (included) |

## Warranty and Support

For detailed warranty information and further support, please refer to the official GameSir website or the user manual PDF provided with your product.
You can also find the official User Manual (PDF)here.
For additional video tutorials and game lists, please visit the GameSir official resources:

- Native controller supported games: doc.xiaoji.com/zh/g4pro/detail/566.html
- Apple Arcade games: doc.xiaoji.com/zh/g4pro/detail/570.html
- G-Touch mode for Apple games: doc.xiaoji.com/zh/g4pro/detail/618.html
- G-Touch mode for Android games: doc.xiaoji.com/zh/g4pro/detail/620.html

© 2023 GameSir. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B01HNXGKT6**

More documents and user manuals: **https://manuals.plus/**