Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Step2 874100

Step2 All Around Playtime Patio with Canopy Playset Instruction Manual

Product Overview

The Step2 All Around Playtime Patio with Canopy Playset is designed for interactive outdoor play, featuring a pretend grill, sink, water and sand table, and a snack table. This durable playset encourages imaginative play and social skill development for toddlers and young children.



Image: The Step2 All Around Playtime Patio with Canopy Playset, showcasing its various play areas including a grill, sink, water/sand table, and snack table, all under a protective canopy.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Sharp points. Adult assembly required.
Always supervise children during play. Ensure all parts are securely fastened before use. Regularly inspect the playset for any damage or loose components.

Parts List

The Step2 All Around Playtime Patio with Canopy Playset includes the following components:

- Playhouse structure with integrated grill and sink area
- Snack table
- Water table with sand cover
- Canopy fabric and support poles
- 16-piece accessory set (including pretend dishes, silverware, pans, sand toys, and mesh accessory bag)

- Assembly hardware



Image: Close-up of the playset's accessories, including pots, pans, cups, and sand toys, neatly stored in a mesh bag.

Setup and Assembly

Adult assembly is required. Follow the included assembly hardware and instructions carefully. A drill may be helpful for securing some pieces.

1. Assemble the main playhouse structure, ensuring all panels and supports are securely connected.
2. Attach the grill and sink components to their designated areas.
3. Install the water table and snack table sections.
4. Erect the canopy support poles and secure the canopy fabric over the top. The canopy is designed for easy removal if needed.
5. Place the sand cover over the sand table section if not in use.

Operating Instructions

Pretend Grill and Sink

- The grill lid opens and closes. Turn the knobs to simulate cooking.
- The sink area can be filled with water for pretend dishwashing. It includes a drain plug for easy emptying.
- Use the included pretend dishes and utensils for enhanced role-play.



Image: Children engaging with the playset's grill and sink, demonstrating interactive features.

Water and Sand Table

- Fill one or both sections with water or sand.
- The table features drain plugs for convenient emptying.
- Utilize the included sand toys and water accessories for interactive play.
- A water tower accessory allows for pouring water and observing water flow.
- Cover the sand section with the provided lid when not in use to protect contents.



Image: A child pouring water into the water table, highlighting the water tower accessory and dual compartments.

Snack Table and Doors

- The snack table provides a surface for real snacks or additional pretend play.
- The playset includes two swinging doors for easy entry and exit, enhancing the playhouse experience.



Image: Rear view of the playset, showing the snack table and the functional swinging doors.

Maintenance and Cleaning

The playset is constructed from double-walled plastic for durability. To maintain cleanliness and hygiene:

- Use disinfectant wipes or standard household cleaners for regular cleaning.
- Rinse thoroughly with water after cleaning, especially in areas used for water or sand play.
- Ensure drain plugs are open to allow water to escape and prevent stagnant water accumulation.
- The canopy can be removed for cleaning or storage during harsh weather conditions.

Troubleshooting

If you encounter any issues with your playset, please refer to the following general advice:

- **Loose Components:** Re-tighten any screws or fasteners that may have come loose during play.

- **Water Drainage Issues:** Check that drain plugs are fully open and clear of debris.
- **Canopy Stability:** Ensure canopy poles are correctly inserted and secured into the playset structure.

Specifications

Feature	Detail
Product Dimensions	47.5" W x 47.5" D x 60" H
Item Weight	44.4 pounds
Model Number	874100
Recommended Age	24 months - 8 years
Material	Double-walled plastic construction
Included Accessories	Playhouse with grill and sink, snack table, water table, sand cover, canopy, 16-piece accessory set (including mesh accessory bag)

Warranty and Support

For warranty information or customer support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01K1J6Z94

More documents and user manuals: **https://manuals.plus/**