XREXS 8541986906

XREXS 4-Channel Digital Kitchen Timer Clock User Manual

Model: 8541986906

1. Product Overview

The XREXS 4-Channel Digital Kitchen Timer Clock is a versatile device designed to assist with time management in various settings, particularly in the kitchen. It features a large LCD display, multiple simultaneous timers, and flexible placement options.



Figure 1: Front view of the XREXS 4-Channel Digital Kitchen Timer Clock, showing the display and control buttons.

2. Setup

2.1 Battery Installation

The timer requires two AAA batteries for operation. For energy saving during shipping, an insulating tape may be present on the batteries. Please remove this tape before installation.

1. Locate the battery compartment on the back of the timer.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Figure 2: Battery compartment with insulating tape on batteries.

2.2 Physical Placement

The timer offers multiple placement options for convenience:

- **Magnetic Attachment:** The timer features a magnetic back, allowing it to be securely attached to metal surfaces such as refrigerators or ovens.
- **Fold-out Stand:** A built-in fold-out stand allows the timer to be placed upright on any flat surface, such as a countertop or desk.
- **Lanyard Hole:** A small hole is provided for attaching a lanyard, enabling the timer to be hung or carried.



Figure 3: Rear features of the timer, including magnets and stand.

3. Operating Instructions

The XREXS timer supports both count-up and count-down functions across four independent channels (T1, T2, T3, T4), and also functions as a clock.

3.1 Clock Function

Press the **CLOCK** button to switch the display to clock mode. The time can be displayed in either 12-hour or 24-hour format.



Figure 4: Timer displaying 24-hour and 12-hour formats.

3.2 Timer Functions (Count-Up / Count-Down)

The timer features four distinct channels (T1, T2, T3, T4) that can operate simultaneously.



Figure 5: Timer displaying multiple channels.

3.2.1 Setting a Count-Down Timer

1. Select the desired timer channel (T1, T2, T3, or T4) by pressing its respective button. The selected channel will be indicated on the display.
2. Use the **HR**, **MIN**, and **SEC** buttons to set the desired countdown time. The maximum setting is 99 hours, 59 minutes, and 59 seconds.
3. Press the **START/STOP** button to begin the countdown.
4. When the countdown reaches zero, the alarm will sound.
5. Press **START/STOP** to stop the alarm.
6. Press the **CLEAR** button to reset the timer to zero.

3.2.2 Using the Count-Up Timer (Stopwatch)

1. Ensure the selected timer channel (T1, T2, T3, or T4) is set to 00:00:00. If not, press the **CLEAR** button.
2. Press the **START/STOP** button to begin counting up.
3. Press **START/STOP** again to pause the count.
4. Press **START/STOP** to resume, or **CLEAR** to reset to zero.

3.3 Alarm Volume Settings

The timer features a three-level volume switch located on the back of the device:

- **HIGH:** Provides a loud alarm suitable for noisy environments.
- **LOW:** Offers a softer alarm for quieter settings.
- **MUTE:** Disables the audible alarm, useful when silence is required.

4. Maintenance

4.1 Cleaning

To clean the timer, wipe it with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.

4.2 Battery Replacement

Replace the AAA batteries when the display dims or the alarm sound becomes weak. Refer to Section 2.1 for battery installation instructions.

5. Troubleshooting

5.1 Display is Scratched or Unclear

The timer screen is covered with a thin protective TPU film. If the display appears scratched or unclear upon arrival, gently peel off this protective film. This is not a defect but a measure to protect the screen during transit.

5.2 Alarm is Too Loud or Too Quiet

Adjust the volume using the High/Low/Mute switch located on the back of the timer (refer to Figure 3).

5.3 Timer Not Responding

If the timer is unresponsive, try replacing the batteries with fresh ones. Ensure the batteries are inserted with correct polarity. If the issue persists, contact customer support.

6. Specifications

Feature	Specification
Brand	XREXS
Model Number	8541986906
Color	White
Material	TPU
Product Dimensions	3.94"D x 3.15"W x 1.06"H
Item Weight	82 Grams (2.89 ounces)
Number of Settings	4 (Independent Channels)
Screen Size	8 Centimeters

Feature	Specification
Batteries Required	2 AAA batteries
UPC	701851255327, 701851254269

7. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact XREXS customer service directly. Keep your purchase receipt for any warranty claims.

© 2025 XREXS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question