**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### CalExotics SE-0077-10-3

# CalExotics Silicone Remote Bullet Vibrator SE-0077-10-3 User Manual

*Model: SE-0077-10-3*

## Introduction

This manual provides instructions for the safe and effective use of your CalExotics Silicone Remote Bullet Vibrator, model SE-0077-10-3. Please read this manual thoroughly before first use and retain it for future reference.
The CalExotics Silicone Remote Bullet Vibrator is designed for personal use, offering 12 functions of vibration, pulsation, and escalation. It features a waterproof silicone stimulator with an easy retrieval cord and is controlled by a compact, discreet remote.




Image: An overview of the product's key features, including 12 intense functions, silicone material, waterproof design, remote control, AAA battery requirement, and remote range.




Image: The CalExotics Silicone Remote Bullet Vibrator and its remote control, shown both in its retail packaging and as individual components. The bullet vibrator is black, sleek, and has a retrieval cord. The remote is also black and oval-shaped with the CalExotics logo.

## Important Safety Information

- **Battery Safety:** This device requires 2 AAA batteries (not included) for the bullet and 1 AAA battery (not included) for the remote. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove batteries if the device will not be used for an extended period.
- **Cleaning:** Clean the product thoroughly before and after each use with warm water and a toy cleaner or mild soap. Rinse thoroughly.
- **Waterproof:** The stimulator is waterproof and may be used in or out of water. Ensure battery compartments are securely closed before water exposure. The remote is not specified as waterproof; avoid submerging the remote.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Discontinue Use:** If you experience any discomfort or irritation, discontinue use immediately. Consult a medical professional if symptoms persist.

## Package Contents

Verify that all items are present in your package:

- 1 x CalExotics Silicone Remote Bullet Vibrator
- 1 x Wireless Remote Control
- 1 x Easy Retrieval Cord (attached to bullet vibrator)
- 1 x User Manual (this document)

## Setup and Battery Installation

The device requires 2 AAA batteries for the bullet vibrator and 1 AAA battery for the remote control (batteries not included).

### 1. Bullet Vibrator Battery Installation:

1. Gently twist off the cap at the base of the bullet vibrator.
2. Insert 2 AAA batteries, ensuring correct polarity (+/-).
3. Securely twist the cap back onto the bullet vibrator until it is fully sealed. This ensures the waterproof integrity of the device.






Image: A close-up view of the bullet vibrator with its base cap removed, revealing the battery compartment where two AAA batteries are to be inserted. The internal spring mechanism for battery contact is visible.

## 2. Remote Control Battery Installation:

1. Locate the battery cover on the back of the remote control.
2. Gently slide or remove the battery cover.
3. Insert 1 AAA battery, ensuring correct polarity (+/-).
4. Replace the battery cover securely.




Image: The remote control with its back cover removed, showing the compartment for a single AAA battery. The battery is partially inserted, illustrating the correct orientation.

## Operating Instructions

The CalExotics Silicone Remote Bullet Vibrator offers 12 distinct functions controlled wirelessly.

### Power On/Off:

- To turn the device **ON**: Press and hold the power button on the remote control for approximately 3 seconds. The bullet vibrator will activate.
- To turn the device **OFF**: Press and hold the power button on the remote control for approximately 3 seconds. The bullet vibrator will deactivate.

### Changing Functions:

- Once the device is powered on, short press the function button on the remote control to cycle through the 12 available vibration, pulsation, and escalation patterns.



Image: A detailed close-up of the black oval-shaped remote control, highlighting the CalExotics logo and the single control button.

## Care and Maintenance

- **Cleaning:** Always clean the silicone bullet vibrator before and after each use. Use warm water and a specialized toy cleaner or mild, antibacterial soap. Rinse thoroughly with clean water. Ensure the battery cap is tightly sealed if cleaning under running water.
- **Drying:** Pat dry with a lint-free cloth or allow to air dry completely before storing.
- **Storage:** Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.
- **Battery Removal:** If the device will not be used for an extended period, remove the batteries from both the bullet vibrator and the remote control to prevent leakage and damage.

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| Device does not turn on. | ◦ Batteries are dead or inserted incorrectly.<br>◦ Battery cap on bullet vibrator is not fully secured.<br>◦ Power button not held long enough. | ◦ Replace batteries in both the bullet vibrator and remote control with fresh AAA batteries, ensuring correct polarity.<br>◦ Ensure the bullet vibrator's battery cap is twisted on tightly.<br>◦ Press and hold the power button on the remote for 3 seconds to activate. |
| Vibrations are weak or inconsistent. | ◦ Low battery power.<br>◦ Loose battery connection. | ◦ Replace batteries in both the bullet vibrator and remote control.<br>◦ Check that batteries are seated firmly and the caps are secure. |

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| Remote control is unresponsive. | ◦ Remote battery is dead or inserted incorrectly.<br>◦ Out of range. | ◦ Replace the AAA battery in the remote control, ensuring correct polarity.<br>◦ Ensure the remote is within the operating range (approximately 32.75 feet / 10 meters). |
| Device stopped working after a short period. | ◦ Battery leakage or corrosion.<br>◦ Product defect. | ◦ Ensure batteries are removed during long periods of non-use. Clean any corrosion if present (with caution).<br>◦ Refer to the warranty information for replacement or repair options. |

## Specifications

- **Model Name:** CalExotics Silicone Remote Bullet Vibrator
- **Model Number:** SE-0077-10-3
- **Brand:** CalExotics
- **Material:** Silicone
- **Color:** Black
- **Functions:** 12 intense functions (vibration, pulsation, escalation)
- **Power Source:**
    - Bullet Vibrator: 2 x AAA batteries (not included)
    - Remote Control: 1 x AAA battery (not included)
- **Waterproof:** Stimulator is waterproof.
- **Remote Range:** Approximately 32.75 feet (10 meters)
- **Product Dimensions:** Bullet vibrator approximately 3.5 inches (9 cm) length, 1 inch (2.5 cm) diameter.
- **Weight:** Approximately 4.6 ounces (total product weight)




Image: A diagram illustrating the dimensions of the bullet vibrator, showing a length of 3.5 inches (9 cm) and a diameter of 1 inch (2.5 cm).

## Warranty and Support

This CalExotics product is backed by a **one-year limited manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.

For warranty claims, technical support, or product inquiries, please contact CalExotics customer service directly. Refer to the official CalExotics website for current contact information.

*Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.*

© 2024 CalExotics. All rights reserved. Information in this manual is subject to change without notice.
For more information, visit www.calexotics.com

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B01KOHQDOK**

More documents and user manuals: **https://manuals.plus/**