Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire 242058253

GENUINE Frigidaire 242058253 Display Board

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the installation, operation, and maintenance of the GENUINE Frigidaire 242058253 Display Board. This component is a genuine replacement part designed specifically for compatible Frigidaire appliances. Please read this manual thoroughly before attempting any installation or repair to ensure proper function and safety.

Product Overview

The Frigidaire 242058253 Display Board is an authentic Original Equipment Manufacturer (OEM) part. It serves as the primary interface for controlling various functions of your appliance, typically found in microwave ovens or refrigerators. This board ensures accurate display and responsive control.



An image showing the genuine Frigidaire 242058253 Display Board, a black rectangular electronic component with a clear plastic housing, featuring touch controls for water, cube, and crush, along with a digital display. This board is crucial for the user interface of compatible appliances.

Key Features:

- This is an O.E.M. Authorized part, ensuring compatibility and quality.
- Electrolux and Frigidaire are interchangeable names for the same brand; the item received may bear either name.
- Model number: 242058253.
- Brand name: FRIGIDAIRE.

Setup and Installation

Important Safety Notice: Before beginning any installation, ensure the appliance is completely disconnected from its power source. Failure to do so can result in electric shock or injury. If you are unsure about any step, consult a qualified technician.

General Installation Steps (Consult Appliance Service Manual for Specifics):

1. **Disconnect Power:** Unplug the appliance from the wall outlet or turn off the circuit breaker supplying power to the appliance.
2. **Access Display Board:** Carefully locate and access the existing display board within your appliance. This may

involve removing control panels, screws, or clips. Refer to your appliance's specific service manual for exact access procedures.

3. **Disconnect Wiring:** Take clear photos of the existing wiring connections before disconnecting them. Carefully unclip or unscrew all wires connected to the old display board.
4. **Remove Old Board:** Detach the old display board from its mounting points.
5. **Install New Board:** Position the new Frigidaire 242058253 Display Board in the same location as the old one. Secure it using the original screws or clips.
6. **Reconnect Wiring:** Using your photos as a guide, carefully reconnect all wires to the new display board. Ensure all connections are secure and correctly seated.
7. **Reassemble Appliance:** Reattach any panels, screws, or clips that were removed to access the board.
8. **Restore Power:** Plug the appliance back into the wall outlet or turn on the circuit breaker.
9. **Test Functionality:** Power on the appliance and test all display and control functions to ensure the new board is operating correctly.

Operating Instructions

The Frigidaire 242058253 Display Board functions as the user interface for your appliance. Once installed, its operation is integrated with the appliance's overall control system. Refer to your appliance's primary user manual for detailed instructions on how to use the specific features and functions controlled by this display board (e.g., setting temperatures, selecting dispense options, programming cycles).
Typical functions controlled by a display board may include:

- Digital time and temperature display.
- Selection of water, ice (cube/crush) dispense options.
- Access to various appliance settings and options.
- Indicator lights for status or alerts.

Maintenance

The Frigidaire 242058253 Display Board itself requires minimal maintenance. To ensure its longevity and proper function:

- **Cleaning:** If the display surface becomes dirty, gently wipe it with a soft, damp cloth. Avoid abrasive cleaners, solvents, or excessive moisture, as these can damage the electronic components or the display surface.
- **Avoid Impact:** Protect the display board from physical impact or excessive force, which can cause cracks or internal damage.
- **Environmental Conditions:** Ensure the appliance operates within its specified environmental conditions (temperature, humidity) to prevent premature component failure.

Troubleshooting

If your appliance's display or control functions are not working correctly after installing the new board, consider the following troubleshooting steps:

- **Power Check:** Ensure the appliance is properly plugged in and receiving power. Check the circuit breaker.
- **Wiring Connections:** Double-check all wiring connections to the display board. Ensure they are secure and correctly matched according to your appliance's service manual or the photos you took during disassembly. Loose or incorrect connections are a common cause of issues.
- **Board Seating:** Verify that the display board is correctly seated and secured in its housing.
- **Appliance Reset:** Try performing a hard reset of the appliance by unplugging it for 5-10 minutes, then plugging it

back in.

- **Other Components:** If the display board appears to be correctly installed and connected, the issue might lie with another component in the appliance's control system. Consult a qualified technician or the appliance's service manual for further diagnostics.

Note: This display board is a replacement part. If the original issue persists after proper installation, it may indicate a problem with a different component of your appliance, not the display board itself.

Specifications

Attribute	Value
Manufacturer	Frigidaire
Part Number	242058253
Item Weight	1.12 pounds
Package Dimensions	11.73 x 7.52 x 4.37 inches
Item Model Number	242058253
Item Package Quantity	1
Batteries Included?	No
Batteries Required?	No
ASIN	B01KR5BAIS
Date First Available	December 30, 2016

Warranty and Support

As a genuine OEM part, the Frigidaire 242058253 Display Board is typically covered by the manufacturer's standard warranty for replacement parts. Please refer to the warranty information provided with your original appliance or contact Frigidaire customer service for specific details regarding warranty coverage for replacement parts.
For further assistance, technical support, or to inquire about other genuine Frigidaire parts, you may visit the official Frigidaire store or contact their customer support channels. You can find more information at the Frigidaire Store on Amazon.

© 2024 Frigidaire. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KR5BAIS

More documents and user manuals: **https://manuals.plus/**