Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB733

Billboard BB733 Water-Resistant Bluetooth Wireless Speaker User Manual

Model: BB733

Introduction

The Billboard BB733 is a water-resistant Bluetooth wireless speaker designed for portable audio enjoyment. It features easy Bluetooth connectivity, allowing you to sync with smartphones and tablets within a 33 ft (10 meter) working distance. Its durable, water-resistant material makes it suitable for outdoor use. The speaker also includes a built-in microphone for hands-free calling.



Image: Front view of the Billboard BB733 speaker, showcasing its blue color and speaker grille.

What's in the Box

- Billboard BB733 Wireless Speaker
- Charging Cable
- User Manual

Product Features

- **Bluetooth Connectivity:** Easily syncs with any smartphone and tablet for wireless audio streaming.
- **Built-in Microphone:** Allows for hands-free call answering and ending directly from the speaker.
- **Water-Resistant Design:** Material ensures protection against splashes and rain, suitable for outdoor use.
- **Long Playtime:** Provides up to 7 hours of play time on a full charge.
- **Compact and Portable:** Designed for easy carrying, allowing you to take your music anywhere.



Image: The Billboard BB733 speaker positioned next to a smartphone, illustrating its compact and portable size.

Setup

Charging the Speaker

1. Locate the charging port on the side of the speaker, typically covered by a protective flap.
2. Connect the provided charging cable to the speaker's DC5V input port.
3. Connect the other end of the charging cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate. A full charge takes approximately 2 hours.
5. Once fully charged, disconnect the charging cable and ensure the protective flap is securely closed to maintain water resistance.



Image: Detailed view of the speaker's side panel, showing the DC5V charging port and AUX input, protected by a rubber flap.

Bluetooth Pairing

1. Ensure the speaker is fully charged.
2. Press and hold the Power button () on the speaker until you hear an audible prompt or see an indicator light flashing, indicating it's in pairing mode.
3. On your smartphone or tablet, navigate to the Bluetooth settings.
4. Turn on Bluetooth and search for available devices.
5. Select "BB733" from the list of found devices.
6. Once paired, the speaker will provide an audible confirmation, and the indicator light will change to a solid state.
7. You can now play audio from your device through the speaker.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the Power button () for a few seconds until the speaker activates.
- **To Power Off:** Press and hold the Power button () again for a few seconds until the speaker shuts down.

Music Playback

- **Play/Pause:** Press the Play/Pause button (▶‖) to start or pause music playback.

- **Volume Up:** Press the Volume Up button (+) to increase the volume.
- **Volume Down:** Press the Volume Down button (-) to decrease the volume.
- **Next Track:** Press and hold the Volume Up button (+) to skip to the next track.
- **Previous Track:** Press and hold the Volume Down button (-) to go to the previous track.
- **Mode Button:** Press the Mode button (M) to switch between Bluetooth, AUX, or TF card modes (if applicable).

Call Management

- **Answer Call:** When a call comes in, press the Play/Pause button (▶‖) to answer.
- **End Call:** During a call, press the Play/Pause button (▶‖) to end the call.
- **Reject Call:** Press and hold the Play/Pause button (▶‖) to reject an incoming call.



Image: Close-up view of the speaker's control panel, showing the power, volume, play/pause, and mode buttons.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Water Resistance:** Ensure all port covers are securely closed before exposing the speaker to water or moisture to maintain its water-resistant properties.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the Power button for a few seconds.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is in pairing mode (flashing light). Turn on Bluetooth on your device. Move device closer to speaker (within 33 ft/10m).
No sound from speaker.	Volume too low; Speaker not connected; Incorrect mode.	Increase volume on both speaker and connected device. Re-pair Bluetooth. Press Mode button to select correct input.
Poor sound quality.	Device too far; Obstructions; Low battery.	Move device closer. Remove obstructions between device and speaker. Charge speaker.

Specifications

Feature	Detail
Model Name	BB733
Material	Plastic
Color	Blue
Connectivity Technology	Bluetooth
Wireless Range	Up to 33 ft (10 meters)
Battery Capacity	600 mAh
Charging Voltage	5V±0.5V
Charging Time	Approximately 2 hours
Play Time	Up to 7 hours
Water Resistance Level	Water Resistant
Item Weight	6.1 ounces

Feature	Detail
Product Dimensions	2.5 x 6 x 4.5 inches

Warranty and Support

The Billboard BB733 speaker comes with a limited warranty. Please refer to the packaging or contact your retailer for specific warranty terms and conditions. For technical support or further assistance, please contact the manufacturer or your point of purchase.

© 2024 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M3W54BE

More documents and user manuals: **https://manuals.plus/**