Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UpStart Components CSC-S49-DL16

UpStart Components 14-inch Semi Chisel Saw Chain Instruction Manual

Model: CSC-S49-DL16

Brand: UpStart Components

1. Important Safety Information

WARNING: This saw chain may be capable of kickback that could result in serious injury to the chainsaw operator or bystanders.**DO NOT USE THIS SAW CHAIN UNLESS YOU HAVE EXPERIENCE AND SPECIALIZED TRAINING FOR DEALING WITH KICKBACK.**Always refer to your chainsaw's User Manual for proper chain installation, maintenance, and safe operation procedures.Failure to follow safety instructions can result in severe personal injury or death.
Always wear appropriate personal protective equipment (PPE) including safety glasses, hearing protection, gloves, and protective legwear when handling or operating a chainsaw.

2. Product Overview

The UpStart Components CSC-S49-DL16 is a 14-inch semi-chisel saw chain designed for use with McCulloch Electramac 14E Chainsaws. This chain features a 3/8" low profile pitch, 0.050" gauge, and 49 drive links. It is engineered for precision, balance, and safety to facilitate efficient cutting.
Key features include:

- High performance for smooth cuts.
- Reduced vibration levels for consistent cuts and user comfort.
- Designed for durability to maintain sharpness longer.



Figure 1: The UpStart Components 14-inch Semi Chisel Saw Chain presented in its clear retail packaging, highlighting the brand and

key specifications.



Figure 2: The UpStart Components 14-inch Semi Chisel Saw Chain, shown both in its retail packaging and uncoiled. This image illustrates the product's physical form.

3. Specifications

Model Number	CSC-S49-DL16
Chain Type	Semi Chisel, Low Profile
Length	14 inches

Pitch	3/8" Low Profile
Gauge	0.050"
Drive Links	49
Compatible Chainsaw	McCulloch Electramac 14E
UPC	734639585248

4. Setup and Installation

Before attempting to install the new saw chain, ensure the chainsaw is turned off, unplugged (if electric), and the spark plug wire is disconnected (if gas-powered) to prevent accidental startup. Always wear heavy-duty gloves to protect your hands from sharp chain cutters.

1. **Remove the Old Chain:** Loosen the bar nuts and remove the clutch cover. Carefully remove the old chain and guide bar from the chainsaw.
2. **Clean Components:** Clean any sawdust or debris from the guide bar groove, sprocket, and clutch area. Inspect the guide bar for wear or damage.
3. **Install the New Chain:** Place the new UpStart Components chain into the groove of the guide bar, ensuring the cutting edges are facing the correct direction (usually forward on the top of the bar).
4. **Mount Bar and Chain:** Fit the guide bar and chain onto the chainsaw studs, ensuring the drive links engage with the sprocket.
5. **Adjust Chain Tension:** Replace the clutch cover and hand-tighten the bar nuts. Adjust the chain tension using the tensioning screw. The chain should be snug against the bottom of the guide bar, but still able to be pulled freely by hand. There should be no slack on the underside of the bar.
6. **Final Tightening:** While holding the tip of the guide bar up, fully tighten the bar nuts. Re-check chain tension after tightening.

Important Note: The same chainsaw model can sometimes accommodate different bar lengths. Always confirm the pitch, gauge, and drive links of your existing chain or guide bar to ensure compatibility before installation. Refer to your chainsaw's original user manual for specific installation procedures and tensioning guidelines.



Figure 3: The 14-inch saw chain laid out in a complete loop, demonstrating its full length and the arrangement of its links. This view helps in understanding the chain's structure before installation.

5. Operation Guidelines

Once the chain is correctly installed and tensioned, operate your chainsaw according to the manufacturer's instructions.

- **Pre-Operation Check:** Before each use, inspect the chain for proper tension, sharpness, and any damage. Ensure all nuts and bolts are tight.
- **Lubrication:** Ensure the chainsaw's oil reservoir is filled with appropriate bar and chain oil to ensure continuous lubrication during operation.
- **Cutting Technique:** Use proper cutting techniques as outlined in your chainsaw's manual to minimize kickback risk and ensure efficient cutting. Avoid forcing the chain through wood.
- **Environmental Awareness:** Be aware of your surroundings, clear the work area of obstacles, and ensure no bystanders are within the danger zone.

6. Maintenance

Regular maintenance extends the life of your saw chain and ensures safe operation.

- **Sharpening:** A sharp chain cuts efficiently and safely. Sharpen the chain regularly using a round file of the correct diameter for 3/8" low profile chains (typically 5/32" or 4.0mm). Maintain the correct filing angles for cutters and depth gauges.



Figure 4: A detailed close-up of the saw chain's individual links, showcasing the semi-chisel cutters and drive links. This view is useful for identifying wear and for proper sharpening.

- **Tension Adjustment:** Check chain tension frequently, especially during the first hour of use with a new chain, and adjust as needed. A loose chain can derail, and an overly tight chain can cause premature wear and damage.
- **Cleaning:** After each use, clean the chain and guide bar to remove sap, pitch, and sawdust. This prevents buildup that can hinder performance and cause corrosion.
- **Inspection:** Regularly inspect the chain for bent or broken links, cracks, or excessive wear. Replace the chain if any significant damage is found. Avoid injuries by replacing dull or damaged chains with a sharp new chain.
- **Storage:** When not in use, store the chain in a clean, dry place. Applying a light coat of oil can help prevent rust.

7. Troubleshooting Common Issues

- **Chain Not Cutting Efficiently:**
  - *Cause:* Dull chain, incorrect sharpening angles, or improper chain tension.
  - *Solution:* Sharpen the chain, ensure correct filing angles, and adjust chain tension.
- **Chain Smoking or Overheating:**
  - *Cause:* Insufficient lubrication, incorrect chain tension (too tight), or dull chain.
  - *Solution:* Check bar and chain oil level, adjust chain tension, and sharpen the chain.
- **Chain Derails from Guide Bar:**
  - *Cause:* Loose chain tension, worn guide bar groove, or damaged drive links.
  - *Solution:* Adjust chain tension, inspect guide bar for wear, and replace chain if damaged.
- **Excessive Vibration:**
  - *Cause:* Damaged chain, unevenly sharpened cutters, or worn sprocket.
  - *Solution:* Inspect chain for damage, ensure even sharpening, and check sprocket for wear.

8. Contact and Support

For further assistance or inquiries regarding your UpStart Components saw chain, please visit the manufacturer's website or contact their customer support.
Manufacturer: UpStart Components
Website: www.upstartcomponents.com (Example link, actual link may vary)

© 2023 UpStart Components. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M6VD1QJ

More documents and user manuals: **https://manuals.plus/**