Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi 60600

Giochi Preziosi Emotion Pets Toffee Pony Instruction Manual

Model: 60600

Introduction

Welcome to the world of Emotion Pets with Toffee, your interactive plush pony. Toffee is designed to react to your interactions, offering a lifelike play experience. This manual will guide you through the setup, operation, and care of your Toffee pony to ensure long-lasting enjoyment.

Safety Information

- **Age Recommendation:** Not suitable for children under 3 years due to small parts. Recommended for ages 4 and up.
- **Battery Safety:** Always use the correct type of batteries (4 x AA). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly. Do not recharge non-rechargeable batteries.
- **Supervision:** Adult supervision is recommended during play, especially during battery installation.

Package Contents

Your Emotion Pets Toffee Pony package should contain the following items:

- 1 x Toffee Interactive Plush Pony
- 1 x Toy Carrot (for feeding interaction)
- 1 x Toy Brush (for grooming interaction)
- 1 x Instruction Manual (this document)



Image: Toffee Interactive Plush Pony with its accessories, including a toy carrot and brush, as seen in its original packaging.

Setup

Battery Installation

1. Locate the battery compartment on Toffee's underside, typically in the stomach area.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 4 x AA (LR6) batteries (not included), ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.
5. Once batteries are installed, you will not need to open this compartment again for normal operation.

Activating Toffee

To awaken Toffee from sleep mode, gently press the sensor/button located at the top of his tail for approximately 3 seconds. Toffee will then become active and ready to interact.

Operating Instructions

Toffee is designed to respond to various interactions, mimicking a real pony's emotions and needs. Here's how to interact with your Toffee pony:

- **Hunger:** When Toffee is hungry, he will call out, blink his eyes, and move his muzzle. Offer him the toy carrot. He will "eat" it, moving his ears and head in contentment.
- **Boredom:** If left alone for a while, Toffee may become bored and seek attention. He might call out or make sounds to indicate he wants to play or be cuddled.
- **Fear:** Toffee can get scared. When frightened, he will open his eyes wide and lower his ears back. Comfort him by picking him up and stroking him gently.
- **Grooming:** Use the toy brush to groom Toffee. This interaction can elicit happy responses.
- **Sleep Mode:** Toffee will enter a sleep mode after a period of inactivity to conserve battery life. To re-activate him, press the tail sensor for 3 seconds.



Image: A detailed view of Toffee's face, emphasizing its interactive features and soft texture.

Maintenance

- **Cleaning:** Toffee is a plush toy. Surface clean only with a damp cloth and mild soap. Do not immerse in water or machine wash, as this can damage the electronic components.
- **Storage:** Store Toffee in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Replacement:** Replace all 4 AA batteries when Toffee's responses become weak or inconsistent.

Troubleshooting

Problem	Possible Cause	Solution
Toffee is not responding.	Batteries are low or depleted. Toffee is in sleep mode.	Replace all 4 AA batteries. Press the tail sensor for 3 seconds to wake Toffee up.
Toffee's movements are weak or slow.	Batteries are running low.	Replace all 4 AA batteries with new ones.
Toffee does not react to the carrot or brush.	Incorrect placement of accessories. Sensor malfunction.	Ensure the carrot/brush is placed correctly near Toffee's mouth/body. If the problem persists after battery replacement, contact customer support.
Toffee enters sleep mode too quickly.	This is normal behavior to conserve battery life.	Press the tail sensor for 3 seconds to re-activate Toffee.

Specifications

- **Model Number:** 60600
- **Brand:** Giochi Preziosi
- **Product Type:** Interactive Plush Toy
- **Theme:** Animal (Pony/Horse)
- **Material:** Plush
- **Color:** Brown
- **Dimensions (L x W x H):** 42 x 23 x 48 cm (16.5 x 9.1 x 18.9 inches)
- **Weight:** 1998 Grams (approx. 4.4 lbs)
- **Power Source:** 4 x AA Batteries (not included)
- **Recommended Age:** 48 months (4 years) and up
- **Special Features:** Interactive, Multifunctional

Warranty Information

The Giochi Preziosi Emotion Pets Toffee Pony (Model 60600) comes with a manufacturer's warranty of **2 years** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims. The warranty does not cover damage resulting from misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

Support

For further assistance, technical support, or warranty claims, please contact Giochi Preziosi customer service. Refer to the packaging or the official Giochi Preziosi website for the most up-to-date contact information.
You can visit the official brand store for more information:Giochi Preziosi France Store

© 2023 Giochi Preziosi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MAXKK68

More documents and user manuals: **https://manuals.plus/**