**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Ergohuman 49802ACHAR

# Ergohuman Eurotech Seating 4x4 Multi Function Chair Instruction Manual

Model: 49802ACHAR

### Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of the Ergohuman Eurotech Seating 4x4 Multi Function Chair in Charcoal, model 49802ACHAR. Designed for all-day comfort, this chair features molded, contoured cushions and a range of ergonomic adjustments to support various body types and work styles. Please read these instructions carefully before using your chair to ensure proper function and longevity.





Image 1: The Eurotech Seating 4x4 Multi Function Chair in Charcoal, showcasing its design and adjustable components.

## Setup and Assembly

The Eurotech Seating 4x4 chair requires minimal assembly. Ensure all components are present before beginning. The chair includes casters for mobility. Follow the manufacturer's instructions provided in the packaging for detailed assembly steps. Typically, this involves attaching the chair back to the seat mechanism, inserting the gas lift into the base, and then placing the assembled seat onto the gas lift.
**Note:** If any parts are missing, please contact customer support immediately.

## Operating Instructions

The Eurotech 4x4 chair offers multiple adjustment features to customize your seating experience. Refer to the video below for a visual guide on operating these features.

▶ **Watch video online**
Eurotech Seating 4x4 Multi Function Chair

Video 1: Demonstrates how to operate the various features of the Eurotech 4x4 Multi Function Chair, including seat height, tilt, back adjustments, and armrest settings.

### 1. Seat Height Adjustment

- To **raise** the seat: Lift up on the second paddle from the front while taking your weight off the seat.
- To **lower** the seat: Lift up on the second paddle from the front while seated, allowing the chair to descend.

### 2. Back Angle Adjustment and Tilt Lock

- To activate **free float**: Pull up on the second-to-last paddle (from the front). The chair will now recline freely.
- To activate **forward tilt**: While in free float, lean forward and pull the front lever back. Once leaning forward, push the second-to-last paddle down to lock the forward tilt.
- To return to **normal sitting position**: Pull up on the second-to-last paddle to re-engage free float. Lean back and push the front lever forward to lock the chair in an upright position.
- To **lock the back angle**: Find a comfortable back position. Lift the back paddle to adjust the angle, then push it down to lock it in place.

### 3. Tilt Tension Adjustment

- To adjust the tension of the tilting motion: Bend down and locate the knob under the seat.
- Turn the knob to the **left** to loosen the tension, making it easier to recline.
- Turn the knob to the **right** to increase the tension, requiring more effort to recline.
- For easier adjustment, place the chair in the forward tilt position before adjusting the tension.

### 4. Backrest Height Adjustment

- To **raise** the backrest: Lift the backrest slowly, stopping at the desired height. Listen for a click to confirm it's locked.
- The backrest operates on an upward ratchet mechanism. If you reach the top height, the backrest will drop to its lowest position, allowing you to reset the height.

### 5. Armrest Height and Width Adjustment

- To adjust **armrest height**: Push the button on the side of the armrest and raise or lower the armrest to your preferred height.
- To adjust **armrest width**: Loosen the knob located under the seat. Slide the armrest in or out to achieve the desired width, then re-tighten the knob to secure its position.

## Maintenance

To maintain the appearance and functionality of your Eurotech Seating 4x4 chair, follow these simple care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the fabric or finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.

## Troubleshooting

If you encounter any issues with your Eurotech Seating 4x4 chair, please refer to the following common solutions:

- **Chair not adjusting properly:** Ensure all levers and knobs are fully engaged or disengaged as described in the "Operating Instructions" section. Sometimes, a lever may not be fully pushed or pulled.
- **Missing parts during assembly:** If you find that parts are missing upon unboxing, please contact customer service immediately for assistance.
- **Unstable or wobbly chair:** Check that all screws and bolts are securely tightened, especially those connecting the seat to the back and the base to the gas lift.

## Specifications

| | |
|---|---|
| **Brand** | Ergohuman |
| **Model Name** | 4x4 |
| **Item Model Number** | 49802ACHAR |
| **Color** | Charcoal |
| **Product Dimensions** | 26"D x 30"W x 44"H |
| **Item Weight** | 60 pounds |
| **Maximum Weight Recommendation** | 250 Pounds |
| **Back Style** | Solid Back |
| **Special Feature** | Adjustable |
| **Fill Material** | Foam |
| **Furniture Base Movement** | Swivel |
| **Included Components** | Caster |
| **UPC** | 669245112123 |

## Warranty

The Eurotech Seating 4x4 Multi Function Chair comes with a **lifetime warranty**, ensuring long-term reliability and peace of mind. For specific details regarding warranty coverage and claims, please refer to the warranty information provided with your product packaging or contact customer support.

## Customer Support

For further questions, assistance with assembly, troubleshooting, or warranty inquiries, please contact Eurotech Seating customer service:

- **Email:** customerservice@raynorgroup.com
- Please have your model number (49802ACHAR) and purchase date available when contacting support.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B01N0XD8WO**

More documents and user manuals: **https://manuals.plus/**