Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Motorola C601i

Motorola C601i Cordless Telephone User Manual

Model: C601i

Introduction

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Motorola C601i Cordless Telephone. Please read this manual carefully to ensure proper use and to maximize the features of your new telephone system.

1. Setup

1.1. What's in the Box

- Cordless Phone Handset
- Cordless Phone Base Unit
- Cordless Adaptor (Power Adapter)
- Line Cable (Telephone Line Cord)
- 2 x AAA Rechargeable Batteries

1.2. Battery Installation

1. Locate the battery compartment cover on the back of the handset.
2. Slide the cover downwards to open it.
3. Insert the two AAA rechargeable batteries, observing the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

1.3. Connecting the Base Unit

1. Plug one end of the telephone line cable into the LINE port on the back of the base unit.
2. Plug the other end of the telephone line cable into your telephone wall jack.
3. Plug the small end of the cordless adaptor into the DC IN port on the back of the base unit.
4. Plug the large end of the cordless adaptor into a standard electrical wall outlet.

1.4. Charging the Handset

Place the handset onto the base unit. Ensure the handset is properly seated in the charging cradle. The display on the handset should indicate that it is charging. For optimal battery performance, charge the handset for at least 15-20 hours

before its first use.



This image displays the Motorola C601i Cordless Telephone, featuring a black handset resting securely in its matching black charging base. The handset has an orange backlit display showing 'HANDSET' and a battery indicator. The keypad is visible with standard numeric buttons and function keys.

2. Operating Your Telephone

2.1. Making Calls

- **Dialing Directly:** Pick up the handset or press the **Call** button, then dial the number.
- **Pre-dialing:** Dial the number first, then press the **Call** button.
- **Hands-free Speakerphone:** During a call, press the **Speaker** button to activate the speakerphone. Press it again to switch back to the handset.

2.2. Receiving Calls

When the phone rings, pick up the handset or press the **Call** button to answer. To answer using the speakerphone, press the **Speaker** button.

2.3. Phonebook

Your Motorola C601i can store up to 50 names and numbers in its phonebook. Refer to the on-screen menu for options to add, edit, or delete entries. To dial from the phonebook, navigate to the desired entry and press the **Call** button.

2.4. Caller ID

The phone supports Caller ID and Call Waiting features. It stores a list of up to 40 incoming calls. You can review the Caller ID list to see who called, and dial back directly from the list. Ensure you have subscribed to Caller ID service from your telephone service provider.

2.5. Ringer Melodies

The handset features polyphonic ringer melodies. You can customize the ringer tone through the handset's menu settings.

3. Maintenance

3.1. Cleaning Your Telephone

Wipe the telephone surfaces with a soft, damp cloth. Do not use cleaning sprays or abrasive cleaners, as these can damage the unit. Ensure the phone is unplugged from the power outlet before cleaning.

3.2. Battery Care

To prolong battery life, avoid overcharging by leaving the handset on the base for extended periods after it is fully charged. If the phone will not be used for a long time, remove the batteries from the handset.

4. Troubleshooting

Problem	Possible Cause	Solution
No dial tone	Telephone line cable not connected properly.	Ensure the telephone line cable is securely plugged into the base unit and the wall jack.
Handset not charging	Handset not properly seated on the base; power adapter not connected.	Ensure the handset is correctly placed on the charging cradle. Verify the power adapter is plugged into the base and a working electrical outlet.
Poor sound quality	Handset too far from base; interference.	Move closer to the base unit. Avoid placing the base unit near other electronic devices that may cause interference.
Display is blank	Batteries are low or not installed correctly.	Charge the handset. Check battery installation and polarity.

5. Specifications

Model: C601i

Color: Black

Product Dimensions: 18 x 14 x 9 cm

Item Weight: 46 g

Batteries: 2 x AAA rechargeable batteries (included)

Talk Time: Up to 10 hours

Standby Time: Up to 150 hours

Phonebook Capacity: 50 names and numbers

Caller ID List Capacity: 40 names and numbers

Special Features: Bright backlit display, Hands-free speakerphone, Polyphonic ringer melodies

Manufacturer: Meizhou Guo Wei Electronics Company Limited

Date First Available: 2 February 2017

6. Warranty and Support

6.1. Warranty Information

Your Motorola C601i Cordless Telephone comes with a **1-year manufacturer warranty** for the device from the date of purchase. In-box accessories, including batteries, are covered by a **6-month manufacturer warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

6.2. Customer Support

For technical assistance, warranty claims, or further inquiries, please contact Motorola customer support. Refer to the official Motorola website or your product packaging for the most current contact information.

© 2024 Motorola. All rights reserved.

Motorola and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N6XNXT3

More documents and user manuals: **https://manuals.plus/**