Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Magic Wand 4332667821

Magic Wand Rechargeable Massager User Manual

Model: 4332667821 | Brand: Magic Wand

Introduction

The Magic Wand Rechargeable Massager is designed to provide powerful, hands-free massage. This cordless device offers deep vibration to target various muscle groups, promoting relaxation and muscle relief. Its portable and lightweight design makes it suitable for both home use and travel.



Image: Front view of the Magic Wand Rechargeable Massager.

Important Safety Information

Please read all instructions carefully before using the Magic Wand Rechargeable Massager. Failure to follow these guidelines may result in injury or damage to the product.

- Do not immerse the massager in water or any other liquid.
- Keep out of reach of children.
- Do not use on swollen, inflamed, or broken skin.
- Consult a physician before use if you have any medical conditions, including but not limited to pregnancy, heart disease, or electronic implants.
- Use only the provided charger.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Package Contents

Verify that all items are present in your package:

- Magic Wand Rechargeable Massager
- Adjustable Harness
- Charging Cable (110-240v US plug)



Image: Magic Wand Rechargeable Massager shown with its packaging.

Setup

Charging the Massager

Before first use, fully charge the Magic Wand Rechargeable Massager. The device uses a Lithium Ion battery.

1. Locate the charging port on the massager.
2. Connect the charging cable to the massager and plug the adapter into a 110-240v US electrical outlet.
3. The indicator light will show charging status (e.g., blinking while charging, solid when fully charged).
4. A full charge typically takes several hours. Disconnect the charger once charging is complete.



Image: The Magic Wand Rechargeable Massager with its charging cable and adapter.

Attaching the Adjustable Harness

The included adjustable harness allows for hands-free use with a pillow.

1. Insert the head of the Magic Wand into the designated slot on the harness.
2. Secure the massager firmly within the harness.
3. Adjust the straps of the harness to fit around a pillow (between 9 to 28.5 inches in width) for comfortable positioning. The straps expand up to 58 inches in circumference.

Operating Instructions

The Magic Wand Rechargeable Massager features multiple speeds and pulsation patterns for a customized experience.

Controls



Image: Close-up of the control panel with power, speed, and pulsation buttons.

- **Power Button:** Press to turn the massager ON or OFF.

- **Speed Control Buttons:** Use the '+' and '-' buttons to adjust between 4 incredible speeds.
- **Pulsation Pattern Button:** Press to cycle through 4 additional pulsation patterns.

Usage

Apply the vibrating head of the massager to the desired area of the body. Adjust the speed and pattern to achieve your preferred intensity and sensation. For hands-free use, position the massager within the adjustable harness against a pillow or other suitable surface.

Maintenance

Cleaning

To ensure hygiene and longevity of your massager:

- Wipe the massager head and body with a damp cloth and mild soap after each use.
- Do not use abrasive cleaners or submerge the device in water.
- Allow the massager to air dry completely before storing.

Storage

Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it away from sharp objects to prevent damage to the silicone head.

Troubleshooting

Problem	Possible Cause	Solution
Massager does not turn on.	Battery is depleted.	Charge the massager fully using the provided charger.
Vibration is weak or inconsistent.	Low battery or obstruction.	Recharge the device. Ensure the massager head is clean and free from debris.
Device overheats.	Prolonged use or internal issue.	Turn off the massager and allow it to cool down. If overheating persists, discontinue use and contact customer support.

Specifications

- **Model Number:** 4332667821
- **Dimensions:** 12.75 x 2.5 x 2.5 inches
- **Weight:** 1.76 Pounds
- **Battery:** 1 Lithium Ion battery (rechargeable)

- **Material:** ABS plastic, silicone
- **Power:** 110-240v US plug for charging
- **Speeds:** 4 incredible speeds
- **Pulsation Patterns:** 4 additional patterns
- **Harness Compatibility:** Fits pillows 9 to 28.5 inches wide, straps expand up to 58 inches circumference.

Warranty and Support

For any questions, concerns, or support needs regarding your Magic Wand Rechargeable Massager, please contact the manufacturer, XR, LLC. Refer to your product packaging for specific contact details or visit the official Magic Wand website.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2025 Magic Wand. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N95U32E

More documents and user manuals: **https://manuals.plus/**