Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bittel HA9888(41) T-18

Bittel Polaris 41 Bathroom Landline Phone

MODEL: HA9888(41) T-18

Introduction

This instruction manual provides detailed guidance for the installation, operation, and maintenance of your Bittel Polaris 41 Bathroom Landline Phone. Please read this manual thoroughly before using the phone to ensure proper functionality and to prevent damage. Keep this manual for future reference.

Package Contents

Please check the package contents upon opening. If any items are missing or damaged, contact your vendor immediately.

- Bittel Polaris 41 Landline Phone Unit
- Handset
- Handset Cord
- Line Cord (1m and 12cm)

Safety Information

- Do not expose the phone to excessive moisture or liquids.
- Avoid placing the phone near heat sources or direct sunlight.
- Use only the provided cords and accessories.
- Do not attempt to open or repair the phone yourself. Refer all servicing to qualified personnel.
- Ensure the phone is installed in a stable location to prevent falls.

Setup

Follow these steps to set up your Bittel Polaris 41 Landline Phone:

1. **Connect the Handset:** Plug one end of the coiled handset cord into the jack on the side of the phone unit and the other end into the jack on the handset.
2. **Connect to Telephone Line:** Plug one end of the line cord into the LINE jack on the back or side of the phone unit. Plug the other end of the line cord into your wall telephone jack.

3. **Placement:** Place the phone unit in a suitable location, ensuring the cords are not tangled or obstructing pathways.



Figure 1: Bittel Polaris 41 Phone Unit and Handset

Operating Instructions

Making a Call

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad. The phone supports standard 12-group DTMF dialing.
4. Wait for the call to connect.
5. To end the call, replace the handset in the cradle.

Receiving a Call

1. When the phone rings, lift the handset to answer the call.
2. To end the call, replace the handset in the cradle.

Using the Flash Function

The Flash button (if present) allows you to switch between calls or access certain PBX features. The flash time is configurable (98ms, 300ms, 600ms), with 600ms as the standard setting.

- During a call, press the **Flash** button briefly to activate the flash function. Consult your PBX system's manual for specific feature codes.

Message Waiting Light (MWL)

The phone is equipped with a Message Waiting Light. This light illuminates when there is a new message waiting for you on your voicemail system (requires compatible PBX system). The standard voltage for the MWL is 90-150V DC.

- When the MWL is illuminated, dial your voicemail access number to retrieve messages.
- The light will turn off automatically once all new messages have been retrieved.

Maintenance

Cleaning

- Wipe the phone's exterior with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the finish.

- Ensure no liquid enters the phone's openings.

Storage

- If storing the phone for an extended period, disconnect it from the telephone line.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Bittel Polaris 41 phone, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No dial tone	• Ensure the line cord is securely connected to both the phone and the wall jack. • Check if your telephone line is active. Test with another phone if available.
Cannot make or receive calls	• Verify the line cord connection. • Confirm that the phone line is active. • If connected to a PBX, ensure the PBX system is functioning correctly.
Message Waiting Light (MWL) not working	• Ensure your PBX system supports the MWL feature and is configured correctly. • Check the MWL voltage compatibility with your PBX (standard 90-150V DC).
Poor call quality / Static	• Check for loose connections of the handset cord or line cord. • Ensure the phone is not placed near strong electrical interference sources.

Specifications

- **Model:** HA9888(41) T-18
- **Brand:** Bittel
- **Color:** Off White
- **Telephone Type:** Corded
- **Handset:** Hearing Aid Compatible
- **Dial Character:** Standard 12 group DTMF
- **Line Cord Length:** 1m and 12cm
- **Flash Time:** 98ms, 300ms, 600ms (standard 600ms)
- **Message Waiting Light Voltage:** Standard 90~150V DC (Customized MWL card compatible with PBX)
- **Compatible Devices:** Hearing Aids, PBX Systems
- **Material:** Other

- **Answering System Type:** Digital

Warranty and Support

Bittel products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or contact your point of purchase. For technical support or service inquiries, please contact the authorized Bittel service center or your product vendor.

© 2024 Bittel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NB0ZGUH

More documents and user manuals: **https://manuals.plus/**