Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER 9W6044-560

PKPower 12V AC/DC Adapter User Manual

For Seagate 9W6044-560 160GB External Hard Disk Drive

1. Introduction

Thank you for choosing the PKPower 12V AC/DC Adapter. This manual provides essential information for the proper installation, operation, and maintenance of your power adapter. This adapter is specifically designed to provide reliable power to your Seagate 9W6044-560 160GB External Hard Disk Drive.

2. Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- **Over Voltage Protection (OVP):** The adapter is designed to protect against excessive output voltage.
- **Over Current Protection (OCP):** The adapter is designed to protect against excessive output current.
- **Short Circuit Protection (SCP):** The adapter is designed to protect against short circuits.
- PKPower products are **CE** / **FCC** / **RoHS certified**, ensuring they meet safety and environmental standards.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is used with compatible devices only.

3. Product Overview

The PKPower 12V AC/DC Adapter is a compact and efficient power supply unit. It consists of the main adapter unit, an AC input power cord, and a DC output cable with a compatible connector for your external hard drive.



Image 3.1: The PKPower 12V AC/DC Adapter, showing the main unit, detachable AC power cord, and integrated DC output cable.



Image 3.2: A detailed view of the adapter's label, indicating input voltage (100-240V), frequency (50-60Hz), and various safety certifications.

4. Setup Instructions

Follow these steps to correctly set up your PKPower AC/DC Adapter with your Seagate external hard drive:

1. **Connect AC Power Cord:** Insert the female end of the AC power cord firmly into the AC input port on the PKPower adapter unit.
2. **Connect to Power Outlet:** Plug the male end of the AC power cord into a standard wall electrical outlet (100-240V, 50/60Hz).
3. **Connect to Device:** Carefully insert the DC output plug from the adapter into the power input port of your Seagate 9W6044-560 160GB External Hard Disk Drive. Ensure a snug fit.
4. Verify all connections are secure before powering on your external hard drive.

5. Operating Instructions

Once the adapter is properly connected as described in the Setup section:

- Ensure your Seagate external hard drive is connected to your computer via its data cable (e.g., USB).
- If your external hard drive has a power switch, turn it to the 'ON' position. The drive should now receive power and become operational.
- Observe any indicator lights on your hard drive or the adapter to confirm power is being supplied.
- To disconnect, first safely eject the hard drive from your computer's operating system, then turn off the hard drive (if applicable), and finally unplug the adapter from the wall outlet.

6. Maintenance

Proper care will extend the life of your PKPower adapter:

- Keep the adapter clean and dry. Use a soft, dry cloth to wipe off dust.
- Avoid placing the adapter in areas with poor ventilation, direct sunlight, or near heat sources.
- Do not coil the cables too tightly, as this can damage the internal wires.
- Unplug the adapter from the wall outlet when not in use for extended periods.

7. Troubleshooting

If you encounter issues with your PKPower adapter, refer to the following common solutions:

- **No Power to Device:**
  - Ensure the AC power cord is securely connected to both the adapter and the wall outlet.
  - Verify the wall outlet is functional by plugging in another device.
  - Check that the DC output plug is fully inserted into the external hard drive's power port.
  - Confirm the external hard drive's power switch (if present) is in the 'ON' position.
- **Device Not Recognized by Computer:**
  - Ensure the external hard drive is receiving power from the adapter.
  - Check the data cable connection between the hard drive and the computer. Try a different USB port or cable if available.
  - Restart your computer.

If problems persist, please contact customer support.

8. Specifications

Detailed technical specifications for the PKPower 12V AC/DC Adapter:



Image 8.1: The PKPower 12V AC/DC Adapter with its approximate dimensions: 4.95 inches (length), 2.00 inches (width), and 1.25 inches (height).

Feature	Specification
Brand	PKPOWER
Input Voltage	100-240V AC, 50-60Hz
Output Current	2 Amps
Compatible Devices	Seagate 9W6044-560 160GB External Hard Disk Drive
Product Dimensions	4 x 2 x 0.5 inches (approximate)
Item Weight	3 ounces
Connector Type	Auxiliary (DC Barrel Connector)
Color	Black

9. Warranty and Support

PKPower stands behind the quality of its products. For any questions, concerns, or technical assistance, our friendly and reliable customer service team is available to help.

- **Customer Service:** Our team will respond to your inquiries within 24 hours.
- For support, please refer to the contact information provided with your purchase or visit the official PKPower website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XB7QW95

More documents and user manuals: **https://manuals.plus/**