Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Home-X SH1079

Home-X Microwave Rice Cooker Instruction Manual

Model: SH1079

Product Overview

The Home-X Microwave Rice Cooker is designed for convenient and efficient cooking or reheating of various types of rice and other starchy foods. Its unique pressure chamber and steam release vents ensure evenly cooked, fluffy results with minimal mess. This 10-cup capacity cooker is made from durable, BPA-free polypropylene and is safe for microwave, refrigerator, freezer, and dishwasher use.



Figure 1: Exploded view of the Home-X Microwave Rice Cooker showing its main components: the red cooker base, the inner pressure chamber tray, the clear outer lid with easy locking clips and built-in steam release vents, and the included red non-stick rice spoon.

Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging. Ensure you have the red cooker base, the inner pressure chamber tray, the clear outer lid, and the rice paddle.
2. **Initial Cleaning:** Before first use, wash all parts of the rice cooker (cooker base, inner tray, outer lid, and rice paddle) with warm, soapy water. Rinse thoroughly and dry completely. The components are also dishwasher safe for convenience.
3. **Inspect:** Check all parts for any signs of damage. Do not use if any part is cracked or broken.

Operating Instructions

Cooking Rice

1. **Measure Rice:** Add your desired amount of rice to the red cooker base. The cooker has a 10-cup capacity.

2. **Rinse Rice (Optional):** If desired, rinse the rice thoroughly under cold water until the water runs clear. Use the inner lid to help drain the rinse water.
3. **Add Water:** Add the appropriate amount of water according to the type of rice you are cooking. A common ratio for white rice is 1 cup of rice to 1.5 cups of water. For brown rice, a ratio of 1 cup of rice to 2.5-3 cups of water is often recommended. Adjust water levels based on desired consistency and rice type.
4. **Insert Inner Tray:** Place the inner pressure chamber tray into the cooker base, ensuring it sits properly above the rice and water.
5. **Secure Lid:** Place the clear outer lid on top of the cooker base, aligning the easy locking clips. Press down firmly on the clips until they securely snap into place on all sides. This creates a secure seal to prevent spills and ensure proper steaming.
6. **Microwave:** Place the assembled rice cooker into your microwave oven.



Figure 2: The Home-X Microwave Rice Cooker positioned inside a microwave oven, ready for cooking.

7. **Cooking Time:** Microwave on high power. Cooking times will vary depending on your microwave's wattage and the type and quantity of rice.
    - For 1 cup of white rice: Approximately 13-15 minutes.

- For 1 cup of brown rice: Approximately 20-25 minutes.
- *Note:* Some users find success with an initial high power cook (e.g., 10 minutes) followed by a lower power cook (e.g., power level 5 for 15-20 minutes) for brown rice. Experiment to find the ideal settings for your microwave.

8. **Rest:** Once cooking is complete, carefully remove the rice cooker from the microwave using oven mitts, as it will be hot. Let it rest for 5-10 minutes with the lid still on. This allows the steam to redistribute and the rice to finish cooking, resulting in fluffier grains.
9. **Serve:** Carefully unclip and remove the lid, directing steam away from your face. Fluff the rice with the included rice paddle and serve.



Figure 3: The 10-cup capacity of the Home-X Microwave Rice Cooker, demonstrating its ability to prepare large portions of rice suitable for family meals.

Other Uses

- **Reheating Rice:** Add a small amount of water (1-2 tablespoons) to leftover rice in the cooker, secure the lid, and microwave for 1-3 minutes until heated through.
- **Cooking Oatmeal:** For 1/2 cup of oatmeal, add 1 cup of liquid (water or milk). Microwave on high for approximately 2

minutes. Adjust liquid and time as needed for desired consistency. The cooker helps prevent boil-overs.

- **Steaming Vegetables:** Place chopped vegetables in the cooker with a small amount of water (1/4 to 1/2 cup). Secure the lid and microwave until tender-crisp.

Maintenance and Care

- **Cleaning:** The Home-X Microwave Rice Cooker is dishwasher safe. For best results, place all components on the top rack of your dishwasher. Alternatively, wash by hand with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely before storing.
- **Storage:** Store all components together in a clean, dry place. The inner tray and lid can be nested within the cooker base for compact storage.
- **Durability:** Made from durable polypropylene, this cooker is designed for long-lasting use. Avoid using abrasive cleaners or scouring pads that could scratch the surface.



Figure 4: The versatility of the Home-X Microwave Rice Cooker, demonstrating its safety for use in both the microwave and freezer, making it ideal for cooking, storing, and reheating.

Troubleshooting

Problem	Possible Cause	Solution
Rice is too hard or undercooked.	Insufficient water or cooking time. Microwave wattage too low.	Increase water slightly or extend cooking time. Ensure lid is securely fastened. Allow adequate resting time after cooking.
Rice is too mushy or overcooked.	Too much water or excessive cooking time. Microwave wattage too high.	Reduce water slightly or decrease cooking time. Adjust microwave power level if possible.

Problem	Possible Cause	Solution
Water/rice bubbles out of vents during cooking.	Too much water, too much rice, or microwave power too high.	Ensure you are not overfilling the cooker. Reduce water slightly. Consider reducing microwave power or cooking in shorter intervals. Ensure steam vents are clear.
Lid does not seal properly.	Clips not fully engaged or lid/cooker is damaged.	Press down firmly on all four easy locking clips until they click into place. Inspect lid and cooker for any cracks or deformities.

Specifications

- **Brand:** Home-X
- **Model Name:** SH1079
- **Capacity:** 10 Cups
- **Product Dimensions:** 7.5"D x 7.5"W x 6"H
- **Material:** Polypropylene (PP)
- **Color:** Red
- **Special Features:** Safety Lock, Steam Vent
- **Care Instructions:** Dishwasher Safe
- **Compatibility:** Microwave Safe, Refrigerator Safe, Freezer Safe
- **Included Components:** Rice Paddle, Instruction Manual
- **Item Weight:** 12.6 ounces
- **UPC:** 713012690359



Figure 5: Visual representation of the Home-X Microwave Rice Cooker's dimensions, measuring 7.5 inches in diameter and 6 inches in height.

Warranty and Support

For information regarding product warranty, returns, or technical support, please contact Home-X customer service directly. Refer to the contact information provided with your product packaging or visit the official Home-X website.

Home-X is a registered trademark of Simply Home Solutions.

© 2024 Home-X. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XDV7L1C

More documents and user manuals: **https://manuals.plus/**