PKPOWER AC/DC Adapter

PK Power AC/DC Adapter User Manual

For AUDIOVOX Portable DVD Players (Models D1817PK, D1888, D1915, D1788, D9000, VBP50, VBP58)

1. Introduction

This manual provides essential instructions for the safe and effective use of your PK Power AC/DC Adapter. This adapter is designed to provide reliable power to compatible AUDIOVOX portable DVD players, ensuring optimal performance for your device.

2. Important Safety Instructions

WARNING: To reduce the risk of fire or electric shock, carefully follow these instructions.

- Read all instructions before using the adapter.
- Do not expose the adapter to rain or moisture.
- Do not disassemble the adapter. Refer all servicing to qualified service personnel.
- Ensure the adapter is connected to a power outlet with the correct voltage (100-240V AC).
- Avoid placing the adapter in direct sunlight or near heat sources.
- Keep the adapter away from children.
- Unplug the adapter from the power outlet when not in use for extended periods.
- **California Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Key Features

The PK Power AC/DC Adapter is engineered with advanced features to ensure safe and efficient power delivery:

- **Wide Input Voltage:** Supports 100-240V AC, 50-60Hz for global compatibility.
- **Safety Certifications:** CE, FCC, and RoHS certified, meeting international safety and environmental standards.
- **Multiple Protection Designed:** Incorporates Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.



Image: Diagram showing the adapter's multiple protection features, including over voltage, over current, over temperature, quality microchip, electromagnetic wave, and short circuit protection.

4. Compatible Devices

This PK Power AC/DC Adapter is specifically designed for use with the following AUDIOVOX Portable DVD Player models:

- AUDIOVOX D1817PK
- AUDIOVOX D1888
- AUDIOVOX D1915
- AUDIOVOX D1788
- AUDIOVOX D-1788
- AUDIOVOX D9000

- AUDIOVOX VBP50
- AUDIOVOX VBP58

Please verify your device model number to ensure compatibility before use.

5. Setup Instructions

Follow these steps to connect your PK Power AC/DC Adapter to your AUDIOVOX Portable DVD Player:

1. Ensure both the AC/DC adapter and your DVD player are turned off.
2. Locate the power input port on your AUDIOVOX Portable DVD Player.
3. Connect the output connector of the PK Power AC/DC Adapter securely into the power input port of your DVD player.
4. Plug the AC adapter's wall plug into a standard electrical wall outlet (100-240V AC).
5. Once connected, you can power on your DVD player.



Image: The PK Power AC/DC Adapter with its integrated power cord, ready for connection.

6. Operating the Adapter

The PK Power AC/DC Adapter operates automatically once connected to a power source and your device. It provides a stable power supply for charging your portable DVD player's battery or for direct operation.

- Use the adapter only with compatible devices as listed in this manual.
- Do not overload the adapter by connecting it to devices requiring higher power than its specifications.
- If the adapter feels excessively hot, disconnect it immediately and check for proper ventilation or potential issues

with the connected device.

7. Care and Maintenance

To ensure the longevity and optimal performance of your AC/DC adapter, follow these maintenance guidelines:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use and replace the adapter.

8. Troubleshooting

If you encounter issues with your PK Power AC/DC Adapter, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Adapter not providing power.	No power from outlet; loose connection; faulty adapter.	Check wall outlet with another device. Ensure all connections are secure. Try a different outlet. If problem persists, adapter may be faulty.
Device not charging or powering on.	Incompatible device; faulty device power port; adapter not fully connected.	Verify device compatibility. Ensure adapter connector is fully inserted. Test the adapter with another compatible device if possible.
Adapter gets excessively hot.	Poor ventilation; overloaded; internal fault.	Ensure adapter is in a well-ventilated area. Disconnect and allow to cool. Do not use if it continues to overheat.

9. Product Specifications

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Output	Refer to adapter label (e.g., Model: ANU-, Input: 100-240VAC0.3A 50/60Hz, Output: [Specific Voltage/Amperage])
Color	Black
Connector Type	Auxiliary (specific barrel connector for compatible DVD players)
Certifications	CE, FCC, RoHS
Special Feature	Travel-friendly design
Power Source	Corded Electric



Image: Product size diagram indicating the adapter's dimensions (1.18in x 1.58in x 2.92in) and a 1.2m/4ft cable length.

10. Warranty and Support

PK-Power products are designed for reliability and performance. For any questions, concerns, or support needs, our friendly and reliable customer service team is available to assist you.

- Customer service inquiries will be responded to within 24 hours.
- For further assistance, please visit the official PKPOWER Store on Amazon.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question