Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER CR7002A

PK Power AC/DC Adapter Instruction Manual

For Crosley CR7002A Tech Turntable Record Player

1. Product Overview

This manual provides essential instructions for the safe and effective use of your PK Power AC/DC Adapter, specifically designed for the Crosley CR7002A Tech Turntable Record Player. This adapter converts standard AC wall power to the DC power required by your turntable, ensuring proper operation.



Figure 1: The PK Power AC/DC Adapter with its integrated power cord. This image displays the compact design of the adapter unit and the coiled power cable.

2. Safety Instructions

Please read and follow these safety instructions carefully to prevent damage to the adapter, your turntable, or personal injury.

- Ensure the adapter's input voltage (100-240V) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.

- Do not attempt to open or repair the adapter. Refer servicing to qualified personnel.
- Always unplug the adapter from the wall outlet before cleaning or if it will be unused for an extended period.
- Keep out of reach of children.
- This adapter is designed with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to ensure safe operation.



Figure 2: Illustration of the adapter's built-in safety features, including over voltage, over current, over temperature, quality microchip, electromagnetic wave, and short circuit protection.

3. Setup Instructions

1. **Verify Compatibility:** Ensure your device is the Crosley CR7002A Tech Turntable Record Player or another compatible model as specified by the manufacturer.
2. **Connect to Turntable:** Locate the power input port on your Crosley CR7002A turntable. Insert the DC output plug of the PK Power adapter firmly into this port.

3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard wall power outlet or a power strip. Ensure the connection is secure.



Figure 3: The PK Power adapter correctly plugged into a wall socket, ready to provide power to a connected device.



Figure 4: The PK Power adapter connected to a power strip, demonstrating flexibility in power source connection.

4. Operating Instructions

Once the adapter is securely connected to both the turntable and a power outlet, your Crosley CR7002A turntable should receive power. Refer to your turntable's specific instruction manual for details on its operation, as this adapter solely provides the necessary power supply.

- Ensure the turntable's power switch is in the "OFF" position before connecting the adapter.
- After connecting, turn the turntable's power switch to the "ON" position to begin operation.
- If the turntable does not power on, check all connections and the power outlet.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from all power sources. Use a soft, dry cloth to wipe the exterior. Do not use

liquid cleaners or solvents.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use and replace the adapter.

6. Troubleshooting

Problem	Possible Cause	Solution
Turntable does not power on.	◦ Adapter not properly connected. ◦ Power outlet is not active. ◦ Adapter or turntable malfunction.	◦ Ensure both ends of the adapter are securely plugged in. ◦ Test the power outlet with another device. ◦ If issues persist, consult the turntable's manual or contact support.
Adapter feels unusually hot.	◦ Overload or internal issue. ◦ Poor ventilation.	◦ Unplug immediately. Allow to cool. ◦ Ensure adapter is in a well-ventilated area. ◦ If overheating continues, discontinue use.

7. Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** (Specific output voltage/current not provided in product data)
- **Certifications:** CE, FCC, RoHS
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)
- **Color:** Black
- **Cable Length:** Approximately 1.2m / 4ft
- **Dimensions (Adapter Unit):** Approximately 1.18in (width), 1.58in (depth), 2.92in (height)



Figure 5: Detailed dimensions of the PK Power AC/DC Adapter, indicating its compact size for portability and ease of use.

8. Warranty and Support

PK Power products are designed for reliability. For specific warranty information or technical support, please refer to the documentation included with your purchase or visit the official PKPOWER website. Our customer service team aims to respond to inquiries within 24 hours.

For further assistance, you may contact the seller directly through the platform where the purchase was made.

© 2023 PKPOWER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XK77XM2

More documents and user manuals: **https://manuals.plus/**