Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter

PKPower AC/DC Adapter User Manual

For FreeMotion 250U Upright Bike and 350R Exercise Bikes

Introduction

This manual provides essential information for the safe and efficient use of your PKPower AC/DC Adapter. This adapter is specifically designed to provide power to FreeMotion 250U Upright Bikes and FreeMotion 350R Exercise Bikes. Please read these instructions carefully before use and retain them for future reference.



Image 1: PKPower AC/DC Adapter. This image shows the compact black adapter with its attached power cord and two-prong plug.

Setup Instructions

1. **Unpack the Adapter:** Carefully remove the AC/DC adapter from its packaging. Inspect it for any signs of damage. Do not use if damaged.
2. **Locate the Power Port:** Identify the power input port on your FreeMotion 250U Upright Bike or 350R Exercise Bike. Refer to your exercise bike's manual for the exact location if needed.
3. **Connect to Exercise Bike:** Insert the adapter's output connector firmly into the power input port of your exercise bike. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 100-240V AC wall outlet. Ensure the outlet is easily accessible and not overloaded.
5. **Verify Power:** Once connected, your exercise bike should receive power. Check the bike's display or indicators to confirm it is powered on.

Important Safety Note: This adapter is equipped with Over Voltage Protection (OVP), Over Current Protection (OCP),

and Short Circuit Protection (SCP) to ensure safe operation. Always use the adapter in a well-ventilated area and avoid covering it during use.

Operating Instructions

The PKPower AC/DC Adapter functions as a dedicated power supply for your FreeMotion exercise bike. Once properly connected as described in the "Setup Instructions" section, the adapter continuously supplies the necessary power for your bike's operation. There are no user-adjustable settings on the adapter itself.

- Ensure the adapter is always plugged into a functional wall outlet when the exercise bike is in use.
- To disconnect power, first unplug the adapter from the wall outlet, then disconnect it from the exercise bike.
- Do not attempt to use this adapter with devices other than the specified FreeMotion 250U Upright Bike and 350R Exercise Bikes to prevent potential damage.

Maintenance

Proper maintenance ensures the longevity and safe operation of your AC/DC adapter.

- **Cleaning:** Disconnect the adapter from both the wall outlet and the exercise bike before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter's casing and cable for any signs of wear, cuts, or damage. If any damage is observed, discontinue use immediately and replace the adapter.
- **Environment:** Keep the adapter away from water, high humidity, and corrosive materials.

Troubleshooting

If you encounter issues with your PKPower AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Exercise bike does not power on.	• Adapter not properly connected. • Wall outlet is not functional. • Adapter or cable is damaged.	• Ensure both ends of the adapter are securely plugged in. • Test the wall outlet with another device. • Inspect the adapter and cable for damage. If damaged, replace the adapter.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal. If the adapter becomes excessively hot to touch or emits a burning smell, disconnect it immediately and cease use. Contact customer support.
Intermittent power to the bike.	Loose connection or damaged cable.	Check all connections for tightness. Inspect the cable for any breaks or frayed wires. Replace if damaged.

Product Specifications

- **Input:** 100-240V AC, 0.3A, 50/60Hz
- **Compatibility:** Specifically designed for FreeMotion 250U Upright Bike and FreeMotion 350R Exercise Bikes.
- **Certifications:** CE, FCC, RoHS
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)
- **Included Components:** 1 AC/DC Adapter



Image 2: PKPower AC/DC Adapter with dimensions. The adapter measures approximately 2.92 inches in length, 1.58 inches in width, and 1.18 inches in height.

Customer Support

For any questions, concerns, or assistance with your PKPower AC/DC Adapter, please contact our customer service team. We aim to respond to all inquiries within 24 hours.

- **Online Support:** Visit the PKPOWER Store on Amazon for product information and support options.
- **Email:** Refer to your product packaging or purchase documentation for specific email contact details.

Warranty Information

PKPOWER products are manufactured to high-quality standards. While specific warranty terms may vary, our commitment to customer satisfaction ensures that our friendly and reliable customer service team is available to assist you with any product-related issues. Please retain your proof of purchase for warranty claims.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XPJM7XT

More documents and user manuals: **https://manuals.plus/**