Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER NTCCEX03810

PKPOWER AC Adapter Instruction Manual

For Nordi Track GX 4.0 and Compatible Exercise Bikes

Introduction

This manual provides essential instructions for the safe and effective use of your PKPOWER AC Adapter. This adapter is designed to provide reliable power to compatible Nordi Track GX 4.0 series exercise bikes and other specified models. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to water, moisture, or high humidity.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input specifications (100-240V AC).
- **Cable Integrity:** Regularly inspect the power cord for any signs of damage, fraying, or exposed wires. Do not use if damaged.
- **Ventilation:** Do not cover the adapter during use, as this may lead to overheating.
- **Disconnect Safely:** Always grasp the plug, not the cord, when disconnecting from the wall outlet or device.
- **Children and Pets:** Keep the adapter and its cord out of reach of children and pets.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

Package Contents

Verify that your package contains the following item:

- 1 x PKPOWER AC Adapter



Image: The PKPOWER AC Adapter shown with its power cord coiled.

Setup

Follow these steps to connect your AC adapter to your exercise bike:

1. **Identify the Power Port:** Locate the DC input power port on your Nordi Track GX 4.0 exercise bike. Refer to your bike's instruction manual if you are unsure.
2. **Connect to Bike:** Insert the barrel connector end of the PKPOWER AC Adapter cable firmly into the power port of your exercise bike.
3. **Connect to Power Outlet:** Plug the AC adapter's wall plug into a standard 100-240V AC electrical wall outlet.

4. **Secure Connections:** Ensure all connections are secure and the adapter is not loose in the outlet.



Image: An angled view of the PKPOWER AC Adapter, showing the plug and cable connection.

Operating Instructions

Once the adapter is correctly connected to both the exercise bike and a power outlet, your exercise bike should be ready for operation. The adapter provides a stable 12V DC output at 1 Amp, suitable for the specified models.
The PKPOWER AC Adapter incorporates multiple protection features to ensure safety and longevity:

- **OVP (Over Voltage output Protection):** Safeguards against excessive output voltage.
- **OCP (Over Current output Protection):** Protects against excessive output current.
- **SCP (Short Circuit output Protection):** Prevents damage from short circuits.



Image: A top-down view of the PKPOWER AC Adapter, highlighting its compact design.

Maintenance

Proper maintenance helps extend the life of your AC adapter:

- **Cleaning:** Use a dry, soft cloth to clean the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures.
- **Cable Care:** Avoid bending or crimping the power cord excessively. Do not place heavy objects on the cord.
- **Unplug When Not in Use:** Disconnect the adapter from the wall outlet and the exercise bike if it will not be used for an extended period.

Troubleshooting

If you encounter issues with your AC adapter, try the following steps:

- **No Power to Bike:**
  - Ensure the adapter is securely plugged into both the wall outlet and the exercise bike.
  - Test the wall outlet with another device to confirm it is receiving power.
  - Check the exercise bike's power switch or button.
- **Adapter Feels Hot:** It is normal for power adapters to generate some heat during operation. However, if the adapter becomes excessively hot to the touch or emits a burning smell, immediately unplug it from the wall outlet and the device. Contact customer support.
- **Flickering Power:** If the power to your bike is intermittent, check all connections for looseness. Try a different wall outlet.

Specifications

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Output Voltage	12V DC
Current Rating	1 Amp
Connector Type	Barrel Connector
Protection Features	OVP, OCP, SCP (Over Voltage, Over Current, Short Circuit Protection)
Certifications	CE, FCC, RoHS
Compatible Models	Nordi Track GX 4.0, 219731, 21973.1, 831.219731, 831.21973.1, NTCCEX03810.0, NTCCEX03810.1, CC640G14879
Included Components	1 AC Adapter



Image: The PKPOWER AC Adapter displaying its physical dimensions (1.58 in, 2.92 in, 1.18 in).

Warranty Information

Specific warranty details for this PKPOWER AC Adapter are not provided within this manual. Please refer to the product packaging, the manufacturer's official website, or your purchase documentation for comprehensive warranty terms and conditions.

Support Information

For technical assistance, troubleshooting beyond this manual, or inquiries regarding your PKPOWER AC Adapter, please contact PKPOWER customer service. Contact information can typically be found on the product packaging or the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XPK2RP6

More documents and user manuals: **https://manuals.plus/**