Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

APEX LEGENDS LD230RM

APEX Digital LD230RM TV Remote Control User Manual

Model: LD230RM

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your APEX Digital LD230RM TV Remote Control. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

The APEX Digital LD230RM is an original replacement remote designed for compatible APEX Digital televisions, offering reliable control over your TV's functions.

2. Product Overview

The APEX Digital LD230RM remote control is an infrared (IR) device designed for straightforward operation of your television. It features an ergonomic design for comfortable handling and provides access to all standard TV functions.


DISPLAY
TV
HDMI
MHL
SLEEP
ZOOM
CH LIST
GUIDE
FAV
FREEZE
EXIT
OK
MENU
INFO
VOL
CH
MUTE
1
2
3
4
5
6
7
8
9
0
INPUT
AUDIO
PICTURE
CCD
APEX
DIGITAL
LD230RM

Figure 1: Front view of the APEX Digital LD230RM TV Remote Control. This image displays the remote's layout, including the power button, channel and volume controls, number pad, and navigation buttons.

3. Setup

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

3.2. Initial Use

The APEX Digital LD230RM is an infrared remote control. No programming is typically required for compatible APEX Digital televisions. Once batteries are installed, point the remote directly at your television and press the Power button to test its functionality.

4. Operating Instructions

Ensure there is a clear line of sight between the remote control and the television's IR receiver for proper operation. Obstructions can interfere with the signal.

- **Power Button:** Press to turn the television on or off.
- **Channel Up/Down:** Press to change channels sequentially.
- **Volume Up/Down:** Press to increase or decrease the television's volume.
- **Mute Button:** Press to temporarily silence the television's audio. Press again to restore sound.
- **Number Buttons (0-9):** Use to directly enter channel numbers.
- **Input/Source Button:** Press to cycle through available input sources (e.g., HDMI 1, AV, Component).
- **Menu Button:** Access the television's on-screen menu for settings adjustments.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate within the TV's on-screen menus and confirm selections.

5. Maintenance

5.1. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

5.2. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.

5.3. Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the TV's IR receiver.
  - Confirm you are pointing the remote directly at the TV.
- **Some buttons not working:**
  - Clean the remote control surface, especially around the non-working buttons, to remove any dirt or debris that might be preventing proper contact.
  - If cleaning and battery replacement do not resolve the issue, the remote may require replacement.
- **TV not responding to any remote:**
  - Ensure the TV itself is powered on and not in standby mode.
  - Check the TV's power cable connection.
  - If the TV does not respond to any remote, there might be an issue with the TV's IR receiver or internal components. Consult your TV's user manual or contact TV support.

7. Specifications

Model Number	LD230RM
Brand	APEX LEGENDS (Manufacturer: APEX)
Connectivity Technology	Infrared (IR)
Compatible Devices	Television
Max Number of Supported Devices	1
Special Feature	Ergonomic
Package Dimensions	6 x 2 x 0.5 inches
Date First Available	March 20, 2017

8. Warranty and Support

For information regarding warranty coverage or technical support for your APEX Digital LD230RM remote control, please refer to the documentation provided with your television or contact the original manufacturer, APEX, directly. Specific warranty terms may vary based on the purchase location and date.

It is recommended to retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XRFT12X

More documents and user manuals: **https://manuals.plus/**