Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Adapter for Packard Bell EasyNote Series

PK Power AC Adapter User Manual

For Packard Bell EasyNote Laptops

1. Introduction

This manual provides essential instructions for the safe and effective use of your PK Power AC Adapter. Please read this manual thoroughly before using the product and retain it for future reference. This AC adapter is designed to provide reliable power to compatible Packard Bell EasyNote laptop models.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- **Power Source:** Only connect the adapter to a power outlet that matches the input voltage range specified on the adapter (100-240V AC, 50-60Hz).
- **Ventilation:** Ensure the adapter is placed in a well-ventilated area. Do not cover the adapter, as this can lead to overheating.
- **Environmental Conditions:** Avoid exposing the adapter to moisture, extreme temperatures, or direct sunlight. Use indoors only.
- **Cable Integrity:** Regularly inspect the power cords for any signs of damage. Do not use the adapter if the cords are frayed or damaged.
- **Protection Features:** This adapter is equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.
- **Certifications:** The product is CE, FCC, and RoHS certified, indicating compliance with relevant safety and environmental standards.
- **Children:** Keep the adapter out of reach of children.

3. Package Contents

Verify that all items are present in the package:

- PK Power AC Adapter Unit
- AC Power Cord (for wall outlet connection)



Image 1: The PK Power AC Adapter unit shown with its detachable AC power cord and the DC output cable.

4. Setup Instructions

Follow these steps to set up your AC adapter:

1. **Connect the AC Power Cord:** Take the AC power cord (the one with the 2-pin plug) and connect one end firmly into the AC input port on the adapter unit.
2. **Connect to Laptop:** Take the DC output cable (the one with the barrel connector) and insert the barrel connector firmly into the power input port of your Packard Bell EasyNote laptop.
3. **Plug into Wall Outlet:** Insert the 2-pin plug of the AC power cord into a standard wall power outlet (100-240V AC).
4. **Verify Connection:** Once connected, your laptop should indicate that it is receiving power or charging.



Image 2: A closer view of the PK Power AC Adapter, highlighting the barrel connector for the laptop and the 2-pin plug for the wall outlet.

5. Operating Instructions

The PK Power AC Adapter is designed for straightforward operation:

- **Charging:** When connected correctly, the adapter will automatically begin charging your laptop's battery or powering the laptop directly if the battery is removed or fully charged.
- **Powering On:** You can power on your laptop while it is connected to the AC adapter, even if the battery is completely drained.
- **Disconnection:** To disconnect, first unplug the AC power cord from the wall outlet, then disconnect the barrel connector from your laptop.
- **Travel Feature:** The compact design and wide input voltage range (100-240V) make this adapter suitable for travel, allowing use in various regions with appropriate plug adapters (not included).

6. Maintenance

Proper maintenance ensures the longevity and performance of your AC adapter:

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cables to prevent damage.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter yourself. This can void the warranty and pose safety risks.

7. Troubleshooting

If you encounter issues with your AC adapter, try the following steps:

- **No Power/Charging:**
  - Ensure all connections (wall outlet, adapter unit, laptop) are secure.
  - Try plugging the adapter into a different wall outlet to rule out a faulty outlet.
  - Check the power cords for any visible damage or breaks.
- **Adapter Overheating:**
  - Ensure the adapter is in a well-ventilated area and not covered.
  - Disconnect the adapter for a few minutes to allow it to cool down.
- **Laptop Not Recognizing Adapter:**
  - Restart your laptop while the adapter is connected.
  - Ensure the barrel connector is fully inserted into the laptop's power port.

If the problem persists after performing these checks, please contact customer support.

8. Specifications

Input Voltage	100-240V AC, 50-60Hz
Connector Type	Barrel Connector
Main Power Connector	2 Pin
Special Feature	Travel-friendly design
Certifications	CE, FCC, RoHS
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
ASIN	B06XSJRF3Z
UPC	794959637775

9. Compatible Models

This PK Power AC Adapter is compatible with various Packard Bell EasyNote laptop models, including but not limited to:

- Packard Bell EasyNote TS11HR-2314G1TMNKK
- Packard Bell EasyNote TS11-HR-002NCD
- Packard Bell EasyNote TS11SB-250GE
- Packard Bell EasyNote TS11SB-4334G32MNKK
- Packard Bell EasyNote TS11HR-52454G50MNKK
- Packard Bell EasyNote TS11HR-32353G75MNKK
- Packard Bell EasyNote TS11HR-32354G50MNKK
- Packard Bell EasyNote TS11HR-32356G50MNKK

Please verify your laptop's power requirements and connector type before use.

10. Warranty and Support

PK Power stands by the quality of its products. If you have any questions, concerns, or require assistance with your AC adapter, our friendly and reliable customer service team is available to help. We aim to respond to all inquiries within 24 hours.
For support, please refer to the contact information provided with your purchase or visit the official PKPOWER store on Amazon.

© 2024 PK Power. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XSJRF3Z

More documents and user manuals: **https://manuals.plus/**