Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN12Z-BK

Minolta MN12Z-BK Digital Camera User Manual

Model: MN12Z-BK

Introduction

Thank you for purchasing the Minolta MN12Z-BK Digital Camera. This manual provides essential information on how to set up, operate, and maintain your camera to ensure optimal performance and longevity. Please read this manual thoroughly before using your camera and keep it for future reference.

What's in the Box

Please check that all the following items are included in your package:

- Minolta MN12Z-BK Digital Camera
- 8GB SD Card
- Camera Pouch
- Instruction Manual (this document)
- Warranty Information

Setup

1. Charging the Battery

The camera uses a Lithium Ion battery. Before first use, fully charge the battery. Insert the battery into the camera with the correct orientation. Connect the camera to a power source using the provided USB cable and adapter (if included). The charging indicator light will show the charging status.

2. Inserting the SD Card

Locate the SD card slot, typically on the side or bottom of the camera. Insert the included 8GB SD card into the slot until it clicks into place. Ensure the card is inserted in the correct direction to avoid damage. The camera requires an SD card to store photos and videos.

3. Powering On/Off

Press and hold the power button located on the top of the camera to turn it on or off. The lens will extend when powered on.

Operating Instructions

Taking Photos

To take a photo, ensure the camera is in photo mode. Frame your shot using the 2.7-inch LCD screen. Press the shutter button halfway down to focus, then press it fully to capture the image. The camera features a 20-megapixel sensor for high-resolution stills.



This image displays the front of the Minolta MN12Z-BK digital camera, highlighting its 12x optical zoom lens, built-in flash, and the Minolta logo. The camera is black with silver accents around the lens.

Using the Optical Zoom

The camera is equipped with a 12x optical zoom lens. Use the zoom lever, typically located around the shutter button, to zoom in or out. Optical zoom allows you to magnify distant subjects without compromising image quality.

Recording HD Video

To record video, switch the camera to video mode. Press the record button (often marked with a red dot) to start and stop recording. The camera records in 720p HD resolution.



This image shows the rear of the Minolta MN12Z-BK digital camera, featuring its 2.7-inch LCD screen displaying a vibrant image. Various control buttons for navigation and settings are visible to the right of the screen.

Wi-Fi & Bluetooth Connectivity

The camera supports Wi-Fi and Bluetooth for wireless transfer of photos and videos to compatible devices. Refer to the camera's on-screen menu for instructions on pairing and connecting to your smartphone or computer.

Scene Modes and Features

The MN12Z-BK offers 26 intelligent scene modes to optimize settings for various shooting conditions. Explore modes like portrait, landscape, night, and sports. Additional features include face detection, panorama shooting, and time-lapse video. Access these modes through the camera's menu system.

Maintenance

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for camera lenses. Avoid touching the lens with your fingers.
- **Cleaning the Body:** Wipe the camera body with a soft, dry cloth. Do not use harsh chemicals or solvents.
- **Battery Care:** Store the battery in a cool, dry place when not in use. Avoid extreme temperatures.
- **Storage:** When not in use for extended periods, store the camera in its pouch in a dry, dust-free environment.

Troubleshooting

Problem	Possible Solution
Camera does not turn on.	Ensure the battery is fully charged and correctly inserted. Try removing and reinserting the battery.
Cannot take pictures.	Check if the SD card is inserted correctly and has sufficient free space. Ensure the camera is in photo mode.
Images are blurry.	Ensure the lens is clean. Press the shutter button halfway to allow the camera to focus before fully pressing. Check lighting conditions.
Wi-Fi/Bluetooth connection fails.	Ensure the camera's Wi-Fi/Bluetooth is enabled. Check the settings on your connecting device. Move closer to the device.

Specifications

Feature	Detail
Model Name	MN12Z-BK
Still Image Resolution	20 Megapixels
Video Resolution	720p HD
Optical Zoom	12x
Image Stabilization	Digital, Optical
LCD Screen Size	2.7 inches
Connectivity	Wi-Fi, Bluetooth
Photo Sensor Technology	CMOS
Supported File Format	JPEG, RAW
Dimensions (L x W x H)	4 x 1.1 x 2.4 inches
Item Weight	4.8 ounces
Battery Type	1 Lithium Ion (included)
Date First Available	May 18, 2017

Warranty and Support

Your Minolta MN12Z-BK Digital Camera comes with a limited warranty. Please refer to the separate warranty information included in your package for details on coverage and terms. For technical support, product registration, or further assistance, please visit the official Minolta website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Minolta. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071VVDS41

More documents and user manuals: **https://manuals.plus/**